

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>John H. Hendrix</b>	8. Farm or Lease Name <b>S. E. Long</b>
3. Address of Operator <b>316 Central Bldg., Midland, Texas 79701</b>	9. Well No. <b>2</b>
4. Location of Well UNIT LETTER <b>J</b> , <b>1980</b> FEET FROM THE <b>South</b> LINE AND <b>1980</b> FEET FROM THE <b>East</b> LINE, SECTION <b>11</b> TOWNSHIP <b>22 South</b> RANGE <b>37 East</b> NMPM.	10. Field and Pool, or Wildcat <b>Drinkard</b>
15. Elevation (Show whether DF, RT, GR, etc.)	12. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

### Proposed Operations - To Drill out & Test Drinkard

1. Squeeze Penrose Skelly and Paddock, Perforations w/250 sacks @ approx. 1500#.
2. Drill out CIBP at 5175', and fish tubing 5175' - 5225'.
3. Drill out Model "K" Cement retainer at 5225'.
4. Drill out cement from 5225' - 6465'.
5. Set 7" CIBP at 6465'.
6. Perforate selected Drinkard horizon 6350' - 6450' with 11 jet shots.
7. Acidize with 5000 gallons 15% LSTNE.
8. Swab & Test Drinkard zone.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED <b>John H. Hendrix</b>	TITLE <b>Owner-Operator</b>	DATE <b>9-18-70</b>
APPROVED BY <b>[Signature]</b>	TITLE <b>Commissioner</b>	DATE <b>1970</b>
CONDITIONS OF APPROVAL, IF ANY:		