

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee   
5. State Oil & Gas Lease No.  
**B-1484**

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator <b>CITIES SERVICE OIL COMPANY</b>	7. Unit Agreement Name
3. Address of Operator <b>Box 69, Hobbs, New Mexico 88240</b>	8. Farm or Lease Name <b>State 0</b>
4. Location of Well UNIT LETTER <b>B</b> <b>660</b> FEET FROM THE <b>North</b> LINE AND <b>1980</b> FEET FROM THE <b>East</b> LINE, SECTION <b>32</b> TOWNSHIP <b>26S</b> RANGE <b>37E</b> NMPM.	9. Well No. <b>2</b> 10. Field and Pool, or Wildcat <b>Jalmon Yates</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>2955' DF</b>	12. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**TD 3250', PBTD 3244', Jalmon Yates. We propose to plug and abandon this well in the following manner:**

1. Load hole with mud laden fluid.
2. Spot 104' cement plug from 3140-3244'.
3. Shoot off and recover approximately 2120' of 5 1/2" casing.
4. Displace 35 sack cement plug 1/2 in and 1/2 out of 5 1/2" casing stub.
5. Displace 25 sack cement plug 1/2 in and 1/2 out of 8 5/8" casing shoe at 651'.
6. Dump 10 sack cement plug in top of 8 5/8" casing from ground level to 30'.
7. Reclaim well head and install 4" dry hole marker.
8. Clear location of all materials and debris.

*35 sacks @ top seat*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *Mike Grand* TITLE Production Engineer DATE Oct. 5, 1971

APPROVED BY Joe D. Ramey TITLE SUPERVISOR DISTRICT I DATE OCT 7 1971  
Orig. Signed by  
Joe D. Ramey  
Dist. I, Supv.  
 CONDITIONS OF APPROVAL, IF ANY:

**RECEIVED**

OCT - 6 1971

**OIL CONSERVATION COMM.**

HOBBS, N. M.

10/11/71  
10/11/71