
Office	State of New M	<b>1</b> exico		Form C-103		
District I – (575) 393-6161 Er	ergy, Minerals and Na	tural Resources		Revised July 18, 2013		
1625 N. French Dr., Hobbs, NM 88240			WELL API NO.			
District II – (575) 748-1283	IL CONSERVATIO	N DIVISION	30-005-60036			
811 S. First St., Artesia, NM 88210 District III – (505) 334-6178	1220 South St. Fr		5. Indicate Type of Lease			
1000 Rio Brazos Rd., Aztec, NM 87410			STATE FEE			
<u>District IV</u> – (505) 476-3460	Santa Fe, NM	8/303	6. State Oil & Gas Lea	ase No.		
1220 S. St. Francis Dr., Santa Fe, NM 87505						
SUNDRY NOTICES AN	D REPORTS ON WELL	S	7. Lease Name or Unit	t Agreement Name		
(DO NOT USE THIS FORM FOR PROPOSALS TO			Kitchens PH	t 7 igreement i vame		
DIFFERENT RESERVOIR. USE "APPLICATION F			8. Well Number			
PROPOSALS.)			1			
1. Type of Well: Oil Well Gas We	ell 🛛 Other	RESUBMIT				
2. Name of Operator			9. OGRID Number			
EOG Resources, Inc.			7377	1 ,		
3. Address of Operator	0		10. Pool name or Wildcat			
104 South Fourth Street, Artesia, NM 8821	0		Pecos Slope; Abo			
4. Well Location						
Unit Letter <u>K</u> : <u>1980</u>	feet from the Sou	th line and	feet from the	<u>West</u> line		
Section 6	Township 9S F	Range 26E	NMPM Chaves	County		
	evation (Show whether D			County		
	1	)6'GR				
12 Check Appropri	riate Box to Indicate		Report or Other Data	a		
12. Check Appropr	ince Box to indicate	rvature or rvotice,	Report of Other Date			
NOTICE OF INTENT	ON TO:	SUB	SEQUENT REPOR	RT OF:		
	AND ABANDON	REMEDIAL WOR		ERING CASING		
TEMPORARILY ABANDON	GE PLANS	COMMENCE DRI	LLING OPNS. P A	ND A		
	PLE COMPL	CASING/CEMEN		_		
DOWNHOLE COMMINGLE	_		OCD 24 hrs. prior to a	any work		
CLOSED-LOOP SYSTEM			7 OCD 24 III3. prior to a	ally WOIK		
OTHER:		OTHER: done				
13. Describe proposed or completed oper of starting any proposed work). SE proposed completion or recompletion	E RULE 19.15.7.14 NM					
EOG Resources, Inc. plans to plug and a	oandon this well as fol	lows:				
<ol> <li>MIRU all safety equipment as needed</li> <li>Set a CIBP at 3967' with 25 sx Class</li> <li>Perforate at 1955'. Squeeze 45 sx Class</li> <li>Perforate at 1250'. Squeeze 50 sx Class</li> <li>Perforate at 858'. Squeeze 50 sx Class</li> <li>Perforate at 60'. Squeeze 40 sx Class</li> <li>Cut off wellhead and weld on dry hole</li> </ol>	"C" cement on top to ass "C" cement from 19 ass "C" cement from 19 s "C" cement from 85 "C" cement from 60 u	3767'. WOC & T 955'-1805'. WOC to 250'-1100'. WOC to 8'-708'. WOC and to up to surface.	ag o tag. o tag. Attempt to circ ag. Attempt to circ erf @100' and Attemp	cmt to surf.		
XX 111 1 2 4 1 1						
Wellbore schematic attached						
Use	closed loop syst	tem - no fluids	on ground			
Spud Date:	Rig Release	Date:				
·						
****SEE ATTACHED COA	's****	MUST BE P	LUGGED BY 12	2/30/2021		
I hereby certify that the information above is				LIGOILOLI		
Thereby certify that the information above is	true and complete to the	best of my knowledge	c and benef.			
signature <i>Tina Huerta</i>	TITLE	Regulatory Specialis	t DATE Dece	ember 16, 2020		
Type or print name Tina Huerta	E-mail address:	tina_huerta@eogreso	urces.com PHONE	: <u>575-748-4168</u>		
For State Use Only		-				
APPROVED BY:	TITLE	Staff Man	agerDATE	12/30/2020		
Conditions of Approval (if any):			<i>U</i> ====================================			

Conditions of Approval (if any):

Released to Imaging: 12/31/2020 2:10:40 PM

Ki	itchens F	PH #1 (	Current			TWN-RNG: OOTAGES:	6-9S-26E 1980'FSL & 198	D'FWL		GL:	30-005-60036 3705'			
										KB:				
					CASING	DETAIL								
					#	HOLE SIZE	SIZE	WGHT	GRADE	Тор	Bottom	Sx Cmt	Circ/TOC	TOC by
					Α	10-3/4"	8-5/8"	24#	J-55	0	1200'	600	CIRC	TOC by
					В	7-7/8"	4-1/2"	9.5#	J-55	0	4707'	475	3515'	Temp Survey
						1-1/0	4-1/2	5.5#	3-33	0	4707	473	3313	Terrip Survey
					FORMAT	TION TOPS								
							FORMATION	TOP			Fromation	TOP		
							San Andres	808						
							Glorieta	1905						
	Α						Abo	4094						
					<u> </u>									
							T	T			T			
					Perforati	ion Detail		1				1		
							Formation	Тор	Bottom		Treatment		Notes	
							Abo	4274	4415		Acidized w/3000g 7-1/2%			
								4357	4415		Re-acidized w/500g 7-1/2			
								4184	4226		Acidized w/2000g 7-1/2%			
								4067	4095		Acidized w/1000g 7-1/2%			
								4067	4415		Frac w/60,000g gel KCL v			
											110,000Lb sand (10,000	100 mesh a	and 100,000 20/40	sand)
								T		Т.				
				TOC 3515'										
				(temp survey)										
Abo Perfs: 4067'-4095'														
Abo Perfs: 4184'-4226"														
2-3/8" tubing at 4350'					ADDITIO	NAL DETAIL	Т	1			T		Т	
								1						
Abo Perfs: 4274'-4415'					-	-				1		1		
					-					1				$\vdash$
														<del>                                     </del>
					-	<del>                                     </del>				1				<del>                                     </del>
					-	<del>                                     </del>				1				<del>                                     </del>
	В						repared by: TH							
	PBTD:	4675'	MD	4			roparou by. 111							
	TD:		MD						10/26	/20				
ļ	10.				1									



## CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E)Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - I) Glorieta
  - J) Yates.
  - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

## **DRY HOLE MARKER REQUIRMENTS**

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

<u>District I</u> 1625 N. French Dr., Hobbs, NM 88240 Phone:(575) 393-6161 Fax:(575) 393-0720

811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720 District III
1000 Rio Brazos Rd., Aztec, NM 87410

Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

CONDITIONS

Action 12336

## **CONDITIONS OF APPROVAL**

Operator:			OGRID:		Action Type:
EOG RESOURCES INC	P.O. Box 2267	Midland, TX79702	7377	12336	C-103F

OCD Reviewer	Condition
gcordero	COA's attached to file