

Office
 District I – (575) 393-6161
 1625 N. French Dr., Hobbs, NM 88240
 District II – (575) 748-1283
 811 S. First St., Artesia, NM 88210
 District III – (505) 334-6178
 1000 Rio Brazos Rd., Aztec, NM 87410
 District IV – (505) 476-3460
 1220 S. St. Francis Dr., Santa Fe, NM
 87505

State of New Mexico
 Energy, Minerals and Natural Resources

Form C-103
 Revised July 18, 2013

OIL CONSERVATION DIVISION
 1220 South St. Francis Dr.
 Santa Fe, NM 87505

WELL API NO. 30-015-22242
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Mitchell SWD
8. Well Number 2
9. OGRID Number 7377
10. Pool name or Wildcat SWD; San Andres

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other SWD	
2. Name of Operator EOG Resources, Inc.	
3. Address of Operator 104 South Fourth Street, Artesia, NM 88210	
4. Well Location Unit Letter <u>I</u> : <u>2030</u> feet from the <u>South</u> line and <u>660</u> feet from the <u>East</u> line Section <u>23</u> Township <u>17S</u> Range <u>25E</u> NMPM <u>Eddy</u> County	
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3476'GR	

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input checked="" type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> MULTIPLE COMPL <input type="checkbox"/> DOWNHOLE COMMINGLE <input type="checkbox"/> CLOSED-LOOP SYSTEM <input type="checkbox"/> OTHER: <input type="checkbox"/>	SUBSEQUENT REPORT OF: REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> P AND A <input type="checkbox"/> CASING/CEMENT JOB <input type="checkbox"/> OTHER: <input type="checkbox"/>
---	---

Notify OCD 24 hrs. prior to any work done

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

EOG Resources, Inc. plans to plug and abandon this well as follows:

1. MIRU all safety equipment as needed. NU BOP. POOH with production equipment.
2. Set a CIBP at 8829' with 25 sx Class "H" cement on top to 8609'. WOC and tag. This will cover Devonian perfs and tops.
3. Spot a 30 sx Class "H" cement plug from 8058'-7794'. WOC and tag. This will cover DV tool, Atoka, Morrow, Chester and Mississippian top.
4. Spot a 33 sx Class "C" cement plug from 7407'-7081'. This will cover Strawn and Canyon tops.
5. Spot a 25 sx Class "C" cement plug from 6521'-6274'. This will cover Penn top.
6. Spot a 25 sx Class "C" cement plug from 5350'-5103'. This will cover Wolfcamp top.
7. Spot a 25 sx Class "C" cement plug from 4164'-3917'. This will cover Abo top.
8. Spot a 25 sx Class "C" cement plug from 2288'-2041'. WOC and tag. This will cover DV tool.
9. Perforate at 1312'. Spot a 25 sx Class "C" cement plug from 1312'-1065'. WOC and tag. This will cover Intermediate casing shoe.
10. Perforate at 408'. Spot a 42 sx Class "C" cement plug from 408' up to surface. WOC and tag. Back fill as needed. This will cover the Surface casing shoe and surface plug.
11. Cut off wellhead and install dry hole marker. Clean location as per regulated.

Wellbore schematics attached.

Spud Date:

Rig Release Date:

****SEE ATTACHED COA's****

MUST BE PLUGGED BY 5/14/2022

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Tina Huerta TITLE Regulatory Specialist DATE May 14, 2021

Type or print name Tina Huerta E-mail address: tina.huerta@eogresources.com PHONE: 575-748-4168

For State Use Only

APPROVED BY: [Signature] TITLE Staff Manager DATE 5/14/2021

Conditions of Approval (if any):

CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
8. Produced water **will not** be used during any part of the plugging operation.
9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
11. Class 'C' cement will be used above 7500 feet.
12. Class 'H' cement will be used below 7500 feet.
13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) **Potash---** (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIREMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3. API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS


In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

Mitchell SWD #2 Current

Sec-TWN-RNG: Sec. 23-17S-28E
FOOTAGES: 2030' FSL & 660' FEL

API: 30-015-22242
GL: 3476
KB:



CASING DETAIL									
#	HOLE SIZE	SIZE	WGHT	GRADE	Top	Bottom	Sx Cmt	Circ/TOC	TOC Method
A	17 1/2	13 9/8	61	J-55	0	358	280	Circ	
B	12 1/4	8 5/8	24	J-55	0	1 282	1310	Circ	
C	7 7/8	5 1/2	15 5/17	N-80/J-55	0	5 461	1335	Circ 3 stage job	

FORMATION TOPS									
Formation	Top	Formation	Top	Formation	Top	Formation	Top	Formation	Top
Abo	4114								
Volcanic	5300								
Penn	6471								
Canyon	7142								
Strawn	7357								
Albion	7866								
Morrow Clastic	8011								
Chester	8162								
Mississippian	8301								
Devonian	8761								

TUBING DETAIL									
#	Joins	Description	Length	OD	ID	Grade	Wt (lbm)	Top (ftKB)	Bot (ftKB)
		2-7/8" Tubing							8769
DV tool @ 8108 & 2236'									
Packer @ 8769'									
cemented perfs @ 8018-8024 w/ 150sx Class H									
2 perfs @ 7010 & 5352 squeezed w/150 sx Class H									
Perf 2 holes @ 5875 & 2 holes @ 4300' cement w/250sx Class C									
perf 2 holes @ 4050 & @ 2355' Cement w/200sx class C									

Perforation Detail									
Formation	Top	Bottom	Treatment						
A	Devonian	8,879	9,362	Acidized w/1000 gals 15% NEFE acid, 500 gals 15% DS-30 acid, 10,000 gals 20% iron control acid and ball sealers					
B	Morrow	8,018	8,024						
C									

P8TD: 9,394 MD
TD: 9,500 MD

Mitchell SWD #2 Proposed

Sec-TWN-RNG: Sec. 23-17S-25E
FOOTAGES: 2030' FSL & 660' FEL

API: 30-015-22242
GL: 3476
KB:

Plug 8: Casing shoe + Surface plug

Plug 6: Abo top

Plug 7: DV tool


Plug 5: Wolfcamp top

Plug 4: Penn top

Plug 3: Strawn top + Canyon top

Plug 2: DV Tool + Abo top + Morrow Classic top + Chester top + Mississippian top

Plug 1: CIBP + Devonian Perfs + Devonian top



CASING DETAIL

#	HOLE SIZE	SIZE	WGHT	GRADE	Top	Bottom	SX CMT	Circ/TOC	TOC Method
A	17 1/2	13 3/8	61	J-55	0	358	280	Circ	
B	12 1/4	8 5/8	24	J-55	0	1,262	1310	Circ	
C	7 7/8	5 1/2	15.5/17	N-80/L-55	0	8,461	1335	Circ 3 stage job	

FORMATION TOPS

Formation	Top	Formation	Top
Abo	4114	Chester	8162
Wolfcamp	5306	Mississippian	8301
Penn	6471	Devonian	8781
Canyon	7142		
Strawn	7957		
Aboke	7986		
Morrow Classic	8011		

TUBING DETAIL

#	Joints	Description	Length	OD	ID	Grade	WT (lb/ft)	Top (ftKB)	Blm (ftKB)
		2-7/8" Tubing and packer						8,769	

DV tool @ 8108 & 2238'
Packer @ 8789'

commented perfs @ 801 B-8024 w/ 150sx Class H
2 perfs @ 7010 & 8352 squeezed w/ 150 sx Class H
Perf 2 holes @ 5875' & 2 holes @ 4300' cement w/ 250sx Class C
perf 2 holes @ 4050 & @ 2355 Cement w/ 200sx class C

Perforation Detail

Formation	Top	Bottom	Treatment
A	Devonian	3,873	9,352
B	Morrow	8,018	8,024

Plug

#	SX	Class	Top	Bottom	A	Notes	Tag
1	25	H	8,608	8,829	220	CIBP + Devonian perfs + Devonian top	Y
2	30	H	7794	8058	264	DV Tool + Abo top + Morrow Classic top + Chester top + Mississippian top	Y
3	33	C	7081	7407	326	Strawn top + Canyon top	N
4	25	C	6274	6521	247	Penn top	N
5	25	C	5103	5350	247	Wolfcamp top	N
6	25	C	3917	4164	247	Abo top	N
7	25	C	2041	2288	247	DV tool	Y
8	25	C	1,056	1,312	247	Casing shoe	Y
9	42	C	0	408	408	Casing shoe + Surface plug	Y

P87D: 9,384 MD
TD: 9,500 MD

Prepared By: Naomi F 5/4/21

District I

1625 N. French Dr., Hobbs, NM 88240
Phone:(575) 393-6161 Fax:(575) 393-0720

District II

811 S. First St., Artesia, NM 88210
Phone:(575) 748-1283 Fax:(575) 748-9720

District III

1000 Rio Brazos Rd., Aztec, NM 87410
Phone:(505) 334-6178 Fax:(505) 334-6170

District IV

1220 S. St Francis Dr., Santa Fe, NM 87505
Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico
Energy, Minerals and Natural Resources
Oil Conservation Division
1220 S. St Francis Dr.
Santa Fe, NM 87505

CONDITIONS

Action 28248

CONDITIONS OF APPROVAL

Operator:	EOG RESOURCES INC	P.O. Box 2267	Midland, TX79702	OGRID:	7377	Action Number:	28248	Action Type:	C-103F
-----------	-------------------	---------------	------------------	--------	------	----------------	-------	--------------	--------

OCD Reviewer	Condition
gcordero	None