ecesyed by OCD 5/27/2921 3:27:55 Office	PM State of New M	Mexico .		Form C-103 of				
<u>District I</u> – (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240	Energy, Minerals and Na	tural Resources	WELL API NO.	Revised July 18, 2013				
<u>District II</u> – (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL CONSERVATIO	N DIVISION	30-015-22997					
<u>District III</u> – (505) 334-6178	1220 South St. Fr	ancis Dr.	5. Indicate Type of Lease  STATE   FEE					
1000 Rio Brazos Rd., Aztec, NM 87410 <u>District IV</u> – (505) 476-3460	Santa Fe, NM	87505	6. State Oil & Gas Lease No.					
1220 S. St. Francis Dr., Santa Fe, NM 87505	L-2919							
SUNDRY NOTI (DO NOT USE THIS FORM FOR PROPOS DIFFERENT RESERVOIR. USE "APPLIC	7. Lease Name or Unit Agreement Name SRC KZ State 8. Well Number							
PROPOSALS.)  1. Type of Well: Oil Well	8. Well Number							
2. Name of Operator	9. OGRID Number							
EOG Resources, Inc.  3. Address of Operator	7377 10. Pool name or Wildcat							
104 South Fourth Street, Artesia, N	Penasco Draw; SA-Y							
4. Well Location	2310 feet from the Nort	h line and	2310 feet from the					
Section 1	<del></del>	Range 24E	NMPM Eddy	County				
Section	11. Elevation (Show whether D		J	County				
	367	71'GR	,					
12 Check A	appropriate Box to Indicate	Nature of Notice	Report or Other Da	ta				
			. •					
NOTICE OF IN PERFORM REMEDIAL WORK □	TENTION TO: PLUG AND ABANDON □	REMEDIAL WOR	BSEQUENT REPC	TERING CASING ☐				
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DR	<del>_</del>					
PULL OR ALTER CASING	MULTIPLE COMPL	CASING/CEMEN						
DOWNHOLE COMMINGLE			Notify OCD 24 hrs. prior	to any work				
CLOSED-LOOP SYSTEM  OTHER:	П	OTHER:	done					
	leted operations. (Clearly state al		nd give pertinent dates, i	ncluding estimated date				
	rk). SEE RULE 19.15.7.14 NM	AC. For Multiple Co	ompletions: Attach well	oore diagram of				
proposed completion or reco	ompletion.							
EOG Resources, Inc. plans to plug	and abandon this well as follows	s:						
MIRU all safety equipment as	needed. NU BOP. POOH with p	roduction equipment	t					
	x Class "C" cement on top to 188			and Glorieta top.				
3. Perforate at 1015'. Spot a 35 s	ox Class "C" cement plug from 10	015'-517'. WOC and	l tag. This will cover inte	ermediate casing shoe				
<ul><li>and San Andres top.</li><li>4. Perforate at 370'. Spot a 26 sx</li></ul>	Class "C" coment plug from 370	)' un to surface Raci	k fill as naodod					
	ry hole marker. Clean location as		k IIII as necucu.					
	•							
Wellbore schematics attached.								
Spud Date:	Rig Release	Date:						
****SEE ATTACHED  I hereby certify that the information is			ugged by 6/3/2022 ge and belief					
Tina Hunsta	-							
SIGNATURE	TITLE1	Regulatory Specialis	t DATE May 27,	<u>2021</u>				
Type or print name Tina Hue For State Use Only	rta E-mail address:	tina huerta@eogres	ources.com PHON	E: <u>575-748-4168</u>				
APPROVED BY:	TITLE	Staff Mar	nager DATE	6/4/2021				
Conditions of Approval (if any):		<i>(X)</i>	(/					

# CONDITIONS FOR PLUGGING AND ABANDONMENT

#### OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E)Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - I) Glorieta
  - J) Yates.
  - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing


## **DRY HOLE MARKER REQUIRMENTS**

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION



	KZ State	#4 Proposed			Sec. 1-19S-24E 2310' FNL & 231	0' FWL		GL:	30-015-22997 3671			
COMMENTS								KB:				
			CASING	CASING DETAIL								
	A		#	HOLE SIZE	SIZE	WGHT	GRADE	Тор	Bottom	Sx Cmt	Circ/TOC	TOC Method
			A	15	10 3/4	32		0	320	250	Circ	
			В	9 7/8	7	23	K-55	0	965	663	Circ	
			С	6 1/4	4 1/2	9.5		0	3,097	275	Circ	
3rd Plug: Sur. Csg. Shoe +												
Surface Plug												
			FORMATI	ON TOPS	=======================================		I	1				
					FORMATION	TOP			Fromation	TOP		
					San Andres	567		1				
					Glorieta	1938		1				
		27.77.97.97.			<u> </u>			<del>                                     </del>				
San Andres top												
	В											
						_	i e		·	, ,		
2nd Plug: Int. Csg. Shoe +			Perforation	n Detail				1				
San Andres top					Formation	Top	Bottom	1	Treatment			
					Yeso	2,407	2,705		1500 gallons regular acid, 60000 gallons gelled 2% kcl water 20000# 100 mesh and 75000# 20-40 sand			cl water,
						+			20000# 100 mesh and 750	J00# 20-40	sand	
		0.000 200 200 200 200 200 200 200 200 20		L								
Glorieta top			Plugs			T						
			#	SX	Class	Тор	Bottom	Δ	Notes	Tag		
			1	33	С	1888	2357	469	CIBP + Glorieta top	Υ		
			3	35 26	C	517 0	1015 370	498 370	Int Csg. Shoe + SA top Sur. Csg Shoe + Surface	Y N		
				20		0	370	310	our. Osy office + outlace	IN		
Plug 1: Yeso Perfs + Glorieta t	ор											
				-	-			1				
								1				
			-	1		1		-		1		
								1				
	С							1				
	•											
				Pr	epared by: JGM							
	PBTD:	3,097 MD					5/27/20	21				
	TD:	3,125 MD					5/2//20	۷ ا				

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720 District II

811 S. First St., Artesia, NM 88210 Phone: (575) 748-1283 Fax: (575) 748-9720 District III

1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

CONDITIONS

Action 29818

# **CONDITIONS**

Operator:	OGRID:
EOG RESOURCES INC	7377
P.O. Box 2267	Action Number:
Midland, TX 79702	29818
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

### CONDITIONS

Created By	Condition	Condition Date			
gcordero	None	6/4/2021			