

Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO.
30-025-36694
5. Indicate Type of Lease
STATE [X] FEE []
6. State Oil & Gas Lease No.
V-5527

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)
1. Type of Well: Oil Well [] Gas Well [X] Other
2. Name of Operator
EOG Resources, Inc.
3. Address of Operator
104 South Fourth Street, Artesia, NM 88210
4. Well Location
Unit Letter K : 1760 feet from the South line and 1350 feet from the West line
Section 7 Township 10S Range 34E NMPM Lea County
11. Elevation (Show whether DR, RKB, RT, GR, etc.)
4217'GR

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK [] PLUG AND ABANDON [X]
TEMPORARILY ABANDON [] CHANGE PLANS []
PULL OR ALTER CASING [] MULTIPLE COMPL []
DOWNHOLE COMMINGLE []
CLOSED-LOOP SYSTEM []
OTHER: []

SUBSEQUENT REPORT OF:

REMEDIAL WORK [] ALTERING CASING []
COMMENCE DRILLING OPNS. [] P AND A []
CASING/CEMENT JOB []
OTHER: []

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

EOG Resources, Inc. plans to plug and abandon this well as follows:

- 1. MIRU all safety equipment as needed. NU BOP. POOH with production equipment.
2. Set a CIBP at 12,125'. Pressure test. Spot 25 sx Class "H" cement on top of CIBP to 11,899'. WOC and tag. This will cover Morrow perms and top.
3. Spot a 25 sx Class "H" cement plug from 11,554'-11,328'. This will cover Atoka top.
4. Spot a 25 sx Class "H" cement plug from 9028'-8802'. This will cover Wolfcamp top.
5. Spot a 25 sx Class "H" cement plug from 7775'-7549'. This will cover Abo top.
6. Perforate at 5467'. Attempt injection rate. Spot a 25 sx Class "C" cement plug from 5467'-5215'. This will cover Glorieta top.
7. Perforate at 4210'. Attempt injection rate. Squeeze with 95 sx Class "C" cement from 4210'-3897'. WOC and tag. This will cover casing shoe and San Andres top.
8. Perforate at 2750'. Attempt injection rate. Squeeze with 40 sx Class "C" cement from 2750'-2618'. WOC and tag. This will cover Yates top.
9. Perforate at 482'. Attempt injection rate. Squeeze with 147 sx Class "C" cement from 482' and circulate up to surface. Verify cement at surface. Back fill as needed.
10. Cut off wellhead and install dry hole marker. Clean location as per regulated.

Wellbore schematics attached LPC Area Below ground marker send pics before backfilling hole

Spud Date: []


Rig Release Date: SEE ATTACHED CONDITIONS OF APPROVAL

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Tina Huerta TITLE Regulatory Specialist DATE February 22, 2022

Type or print name Tina Huerta E-mail address: tina.huerta@eogresources.com PHONE: 575-748-4168
For State Use Only

APPROVED BY: Kerry Fortner TITLE Compliance Officer A DATE 3/11/22
Conditions of Approval (if any): 575-263-6633



Sec-TWN-RNG: 7-10S-34E		API: 30-025-36694							
Surface: 1760' FSL & 1350' FWL		GL: 4217'							
		KB: 4235'							
COMMENTS									
Plug 8: Perf @ 482. 0' - 482'. Verify @ surface. Casing shoe + surface plug.									
Plug 7: Perf @ 2750. 2618' - 2750'. WOC & tag. Yates top									
Plug 6: Perf @ 4210. 3897' - 4210'. WOC & tag. Int csg shoe + San Andres top									
Plug 5: Perf @ 5467. 5215' - 5467'. WOC & tag. Glorieta top									
Plug 4: 7549' - 7775'. Abo top									
Plug 3: 8802' - 9028'. Wolfcamp top									
Plug 2: 11328' - 11554'. Atoka top									
Plug 1: CIBP @ 12125. 11899' - 12125'. WOC & tag. Morrow perfs + Morrow top Existing Morrow Perfs: 12175' - 12222'									
PBTD: 12,301 MD		TD: 12,425 MD							
KJP 2/16/2022									
CASING DETAIL									
#	Hole Size	Csg. Size	Wt.	Grade	Top	Bottom	Sx Cmt	TOC	TOC by
A	17 1/2	13 3/8	48	H-40	0	432	440	Surface	Circ.
B	12 1/4	9 5/8	36/40	J-55	0	4160	1435	Surface	Circ.
C	8 3/4	5 1/2	17	HCP-110	0	12425	3400	3660'	Calc.
FORMATION TOPS									
Formation	Top (MD)	Formation	Top (MD)						
Yates	2,700	Morrow	12,021						
San Andres	3,960	Austin	12,236						
Glorieta	5,417	Chester Lime	12,312						
Abo	7,725	Miss. Lime	12,384						
Wolfcamp	8,978								
Atoka Shale	11,504								
PLUGS									
#	SX	Class	Top	Bottom	Δ	Notes	Tag		
1	25	H	11899	12125	226	CIBP at 12125. Pressure test. Spot 25 sx. WOC & Tag. Morrow Perfs + Morrow top	Y		
2	25	H	11328	11554	226	Spot 25 sx. Atoka Top.	N		
3	25	H	8802	9028	226	Spot 25 sx. Wolfcamp Top	N		
4	25	H	7549	7775	226	Spot 25 sx. Abo Top	N		
5	25	C	5215	5467	252	Perf @ 5467. Attempt inj. Spot 25 sx. Glorieta Top	Y		
6	95	C	3897	4210	313	Perf at 4210'. Attempt Inj. Sqz 95 sx. WOC & Tag. Int. Csg. Shoe & SA	Y		
7	40	C	2618	2750	132	Perf at 2750'. Attempt Inj. Sqz 40 sx. WOC & Tag. Yates Top.	Y		
8	147	C	0	482	482	Perf at 482'. Attempt Inj. Sqz 147sx. WOC & Tag. Verify @ surface. Sur. Csg. Shoe + Surface plug	Y		
PERFORATION DETAIL									
Formation	Top	Bottom	Formation	Top	Bottom				
Morrow	12,175	12,222							
ADDITIONAL DETAIL									
Well swabbed in Aug. '18. Initial fluid level ~5,000', final fluid level ~11,300'									

**CONDITIONS OF APPROVAL
FOR PLUGGING AND ABANDONMENT
OCD - Southern District**

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office I (Hobbs) at **(575)-263-6633** at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

Company representative will be on location during plugging procedures.

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal - commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
8. Produced water will not be used during any part of the plugging operation.
9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
11. Class 'C' cement will be used above 7500 feet.
12. Class 'H' cement will be used below 7500 feet.
13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.
16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.

K) Potash---(In the R-111-P Area (Potash Mine Area),
 A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.

21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing.

DRY HOLE MARKER REQ.UIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

- 1. Operator name
- 2. Lease and Well Number
- 3. API Number
- 4. Unit letter
- 5. Quarter Section (feet from the North, South, East or West)
- 6. Section, Township and Range
- 7. Plugging Date
- 8. County

SPECIAL CASES -----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

District I
 1625 N. French Dr., Hobbs, NM 88240
 Phone:(575) 393-6161 Fax:(575) 393-0720

District II
 811 S. First St., Artesia, NM 88210
 Phone:(575) 748-1283 Fax:(575) 748-9720

District III
 1000 Rio Brazos Rd., Aztec, NM 87410
 Phone:(505) 334-6178 Fax:(505) 334-6170

District IV
 1220 S. St Francis Dr., Santa Fe, NM 87505
 Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico
Energy, Minerals and Natural Resources
Oil Conservation Division
1220 S. St Francis Dr.
Santa Fe, NM 87505

COMMENTS

Action 83093

COMMENTS

Operator: EOG RESOURCES INC P.O. Box 2267 Midland, TX 79702	OGRID: 7377
	Action Number: 83093
	Action Type: [C-103] NOI Plug & Abandon (C-103F)

COMMENTS

Created By	Comment	Comment Date
plmartinez	DATA ENTRY PM	3/14/2022

District I
 1625 N. French Dr., Hobbs, NM 88240
 Phone:(575) 393-6161 Fax:(575) 393-0720
District II
 811 S. First St., Artesia, NM 88210
 Phone:(575) 748-1283 Fax:(575) 748-9720
District III
 1000 Rio Brazos Rd., Aztec, NM 87410
 Phone:(505) 334-6178 Fax:(505) 334-6170
District IV
 1220 S. St Francis Dr., Santa Fe, NM 87505
 Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico
Energy, Minerals and Natural Resources
Oil Conservation Division
1220 S. St Francis Dr.
Santa Fe, NM 87505

CONDITIONS
 Action 83093

CONDITIONS

Operator: EOG RESOURCES INC P.O. Box 2267 Midland, TX 79702	OGRID: 7377
	Action Number: 83093
	Action Type: [C-103] NOI Plug & Abandon (C-103F)

CONDITIONS

Created By	Condition	Condition Date
kfortner	See attached conditions of approval	3/11/2022