
Receiped by Opp Po Appropriate Bistrict 4	Diate of fiew file		Form C-103 of 11
District I – (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240	Energy, Minerals and Natu	ral Resources	Revised July 18, 2013 WELL API NO. 30-025-03781
<u>District II</u> – (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL CONSERVATION		5. Indicate Type of Lease
<u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Fran		STATE FEE
<u>District IV</u> – (505) 476-3460	Santa Fe, NM 87	7505	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM 87505			
	TICES AND REPORTS ON WELLS OSALS TO DRILL OR TO DEEPEN OR PLU		7. Lease Name or Unit Agreement Name
DIFFERENT RESERVOIR. USE "APPL PROPOSALS.)	LICATION FOR PERMIT" (FORM C-101) FO	OR SUCH	LOVINGTON SAN ANDRES UNIT
1. Type of Well: Oil Well	Gas Well  Other INJECTOR	2	8. Well Number 24
2. Name of Operator CHEVRON MIDCONTINENT, I	 L.P.		9. OGRID Number 241333
3. Address of Operator			10. Pool name or Wildcat
6301 Deauville BLVD, Mid	dland TX 79706		[40580] LOVINGTON; GRAYBURG-SAN ANDRES
4. Well Location Unit Letter P	: 660 feet from the SOUTH	l line and 66	0 feet from the EAST line
Section 36	icct from the	nge 36E	NMPM County LEA
Section 30	11. Elevation (Show whether DR,		<i>y</i> ==
12 Charle	Annuantiata Day to Indicata M	fature of Notice	Papart or Other Date
12. Check	Appropriate Box to Indicate N		•
	NTENTION TO:		SEQUENT REPORT OF:
PERFORM REMEDIAL WORK  TEMPORARILY ABANDON		REMEDIAL WOR	
PULL OR ALTER CASING	<del>-</del>	CASING/CEMEN	
DOWNHOLE COMMINGLE			
CLOSED-LOOP SYSTEM	]	OTHER:	
OTHER:  13. Describe proposed or com	npleted operations. (Clearly state all t	OTHER:	d give pertinent dates, including estimated date
of starting any proposed v	work). SEE RULE 19.15.7.14 NMAC		mpletions: Attach wellbore diagram of
proposed completion or re	<u>*</u>		
Move in, rig up lay-dow		ahlish machan	ical barrier at packer set depth.
Pressure test casing to	500 psi for 15 min. Rig dow	n lav-down rig	icai barrier at packer set deptir.
MIRU coiled tubing unit	t. RIH to tag mechanical bar	rier.	•
Spot 23 sacks Class C	cement from 4431' to 4200'.	<u>-</u>	
	cement from 3862' to 3612'. cement from 3272' to 3022'.		
			23'. WOC, tag, pressure test. Bubble test
Perforate & squeeze 87	7 sacks Class C cement fron	n 372' to 0'.	20 : 1. 0 0, tag, p. 000a. 0 tool. 2 azz. 0 tool
Confirm cement returns	s to surface. Rig down coiled	d tubing.	
4" diameter 4' tall	marker	See attached	d conditions of approval
Spud Date:	Rig Release Da		a conditions of approval
I I and a different day of a factor of the second of the s			11.1.6
I hereby certify that the information	n above is true and complete to the be	est of my knowledg	ge and belief.
SIGNATURE Hayes 1	hibodeaux TITLE Engir	neer	<sub>DATE</sub> 5/9/2022
Type or print name Hayes Thik	oodeaux E mail adduca	Hayes.Thibodeaux	x@chevron.com PHONE: 281-726-9683
For State Use Only	c-man address	·	FHORE
APPROVED BY: Yung ? Conditions of Approv	tortherTITLE_	pliance Offer	DATE 6/14/22
Conditions of Approv	Com	tour tou	cac 11

## **Wellbore Diagram**


Created:	04/23/19	Ву:		Well #:	24	St. Lse:	
Updated:		By:		API		30-025-03781	
Lease:	Lovingto	on San Andres	Unit	Unit Ltr.:	Р	Section:	36
Field:		Lovington		TSHP/Rng:		16S-36E	
Surf. Loc.:	660	FSL & 660 FE	L	Unit Ltr.:		Section:	
Bot. Loc.:				TSHP/Rng:		_	
County:	Lea	St.:	NM	Directions:		Lovington, NM	
Status:				Chevno:		FA4928	
				·			



## **Proposed Wellbore Diagram**

Created:	04/23/19	By:		
Updated:		By:		
Lease:	Loving	ton San Andre	s Unit	
Field:		Lovington		
Surf. Loc.:	660 FSL & 660 FEL			
Bot. Loc.:				
County:	Lea	St.:	NM	
Status:				

Well #:	24	St. Lse:	
API		30-025-03781	
Unit Ltr.:	Р	Section:	36
TSHP/Rng:		16S-36E	
Unit Ltr.:		Section:	
TSHP/Rng:			
Directions:		Lovington, NM	
Chevno:		FA4928	



## Plugging Plan – Lovington San Andres Unit #24

API: 30-025-03781

#### Note:

- Injector well with internally lined plastic tubing
- Baker AD-1 packer at 4431'

## Proposed procedure - Lay down rig + CTU

- 1. Move in Axis 34 Lay Down rig package
- 2. N/U BOPE and pressure test same to 250 psi low for 5 minutes / 2500 psi high for 10 minutes.
- 3. Gauge ring run will be required unless the packer is removed from the wellbore
- 4. RIH with CIBP and set at proposed depth in C-103
- 5. Pressure test mech. barrier + casing to 500 psi for 15 minutes. Document results in WellView.
- 6. Conduct bubble tests on all annuli. If bubble test fails, communicate to coiled tubing WSR for planning purposes. Adjust forward plan as necessary to perforate and squeeze any intervals listed below with the approval of NMOCD.
- 7. Rig down Axis 34 lay down rig

## **Proposed procedure - Coiled Tubing Unit**

- 8. R/U coiled tubing P&A package
- 9. N/U BOPE and pressure test same to 250 psi low for 5 minutes / 2500 psi high for 10 minutes.
- 10. RIH with coiled tubing to tag existing mechanical barrier in wellbore
- 11. Spot 25 sacks Class C cement from 4431' to 4200'.
- 12. Spot 25 sacks Class C cement from 3862' to 3612'.
- 13. Spot 25 sacks Class C cement from 3272' to 3022'.
- 14. Perforate & squeeze 117 sacks Class C cement from 2123' to 1623'. WOC, tag, test.
- 15. Conduct 30 minute bubble test after circulating cement into annulus. If bubble test fails, consider additional perf/squeeze attempt then transition to casing cutting & pulling. Discuss forward plan with NMOCD engineer for approval.
  - a. Cut casing will require a stub plug 50' inside of cut casing extending 50' above the cut portion at a minimum. WOC, tag, pressure test barrier. Proceed with approved C-103 if passing bubble test is achieved.
- 16. Perforate & circulate 87 sacks Class C cement from 372' to 0'.
- 17. Confirm cement returns at surface
- 18. Rig down move off location

# CONDITIONS OF APPROVAL FOR PLUGGING AND ABANDONMENT OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office I (Hobbs) at (575)-263-6633 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

## Company representative will be on location during plugging procedures.

- **1.** A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- **2.** Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- **3.** Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- **5.** A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can +be released.
- **6.** If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- **8.** Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- **10.** All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- **13.** A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- **14.** All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.
- **16.** When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- **18.** A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
- A) Fusselman
- B) Devonian
- C) Morrow
- D) Wolfcamp
- E) Bone Springs
- F) Delaware
- G) Any salt sections
- H) Abo
- I) Glorieta
- J) Yates.
- K) Potash---(In the R-111-P Area (Potash Mine Area),

A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.

**21.** If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing.

## DRY HOLE MARKER REQ.UIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

- 1. Operator name
- 2. Lease and Well Number
- 3. API Number
- 4. Unit letter
- 5. Quarter Section (feet from the North, South, East or West)
- 6. Section, Township and Range
- 7. Plugging Date
- 8. County

## SPECIAL CASES ----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

## SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

## Plugging Plan – Lovington San Andres Unit #24

API: 30-025-03781

#### Note:

- Injector well with internally lined plastic tubing
- Baker AD-1 packer at 4431'

## Proposed procedure - Lay down rig + CTU


- 1. Move in Axis 34 Lay Down rig package
- 2. N/U BOPE and pressure test same to 250 psi low for 5 minutes / 2500 psi high for 10 minutes.
- 3. Gauge ring run will be required unless the packer is removed from the wellbore
- 4. RIH with CIBP and set at proposed depth in C-103
- 5. Pressure test mech. barrier + casing to 500 psi for 15 minutes. Document results in WellView.
- 6. Conduct bubble tests on all annuli. If bubble test fails, communicate to coiled tubing WSR for planning purposes. Adjust forward plan as necessary to perforate and squeeze any intervals listed below with the approval of NMOCD.
- 7. Rig down Axis 34 lay down rig

## **Proposed procedure - Coiled Tubing Unit**

- 8. R/U coiled tubing P&A package
- 9. N/U BOPE and pressure test same to 250 psi low for 5 minutes / 2500 psi high for 10 minutes.
- 10. RIH with coiled tubing to tag existing mechanical barrier in wellbore
- 11. Spot 25 sacks Class C cement from 4431' to 4200'.
- 12. Spot 25 sacks Class C cement from 3862' to 3612'.
- 13. Spot 25 sacks Class C cement from 3272' to 3022'.
- 14. Perforate & squeeze 117 sacks Class C cement from 2123' to 1623'. WOC, tag, test.
- 15. Conduct 30 minute bubble test after circulating cement into annulus. If bubble test fails, consider additional perf/squeeze attempt then transition to casing cutting & pulling. Discuss forward plan with NMOCD engineer for approval.
  - a. Cut casing will require a stub plug 50' inside of cut casing extending 50' above the cut portion at a minimum. WOC, tag, pressure test barrier. Proceed with approved C-103 if passing bubble test is achieved.
- 16. Perforate & circulate 87 sacks Class C cement from 372' to 0'.
- 17. Confirm cement returns at surface
- 18. Rig down move off location

## **Wellbore Diagram**

Created:	04/23/19	Ву:	Well #:	24	St. Lse:	
Updated:		By:	API		30-025-03781	
Lease:	Lovingto	n San Andres Unit	Unit Ltr.:	Р	Section:	36
Field:		Lovington	TSHP/Rng:		16S-36E	
Surf. Loc.:	660	FSL & 660 FEL	Unit Ltr.:		Section:	
Bot. Loc.:			TSHP/Rng:			
County:	Lea	St.: NN	Directions:		Lovington, NM	
Status:			 Chevno:		FA4928	
Status:			 Chevno:		FA4928	




1.1

10. \_\_\_\_\_\_\_\_

## **Proposed Wellbore Diagram**

Created:	04/23/19	By:		
Updated:		By:		
Lease:	Loving	ton San Andre	s Unit	
Field:		Lovington		
Surf. Loc.:	660	660 FSL & 660 FEL		
Bot. Loc.:				
County:	Lea	St.:	NM	
Status:		·		

Well #:	24	St. Lse:	
API		30-025-03781	
Unit Ltr.:	Р	Section:	36
TSHP/Rng:		16S-36E	
Unit Ltr.:		Section:	
TSHP/Rng:			
Directions:		Lovington, NM	
Chevno:		FA4928	



District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720 District II

811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720 District III

1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

## **State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505**

COMMENTS

Action 105407

#### **COMMENTS**

Operator:	OGRID:
CHEVRON U S A INC	4323
6301 Deauville Blvd	Action Number:
Midland, TX 79706 105407	
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

#### COMMENTS

Created By	Comment	Comment Date
plmartine	z DATA ENTRY PM	6/14/2022

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

CONDITIONS

Action 105407

## **CONDITIONS**

Operator:	OGRID:
CHEVRON U S A INC	4323
6301 Deauville Blvd	Action Number:
Midland, TX 79706 105407	
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

#### CONDITIONS

Created By		Condition Date
kfortner	See attached COA	6/14/2022