Revised July 18, 2013 NO. 1-025-28565 Type of Lease FE FE & Gas Lease No. 32 Type of Lease FE White White
Type of Lease TE FEE & Gas Lease No. 32 The state of the state
FEE
ame or Unit Agreement Name B mber 1 Number me or Wildcat pper Penn et from theEline
mme or Unit Agreement Name B mber 1 Number me or Wildcat pper Penn et from the
B mber 1 Number me or Wildcat pper Penn et from the line
mber 1 Number me or Wildcat pper Penn et from the Line
Number me or Wildcat pper Penn et from the line
me or Wildcat pper Penn et from the line
pper Penn et from the line
et from the $\underline{}$ line
LEA County
Other Data
REPORT OF:
☐ ALTERING CASING ☐
. P AND A
П
nt dates, including estimated date
tach wellbore diagram of
e ground marker
d conditions of surrous
d conditions of approva
s plug
is plug
circ cement to suface ated to NMOCD standards.
ated to MMOCAL standards.
DATE_ 11/28/2022
h:


Well Bore Diagram Worksheet

Operataor: J&J Services Well Name State NB 1 API #30-025-28565

Location: Sec 14, T13S, R32E: 660 FSL 660 FEL

Date Spud 1/13/1984
Date Complete 3/12/1984

PROPOSED PLUGS



CONDITIONS OF APPROVAL FOR PLUGGING AND ABANDONMENT OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office I (Hobbs) at (575)-263-6633 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

Company representative will be on location during plugging procedures.

- **1.** A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- **2.** Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- **3.** Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- **5.** A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can +be released.
- **6.** If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- **8.** Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- **10.** All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- **13.** A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- **14.** All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.
- **16.** When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- **18.** A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
- A) Fusselman
- B) Devonian
- C) Morrow
- D) Wolfcamp
- E) Bone Springs
- F) Delaware
- G) Any salt sections
- H) Abo
- I) Glorieta
- J) Yates.
- K) Potash---(In the R-111-P Area (Potash Mine Area),

A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.

21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing.

DRY HOLE MARKER REQ.UIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

- 1. Operator name
- 2. Lease and Well Number
- 3. API Number
- 4. Unit letter
- 5. Quarter Section (feet from the North, South, East or West)
- 6. Section, Township and Range
- 7. Plugging Date
- 8. County

SPECIAL CASES ----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION


Ceived by OCP: Appropriate Bistrict: Office	State of flew ivi		Form C-103 ⁵ o
Energy, Minerals and Natural Resources 625 N. French Dr., Hobbs, NM 88240 District II – (575) 748-1283 OH. CONSERNATION DIVISION		V	Revised July 18, 2013 WELL API NO. 30-025-28565
811 S. First St., Artesia, NM 88210 <u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410 <u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM 87505	1220 South St. Francis Dr. Santa Fe, NM 87505		5. Indicate Type of Lease STATE X FEE 5. State Oil & Gas Lease No. LG-1532
SUNDRY NOT (DO NOT USE THIS FORM FOR PROPE	TICES AND REPORTS ON WELLS OSALS TO DRILL OR TO DEEPEN OR PL ICATION FOR PERMIT" (FORM C-101) F	UG BACK TO A OR SUCH	State NB
1. Type of Well: Oil Well X	. Type of Well: Oil Well $\begin{tabular}{ c c c c c }\hline X & Gas Well & \begin{tabular}{ c c c c c c }\hline Other & \begin{tabular}{ c c c c c }\hline \end{array}$		3. Well Number 1
	ervice, Inc.		O. OGRID Number 11095
3. Address of Operator PO Bo Loving	x 324 gton, NM 88260	1	0. Pool name or Wildcat Baum Upper Penn
4. Well Location Unit Letter P Section 14	660 feet from the S Township 13S R 11. Elevation (Show whether DF 4306 GL	U	feet from the E line NMPM LEA County
12. Check	Appropriate Box to Indicate N	Nature of Notice, Re	eport or Other Data
NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING DOWNHOLE COMMINGLE CLOSED-LOOP SYSTEM OTHER:	CHANGE PLANS	SUBSE REMEDIAL WORK COMMENCE DRILL CASING/CEMENT J	
13. Describe proposed or com	ork). SEE RULE 19.15.7.14 NMA completion.	pertinent details, and g	ive pertinent dates, including estimated date letions: Attach wellbore diagram of
Set a CIBP @ 9686' topped with Circulate well with plugging mu Pump 25 sx class H plug @ 8846 Pump 25 sx class H plug @ 7530	35' cement bailed or 25 sx class H p d and test casing 500 psi. ', Plug 2: 8596-8846' to cover top of ', Plug 3: 7820-7530' to cover top of	Wolfcamp Abo	
Pump 25 sx class C plug @ 4098 Perf and squeze 35 sx class C plu Perf and squeeze 35 sx class C p	', Plug 4: 5116-5366' to cover top of ', Plug 5: 3848-4098' to cover 8 5/8" ug @ 2550': Plug 6: 2400-2550' to cover @ 1726': Plug 7: 1600-1726' to cover @ 500': Plug 8: 400' to 500' to cover @ 500': Plug 8: 400' to 500' to cover @ 500': Plug 8: 400' to 500' to cover @ 500': Plug 8: 400' to 500' to cover @ 500': Plug 8: 400' to 500' to cover @ 500': Plug 8: 400' to 500' to cover @ 500': Plug 8: 400' to 500' to cover @ 500' to c	shoe. WOC and tag the ver top of Yates. WOC over top of Salt.	and tag this plug
Pefr and squeeze 35 sx class C p	lug @ 500': Plug 8: 400' to 500' to co lug @ 90': Plug 9: Surface to 90', Wo dry hole marker will be installed an	OC and top off casings.	
Spud Date: 1/13/1984	Rig Release D	ate: 3/12/1984	
hereby certify that the information	above is true and complete to the b	pest of my knowledge a	nd belief.
		nsultant	DATE11/28/2022
SIGNATURE Phelps White	111LE		
Type or print name Phelps White For State Use Only	E-mail addres	ss:pwiv@zianet.com	PHONE: 575 626 7660
APPROVED BY:Conditions of Approval (if any):	TITLE		DATE

Well Bore Diagram Worksheet

Operataor: J&J Services Well Name State NB 1 API #30-025-28565

Location: Sec 14, T13S, R32E: 660 FSL 660 FEL

Date Spud 1/13/1984 Date Complete 3/12/1984




Well Bore Diagram Worksheet

Operataor: J&J Services Well Name State NB 1 API #30-025-28565

Location: Sec 14, T13S, R32E: 660 FSL 660 FEL

Date Spud 1/13/1984 Date Complete 3/12/1984

PROPOSED PLUGS



District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division 1220 S. St Francis Dr. **Santa Fe, NM 87505**

COMMENTS

Action 161969

COMMENTS

	CODID
Operator:	OGRID:
J & J SERVICE INC	11095
P.O. Box 324	Action Number:
Lovington, NM 88260	161969
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

COMMENTS

Created B	Comment	Comment Date
plmartin	DATA ENTRY PM	12/5/2022

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division 1220 S. St Francis Dr. **Santa Fe, NM 87505**

CONDITIONS

Action 161969

CONDITIONS

Operator:	OGRID:
J & J SERVICE INC	11095
P.O. Box 324	Action Number:
Lovington, NM 88260	161969
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

CONDITIONS

Created By		Condition Date
kfortner	See attached COA	12/5/2022