

Submit a Copy To Appropriate District Office
 District I – (575) 393-6161
 1625 N. French Dr., Hobbs, NM 88240
 District II – (575) 748-1283
 811 S. First St., Artesia, NM 88210
 District III – (505) 334-6178
 1000 Rio Brazos Rd., Aztec, NM 87410
 District IV – (505) 476-3460
 1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
 Energy, Minerals and Natural Resources

Form C-103
 Revised July 18, 2013

OIL CONSERVATION DIVISION
 1220 South St. Francis Dr.
 Santa Fe, NM 87505

WELL API NO. 30-015-28905	
5. Indicate Type of Lease STATE ☒ FEE ☐	
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name Todd "2" State	
8. Well Number	4
9. OGRID Number 4323	
10. Pool name or Wildcat Ingle Wells, Delaware	
4. Well Location Unit Letter <u>I</u> : <u>1980</u> feet from the <u>South</u> line and <u>660</u> feet from the <u>East</u> line Section <u>2</u> Township <u>24S</u> Range <u>31E</u> NMPM County <u>Eddy</u>	
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3524' KB (19' AGL)	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator

Chevron U.S.A. Inc.

3. Address of Operator

6301 Deauville Blvd Midland, Texas 79706

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
 TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
 PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
 DOWNHOLE COMMINGLE ☐
 CLOSED-LOOP SYSTEM ☐
 OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
 COMMENCE DRILLING OPNS. ☐ P AND A ☐
 CASING/CEMENT JOB ☐
 OTHER: ☐

Notify OCD 24 hrs. prior to any work done

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Please see attached procedure for well abandonment details.

R-111-P Area

Spud Date:

Rig Release Date:

****SEE ATTACHED COA's****

MUST BE PLUGGED BY 11/30/2023

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Mark Torres TITLE P&A Engineer DATE 5/4/2023

Type or print name Mark Torres E-mail address: marktorres@chevron.com PHONE: 989-264-2525

For State Use Only

APPROVED BY: [Signature] TITLE Staff Manager DATE 5/5/23
 Conditions of Approval (if any):

Todd 2 State #4**API:** 30-015-28905**Fresh Water Depth:** 400'**Potash Area:** Yes**Notes:**

- ACOI – Uneconomic to Return to Production.
- Additional well history available in Wellview and Electronic Well File. Contact engineer for more info.
- WSR to assess crew competency and utilize SWA and contact Superintendent with any concerns.
- Reference [Onshore Operating Guidelines](#) and Business Partner SOPs for detailed guidance.
- If program requires change of scope, do not proceed before contacting an engineer or Superintendent.

Rig Work

1. Prior to rig arrival, verify well prep and confirm if any special or welded flanges are present that will require further intervention.
2. Contact NMOCD at least 24 hours prior to performing any work.
 - a. Place job number in WellView, note the time you contacted the agency and the engineer's name.
3. MIRU pulling unit.
4. Verify pressures and kill well as per [Chevron Global Well Control Document](#).
 - a. Bubble test intermediate and surface casings for 30 minutes each and share results in WellView under daily pressure.
5. N/D tree and N/U BOPE using rubber coated hangers provided by Chevron, and pressure test, 250 psi low and MASP + 500 psi high (per Chevron operating guidelines) for 5 minutes each.
 - a. On a chart, no bleed off allotted.
6. PU and TIH w/ work string and RBP retrieval tool.
 - a. NOTE: MASP 100 psi (killed with 10 ppg brine in July 2022).
 - b. WSR to confirm calculations and that string weight is enough to prevent a pipe light situation while equalizing pressure across RBP prior to releasing.
 - c. If Drill Collars are required to achieve desired string weight, review Drill Collar handling SOP with Rig Contractor. Items to review with personnel include but are not limited to:
 - i. Caliper lifting subs and elevators, record in Elevator change out log.
 - ii. Tightening lifting subs with pipe wrenches and drawing a chalk line across connection to confirm no loosening while making up joints.
7. Circulate out any sand above RBP and circulate well with brine. Contact engineer if unable to establish circulation.
8. Release top RBP as per Business Partner procedure and TOH.
 - a. Prior to beginning operation, review RBP retrieval procedure with all personnel on location and ensure alignment.
 - b. While equalizing across the RBP, stop operations and sting out of RBP if any unexpected pressure is encountered (Previous casing pressure 200 psi). Contact engineer.

- c. Stop work and contact engineer if there is any doubt that the RBP is fully equalized, or not releasing properly prior to continuing procedure.
 - d. If necessary, kill well again as per Chevron Global Well Control Document prior to TOH w/ RBP.
9. TIH and tag bottom RBP at +/- 6,810'.
10. Follow above procedure to release bottom RBP and TOH w/ same.
11. PU fishing tools, TIH and attempt to latch onto 2-3/8" production tubing, release TAC and LD remaining tubing.
 - a. Consult with fishing tool company prior to RU to determine fishing plan.
 - b. If unable to release TAC or retrieve any further tubing, contact engineer and NMOCD office prior to moving forward.
12. MIRU WL unit and pressure test lubricator to 500 psi for 5 min.
13. RIH and set CIBP within 100' of top perf (6,904').
14. RDMO WL.
15. Fill well with fresh water and pressure test casing to 500 psi for 15 minutes.
 - a. Confirm burst pressure of each casing string and ensure the bottomhole pressure during a pressure test does not exceed burst.
 - b. 5% bleed off allotted.
16. Spot 61 sacks Class C cement from 6,904' – 6,304' (perfs, DV tool).
 - a. WOC, tag, pressure test barrier. If pressure test fails, discuss contingency plan with engineer.
 - b. Plug must be at least 50' above DV tool (6,354').
17. Spot MLF to appropriate depth to ensure it is spaced out between plugs.
 - a. Do not pump MLF past the first perforation because it will be pumped away during the P&S procedure. Also, if the casing failed a pressure test, do not spot MLF until it tests properly.
18. Spot 25 sx Class C f/ 5,450' – 5,210' (Isolate Cherry Canyon).
19. Spot 31 sx Class C f/ 4,600' – 4,298' (Delaware, int. csg shoe, Salt Bottom).
 - a. WOC & tag plug.
20. Perf @ 3,900' and circulate approx. 717 sx Class C f/ 3,900' – 1,000'.
 - a. WSR to evaluate pumping plug in stages pending crew competency, equipment limitations, etc. WOC & tag each stage.
 - b. If unable to establish injection/circulation at 3,900', perform CBL on production casing to confirm true TOC in annulus.
21. Perf @ 1,000 and establish circulation up production x intermediate annulus.
22. Conduct bubble test for min. 30 minutes on all casing annuli.
 - a. If bubble test fails, contact engineer to discuss running a CBL to confirm cement quality behind pipe and/or adjusting forward plan for a perforate and squeeze contingency, cement plug or identify any opportunity to cut & pull casing, or R/D and monitor well.
 - b. Ultimate goal is to address failed test prior to fresh water depths.
 - c. Confirm forward plan with engineer and request forward plan approval from the agency.

23. If bubble test passes, proceed to isolate to surface.
 - a. Notify BLM of any proposed changes to cement volumes.
24. Circulate approx. 248 sx Class C cement f/ 1,000' to surface filling production casing and all annuli to surface.
25. While RDMO, perform 30-minute bubble test on surface and production casings. Record results to meet the barrier standard intent.
26. Cut all casings & anchors & remove 3' below grade. Verify cement to surface & weld on dry hole marker (4" diameter, 4' tall). Clean location.

PROPOSED WELLBORE DIAGRAM

FIELD: Carlsbad East
 LEASE/UNIT: Todd "2" State
 WELL NO.: 4
 COUNTY: Eddy ST: New Mexico
 LOCATION: 1980' FSL & 660' FWL, Sec. 2, T-24S, R-31E

API NO.: 30-015-28905
 CHEVNO:
 PROD FORMATION:
 STATUS: SI Oil Well

Spud Date: 5/27/1996
 TD Date: 6/9/1996
 Comp Date: 7/3/1996
 GL: 3,505'
 KB:
 Base of Fresh Water: 400'
R111P: Yes

Surface Casing

Size: 11-3/4"
 Wt., Grd.: 42#
 Depth: 452'
 Sxs Cmt: 420 sx
 Circulate: Yes
 TOC: Surf
 Hole Size: 14-3/4"


Intermediate Casing

Size: 8-5/8"
 Wt., Grd.: 24#
 Depth: 4,398'
 Sxs Cmt: 1470 sx
 Circulate: Yes, 110 sx
 TOC: Surf
 Hole Size: 11"

Production Casing

Size: 5-1/2"
 Wt., Grd.: 15.5#
 Depth: 8,525'
 DV Tool: 6,404'
 Sxs Cmt: 1470 sx
 Circulate: No
 TOC: 3,900' CALC
 Hole Size: 7-7/8"

Formation	Top (MD)
Rustler	777'
Top of Salt	1,100'
Base of Salt	4,490'
Lamar	4,490'
Bell Canyon	4,537'
Cherry Canyon	5,400'
Brushy Canyon	6,639'
Bone Spring	8,328'



Finish Isolating Salt to Surface

5 Perf & Circulate 248 sx Class C f/ 1,000' - 0'

Isolate Salt

4 Perf & Circulate 717 sx Class C f/ 3,900' - 1,000'
****WSR TO EVALUATE PUMPING PLUG IN STAGES****
****WOC & TAG EACH STAGE****

Toc @ 3,900'

Isolate Delaware Mtn Group, Int. Shoe, Base of Salt

3 Spot 71 sx Class C f/ 4,600' - 3,900'
 WOC, tag, pressure test (min. plug length 50' above shoe)

Isolate Cherry Canyon

2 Spot 25 sx Class C f/ 5,450' - 5,210'

= DV Tool @ 6,404'

CIBP @ 6,904'

Isolate Perfs, DV tool

1 Set CIBP within 100' of top perf at 6,904'
 Spot 61 sx Class C f/ 6,904' - 6,304'
 WOC, tag, pressure test (min. 50' above DV tool)

Perf Record:

3 holes: 7,004' - 7,010' (9/28/1996)
 36 Holes: 7,062' - 7,080' (9/28/1996)

40 holes: 8,240' - 8,260' (6/25/1996)

H2S Concentration >100 PPM?
NO
NORM Present in Area? NO

8,525' TD

CURRENT WELLBORE DIAGRAM

FIELD: Carlsbad East API NO.: 30-015-28905 Spud Date: 5/27/1996
 LEASE/UNIT: Todd "2" State CHEVNO: TD Date: 6/9/1996
 WELL NO.: 4 PROD FORMATION: Comp Date: 7/3/1996
 COUNTY: Eddy ST: New Mexico STATUS: SI Oil Well GL: 3,505'
 LOCATION: 1980' FSL & 660' FWL, Sec. 2, T-24S, R-31E KB:

Base of Fresh Water: 400'

R11P/SOPA: No/Yes

Surface Casing

Size: 11-3/4"
 Wt., Grd.: 42#
 Depth: 452'
 Sxs Cmt: 420 sx
 Circulate: Yes
 TOC: Surf
 Hole Size: 14-3/4"


Intermediate Casing

Size: 8-5/8"
 Wt., Grd.: 24#
 Depth: 4,398'
 Sxs Cmt: 1470 sx
 Circulate: Yes, 110 sx
 TOC: Surf
 Hole Size: 11"

Production Casing

Size: 5-1/2"
 Wt., Grd.: 15.5#
 Depth: 8,525'
 DV Tool: 6,404'
 Sxs Cmt: 1470 sx
 Circulate: No
 TOC: 3,900' CALC
 Hole Size: 7-7/8"

Formation	Top (MD)
Rustler	777'
Top of Salt	1,100'
Base of Salt	4,490'
Lamar	4,490'
Bell Canyon	4,537'
Cherry Canyon	5,400'
Brushy Canyon	6,639'
Bone Spring	8,328'



RBP @ 2,000'

Toc @ 3,900'

= DV Tool @ 6,404'

RBP @ 6,810'

Tbg stuck, jet cut at 6,885' (frac protect 7/2/2022)

Perf Record:

3 holes: 7,004' - 7,010' (9/28/1996)
 36 Holes: 7,062' - 7,080' (9/28/1996)

40 holes: 8,240' - 8,260' (6/25/1996)

H2S Concentration >100 PPM?
NO
NORM Present in Area? NO

8,525' TD

CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
8. Produced water **will not** be used during any part of the plugging operation.
9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
11. Class 'C' cement will be used above 7500 feet.
12. Class 'H' cement will be used below 7500 feet.
13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Cherry Canyon - Eddy County
 - L) Potash---(In the R-111-P Area (Page 3 & 4), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIREMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

R-111-P Area

T 18S – R 30E

Sec 10 Unit P. Sec 11 Unit M,N. Sec 13 Unit L,M,N. Sec 14 Unit C -P. Sec 15 Unit A G,H,I,J,K,N,O,P. Sec 22 Unit All except for M. Sec 23, Sec 24 Unit C,D,E,L, Sec 26 Unit A-G, Sec 27 Unit A,B,C

T 19S – R 29E

Sec 11 Unit P. Sec 12 Unit H-P. Sec 13. Sec 14 Unit A,B,F-P. Sec 15 Unit P. Sec 22 Unit A,B,C,F,G,H,I,J K,N,O,P. Sec 23. Sec 24. Sec 25 Unit D. Sec 26 Unit A- F. Sec 27 Unit A,B,C,F,G,H.

T 19S – R 30E

Sec 2 Unit K,L,M,N. Sec 3 Unit I,L,M,N,O,P. Sec 4 Unit C,D,E,F,G,I-P. Sec 5 Unit A,B,C,E-P. Sec 6 Unit I,O,P. Sec 7 – Sec 10. Sec 11 Unit D, G—P. Sec 12 Unit A,B,E-P. Sec 13 Unit A-O. Sec 14-Sec 18. Sec 19 Unit A-L, P. Sec 20 – Sec 23. Sec 24 Unit C,D,E,F,L,M,N. Sec 25 Unit D. Sec 26 Unit A-G, I-P. Sec 27, Sec 28, Sec 29 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 32 Unit A,B,G,H,I,J,N,O,P. Sec 33. Sec 34. Sec 35. Sec 36 Unit D,E,F,I-P.

T 19S – R 31E

Sec 7 Unit C,D,E,F,L. Sec 18 Unit C,D,E,F,G,K,L. Sec 31 Unit M. Sec 34 Unit P. Sec 35 Unit M,N,O. Sec 36 Unit O,P.

T 20S – R 29E

Sec 1 Unit H,I,P. Sec 13 Unit E,L,M,N. Sec 14 Unit B-P. Sec 15 Unit A,H,I,J,N,O,P. Sec 22 Unit A,B,C,F,G,H,I,J,O,P. Sec 23. Sec 24 Unit C,D,E,F,G,J-P. Sec 25 Unit A-O. Sec 26. Sec 27 Unit A,B,G,H,I,J,O,P. Sec 34 Unit A,B,G,H. Sec 35 Unit A-H. Sec 36 Unit B-G.

T 20S – R 30E

Sec 1 – Sec 4. Sec 5 Unit A,B,C,E-P. Sec 6 Unit E,G-P. Sec 7 Unit A-H,I,J,O,P. Sec 8 – 17. Sec 18 Unit A,B,G,H,I,J,O,P. Sec 19 Unit A,B,G,H,I,J,O,P. Sec 20 – 29. Sec 30 Unit A-L,N,O,P. Sec 31 Unit A,B,G,H,I,P. Sec 32 – Sec 36.

T 20S – R 31E

Sec 1 Unit A,B,C,E-P. Sec 2. Sec 3 Unit A,B,G,H,I,J,O,P. Sec 6 Unit D,E,F,J-P. Sec 7. Sec 8 Unit E-P. Sec 9 Unit E,F,J-P. Sec 10 Unit A,B,G-P. Sec 11 – Sec 36.

T 21S – R 29E

Sec 1 – Sec 3. Sec 4 Unit L1 – L16,I,J,K,O,P. Sec 5 Unit L1. Sec 10 Unit A,B,H,P. Sec 11 – Sec 14. Sec 15 Unit A,H,I. Sec 23 Unit A,B. Sec 24 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 25 Unit A,O,P. Sec 35 Unit G,H,I,J,K,N,O,P. Sec 36 A,B,C,F – P.

T 21S – R 30E

Sec 1 – Sec 36

T 21S – R 31E

Sec 1 – Sec 36

T 22S – R 28E

Sec 36 Unit A,H,I,P.

T 22S – R 29E

Sec 1. Sec2. Sec 3 Unit I,J,N,O,P. Sec 9 Unit G – P. Sec 10 – Sec 16. Sec 19 Unit H,I,J. Sec 20 – Sec 28. Sec 29 Unit A,B,C,D,G,H,I,J,O,P. Sec 30 Unit A. Section 31 Unit C – P. Sec 32 – Sec 36

T 22S – R 30E

Sec 1 – Sec 36

T 22S – R 31E

Sec 1 – Sec 11. Sec 12 Unit B,C,D,E,F,L. Sec 13 Unit E,F,K,L,M,N. Sec 14 – Sec 23. Sec 24 Unit C,D,E,F,K,L,M,N. Sec 25 Unit A,B,C,D. Sec 26 Unit A,BC,D,G,H. Sec 27 – Sec 34.

T 23S – R 28E

Sec 1 Unit A

T 23S – R 29E

Sec 1 – Sec 5. Sec 6 Unit A – I, N,O,P. Sec 7 Unit A,B,C,G,H,I,P. Sec 8 Unit A – L, N,O,P. Sec 9 – Sec 16. Sec 17 Unit A,B,G,H,I,P. Sec 21 – Sec 23. Sec 24 Unit A – N. Sec 25 Unit D,E,L. Sec 26. Sec 27. Sec 28 Unit A – J, N,O,P. Sec 33 Unit A,B,C. Sec 34 Unit A,B,C,D,F,G,H. Sec 35. Sec 36 Unit B,C,D,E,F,G,K,L.

T 23S – R 30E

Sec 1 – Sec 18. Sec 19 Unit A – I,N,O,P. Sec 20, Sec 21. Sec 22 Unit A – N, P. Sec 23, Sec 24, Sec 25. Sec 26 Unit A,B,F-P. Sec 27 Unit C,D,E,I,N,O,P. Sec 28 Unit A – H, K,L,M,N. Sec 29 Unit A – J, O,P. Sec 30 Unit A,B. Sec 32 A,B. Sec 33 Unit C,D,H,I,O,P. Sec 34, Sec 35, Sec 36.

T 23S – R 31E

Sec 2 Unit D,E,J,O. Sec 3 – Sec 7. Sec 8 Unit A – G, K – N. Sec 9 Unit A,B,C,D. Sec 10 Unit D,P. Sec 11 Unit G,H,I,J,M,N,O,P. Sec 12 Unit E,L,K,M,N. Sec 13 Unit C,D,E,F,G,J,K,L,M,N,O. Sec 14. Sec 15 Unit A,B,E – P. Sec 16 Unit I, K – P. Sec 17 Unit B,C,D,E, I – P. Sec 18 – Sec 23. Sec 24 Unit B – G, K,L,M,N. Sec 25 Unit B – G, J,K,L. Sec 26 – Sec 34. Sec 35 Unit C,D,E.

T 24S – R 29E

Sec 2 Unit A, B, C, D. Sec 3 Unit A

T 24S – R 30E

Sec 1 Unit A – H, J – N. Sec 2, Sec 3. Sec 4 Unit A,B,F – K, M,N,O,P. Sec 9 Unit A – L. Sec 10 Unit A – L, O,P. Sec 11. Sec 12 Unit D,E,L. Sec 14 Unit B – G. Sec 15 Unit A,B,G,H.

T 24S – R 31E

Sec 3 Unit B – G, J – O. Sec 4. Sec 5 Unit A – L, P. Sec 6 Unit A – L. Sec 9 Unit A – J, O,P. Sec 10 Unit B – G, K – N. Sec 35 Unit E – P. Sec 36 Unit E,K,L,M,N.

T 25S – R 31E

Sec 1 Unit C,D,E,F. Sec 2 Unit A – H.

District I
1625 N. French Dr., Hobbs, NM 88240
Phone:(575) 393-6161 Fax:(575) 393-0720
District II
811 S. First St., Artesia, NM 88210
Phone:(575) 748-1283 Fax:(575) 748-9720
District III
1000 Rio Brazos Rd., Aztec, NM 87410
Phone:(505) 334-6178 Fax:(505) 334-6170
District IV
1220 S. St Francis Dr., Santa Fe, NM 87505
Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico
Energy, Minerals and Natural Resources
Oil Conservation Division
1220 S. St Francis Dr.
Santa Fe, NM 87505

CONDITIONS

Action 213436

CONDITIONS

Operator: CHEVRON U S A INC 6301 Deauville Blvd Midland, TX 79706	OGRID: 4323
	Action Number: 213436
	Action Type: [C-103] NOI Plug & Abandon (C-103F)

CONDITIONS

Created By	Condition	Condition Date
gcordero	None	5/5/2023