NO

YES

<u>DEGGEORE</u>X South District-Artesia

YES

State of New Mexico Energy, Minerals and Natural Resources Department Oil Conservation Division Price District Office

BRADENHEAD TEST REPORT API Number Operator Name Property Name ¹ Surface Location Feet from N/S Line E/W Line Township Feet From Range Section Well Status INJECTOR TA'D WELL SHUT-IN PRODUCER

SWD

OIL

GAS

OBSERVED DATA

NO

INJ

y i reng gan dingan di annan , na mga mgi m. I Bar (Bar) ani, ti nang prasentili di mgi agan tersariti di Alban	(A)Surface	(B)Interm(1)	(C)Interm(2)	(D)Prod Csng	(E)Tuhing
Pressure	0	/	/		380
Flow Characteristics		/			
Puff	Y/N	Y / N	YIN	Y) N	CO2
Steady Flow	Y / (5)	YIN	Y/N	YN	WTR GAS
Surges	YIN	y/ N	Y / N	YZN	Type of Flats
Down to nothing	Y) N	Y/N	Y / N	(Y) N	Injected for Waterfland I
Gas or Oil	Y / (N)	YIN	Y/N	YO	applies
Water	Y(N)	Y / N	Y/N	Y	

Remarks - Please state for each string (A,B,C,D,E) pertinent information regarding bleed down or continuous build up if applies.

Signature:	OIL CONSERVATION DIVISION
Printed name:	Entered into RBDMS
Title.	Re-test
E-mail Address:	
Date: Phone:	MARINET DE LE CENTRA DE PARTICIPA DE LA CONTRA DEL CONTRA DE LA CONTRA DEL CONTRA DE LA CONTRA DEL CONTRA DE LA CONTRA DE
Witness:	A CONTROL OF THE PROPERTY OF T

INSTRUCTIONS ON BACK OF THIS FORM

PERFORMING BRADENHEAD TEST

General Procedure for Bradenhead Test

Identify:

All valves prior to testing

Gauges:

Install on each casing string to record pressure.

Assure:

That all valves are in good working condition and closed at least 24 hours prior

to testing.

Open:

Each valve (Bradenhead, intermediate and casing valves) is to be opened

separately.

Check Gauges:

Record pressure on each gauge and casing string on BHT form. Open

valves to atmosphere and record results on BHT form.

Designate what applies to the result of opening the valves for each string:

Blow or Puff
Bled down to Nothing
Steady Flow
Oil or Gas
Water
Yes or No
Yes or No
Yes or No
Yes or No

Start: Injection or SWD pump so tubing pressure can be read.

In case of pressure:

- 1. Record pressure reading on gauge.
- 2. Bleed and note time elapsed to bleed down.
- 3. Leave valve open for additional observation.
- 4. Note any fluids expelled.

In absence of Pressure:

- 1. Leave valve open for additional observation.
- 2. Note types of fluids expelled.
- 3. Note if fluids persist throughout test.

Note: Tubing pressure on injection or SWD wells.

Test will be signed by person performing test with a contact phone number.

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division 1220 S. St Francis Dr. **Santa Fe, NM 87505**

CONDITIONS

Action 289044

CONDITIONS

Operator:	OGRID:
BXP Operating, LLC	329487
11757 KATY FREEWAY	Action Number:
HOUSTON, TX 77079	289044
	Action Type:
	[UF-BHT] Bradenhead Test (BRADENHEAD TEST)

CONDITIONS

Created By		Condition Date
kfortner	None	12/4/2023