

Santa Fe Main Office  
Phone: (505) 476-3441  
General Information  
Phone: (505) 629-6116

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised July 18, 2013

Online Phone Directory Visit:  
<https://www.emnrd.nm.gov/oed/contact-us/>

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

WELL API NO. 30-015-26134
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Resler Yates State
8. Well Number #381
9. OGRID Number 154329
10. Pool name or Wildcat (3230) Artesia; Queen-Grayburg-San Andres

<p><b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)</p>	
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>	
2. Name of Operator Sandlott Energy (Jackie Brewer DBA)	
3. Address of Operator P.O. Box 711 Lovington, NM 88260	
4. Well Location Unit Letter <u>G</u> : <u>1884</u> feet from the <u>North</u> line and <u>1394</u> feet from the <u>East</u> line Section <u>32</u> Township <u>18S</u> Range <u>28E</u> NMPM Eddy County	
11. Elevation (Show whether DR, RKB, RT, GR, etc.)	

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	P AND A <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPL <input type="checkbox"/>	CASING/CEMENT JOB <input type="checkbox"/>	
DOWNHOLE COMMINGLE <input type="checkbox"/>			
CLOSED-LOOP SYSTEM <input type="checkbox"/>			
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Please see attached procedure & wellbore schematics

Spud Date:

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE J. Brewer TITLE \_\_\_\_\_ DATE 11/2/2025

Type or print name \_\_\_\_\_ E-mail address: \_\_\_\_\_ PHONE: \_\_\_\_\_

**For State Use Only**

APPROVED BY: \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

Conditions of Approval (if any):

*Newbourne Oil Company***Plug and Abandon**

Submitted By: C. Casey

**Wellname:** RESLER YATES STATE #381**Location:** 1884' FNL & 1394' FEL, Sec. G-32-18S-28E - Eddy  
Co, NM**Date:** August 7, 2025**API #:** 30-015-26134**Surf Csg Set:** 10 3/4" 40.5# J-55**Csg Size:** 7" 20# J-55**Set @:** 400'**Set @:** 2099'**Inter #1:** \_\_\_\_\_**Perfs:** 2021'-2023' (21 shots)**Set @:** \_\_\_\_\_

Well is to be plugged &amp; abandoned.

**Procedure:**

1. MIRU plugging crew.
2. ND WH, NU BOP.
3. MIRU WL
4. RIH w/WL & CIBP to 2000' (top Upper GrayBurg 2020' top perf @ 2021')
5. Pressure test csg to 500# for 15min
6. POOH w/WL
7. RIH w/WL & CBL
8. Run CBL and verify top of cements
9. RIH w/tbg & circulate MLF to surface
10. Spot 40 sks Class C neat cmt (537' ±) on top of CIBP.
11. WOC 6 hrs & tag plug @ 1513' or higher (top of queens 1563')
12. POOH w/tbg.
13. RIH w/wireline & perforate 7" csg @ 450' and circulate MLF
14. Circulate cmt to surface (approximately 70 sks required).
15. WOC & confirm that wellbore remains full.
16. Cut off WH & install dry hole marker. Cut off anchors & clean location.

# RESLER YATES STATE #381 P&A Schematic

1884' FNL & 1394' FEL, Sec. G-32-18S-28E- Eddy Co, NM  
API 30-015-26134

14 3/4" hole w/ 10 3/4" 40.5#  
J55 set @ 400'

TOC: Surface

9 7/8" hole w/ 7" 20# J55 set  
@ 2099'

TOC: 846'

Queen top @ 1563'

GrayBurg top @ 2020'




GrayBurg perfs @  
2021'-2033' (2 SPF)

## RESLER YATES STATE #381 P&amp;A Schematic

1884' FNL &amp; 1394' FEL, Sec. G-32-18S-28E- Eddy Co, NM

API 30-015-26134



Sante Fe Main Office  
Phone: (505) 476-3441

General Information  
Phone: (505) 629-6116

Online Phone Directory  
<https://www.emnrd.nm.gov/ocd/contact-us>

**State of New Mexico**  
**Energy, Minerals and Natural Resources**  
**Oil Conservation Division**  
**1220 S. St Francis Dr.**  
**Santa Fe, NM 87505**

CONDITIONS

Action 524502

**CONDITIONS**

Operator: MEWBOURNE OIL CO P.O. Box 5270 Hobbs, NM 88241	OGRID: 14744
	Action Number: 524502
	Action Type: [C-103] NOI Plug & Abandon (C-103F)

**CONDITIONS**

Created By	Condition	Condition Date
loren.diede	Notify the OCD inspection supervisor via email 24 hours prior to beginning Plug & Abandon (P&A) operations.	11/14/2025
loren.diede	NMOCD does not consider this well to be within the LPCH restricted area and an above ground P&A marker is required. NMOCD requires that plug(s) be added to cover the 7 Rivers = (962') and Yates = (608') formation tops. Submit photo and GPS coordinates of the P&A marker with the final P&A reports. The API# on the marker is to be clearly legible. Run CBL from CIBP to surface. Submit the CBL tif file to NMOCD for uploading into the Well Log File.	11/14/2025