

1R - 427-02

# WORKPLANS

Date:

3-25-13

# Rice Environmental Consulting & Safety

P.O. Box 5630 Hobbs, NM 88241

Phone 575.393.4411 Fax 575.393.0293

CERTIFIED MAIL

RETURN RECEIPT NO. 7008 1140 0001 3072 4604

RECEIVED

March 25<sup>th</sup>, 2013

MAR 27 2013

17

**Mr. Edward Hansen**

New Mexico Energy, Minerals, & Natural Resources

Oil Conservation Division, Environmental Bureau

1220 S. St. Francis Drive

Santa Fe, New Mexico 87505

Oil Conservation Division  
1220 S. St. Francis Drive  
Santa Fe, NM 87505

**RE: Investigation and Characterization Plan  
Rice Operating Company – EME SWD System  
EME H-10 (1R427-02): UL/H sec. 10 T20S R36E**

Mr. Hansen:

RICE Operating Company (ROC) has retained Rice Environmental Consulting and Safety (RECS) to address potential environmental concerns at the above-referenced site in the EME Salt Water Disposal (SWD) system. ROC is the service provider (agent) for the EME SWD System and has no ownership of any portion of the pipeline, well, or facility. The system is owned by a consortium of oil producers, System Parties, who provide all operating capital on a percentage ownership/usage basis.

For all such environmental projects, ROC will choose the path forward that:

- Protects public health,
- Provides the greatest net environmental benefit,
- Complies with NMOCD Rules, and
- Is supported by good science.

Each site shall generally have three submissions:

1. This Investigation and Characterization Plan (ICP) is proposed for gathering data and site characterization and assessment.
2. Upon evaluating the data and results from the ICP, a recommended remedy will be submitted in a Corrective Action Plan (CAP), if warranted.
3. Finally, after implementing the remedy, a Termination Request with final documentation will be submitted.

## **Background and Previous Work**

The site is located approximately 4.8 miles southwest of Monument, New Mexico at UL/H sec. 10 T20S R36E as shown on the Site Location Map (Figure 1). An updated

study of NM OSE records, conducted in 2013, indicates that groundwater will likely be encountered at a depth of approximately 34 +/- feet.

In 2003, ROC initiated work on the former EME H-10 junction box. The site was delineated using a backhoe to form a 24 ft x 11 ft x 16 ft deep excavation and soil samples were screened at regular intervals for chlorides. From the excavation, the four-wall composite, the bottom composite, and the remediated backfill were taken to a commercial laboratory for analysis. Laboratory tests of the four-wall composite showed a chloride reading of 88.6 mg/kg and a gasoline range organics (GRO) and diesel range organics (DRO) reading of non-detect. The bottom composite showed a chloride laboratory reading of 677 mg/kg and a GRO and DRO reading of non-detect. The remediated backfill showed a chloride laboratory reading of 106 mg/kg, a GRO reading of non-detect and a DRO reading of 65.7 mg/kg. BTEX readings for all three samples were non-detect. A one-foot thick, compacted clay layer was installed at the base of the excavation and the site was backfilled with the remediated soil. The area was contoured to the surrounding landscape since a junction box is no longer necessary at the site. NMOCD was notified of potential groundwater impact on February 24<sup>th</sup>, 2003 and a junction box disclosure report (Appendix A) was submitted to NMOCD with all the 2003 junction box closures and disclosures.

ROC proposes additional investigative work at the site to determine if there is potential for groundwater degradation from residual chlorides at the site.


### **Proposed Work Elements**

1. Conduct vertical and lateral delineation of residual chlorides and hydrocarbons from samples taken using a drill rig, hand auger and/or backhoe (see Appendix B for Quality Procedures).
  - a. Vertical sampling will be conducted until the following criteria are met in the field.
    - i. Three samples in which the chloride concentration decreases and the third sample has a chloride concentration of  $\leq 250$  ppm; and,
    - ii. Three samples in which PID readings decrease and the third sample has a PID reading of  $\leq 100$  ppm; or,
    - iii. The sampling reaches the capillary fringe.
  - b. Lateral sampling will be conducted until the following criteria are met in the field.
    - i. A decrease is observed in chloride concentrations between lateral bores at similar depths; and,
    - ii. A chloride concentration of  $\leq 250$  ppm is observed in a lateral surface sample; or,
    - iii. Safety concerns impede further lateral delineation
2. If warranted, install a monitor well to provide direct measurement of the potential groundwater impact at the site. (All monitor wells will be installed by EPA, NMOCD, and industry standards.)
3. Evaluate the risk of groundwater impact based on the information obtained.

If the evaluation of the site shows no threat to groundwater from residual chlorides, then only a vadose zone remedy will be undertaken. However, if groundwater shows impact from residual chlorides, a CAP will be developed to address these concerns.

RECS appreciates the opportunity to work with you on this project. Please call Hack Conder at (575) 393-9174 or me if you have any questions or wish to discuss the site.

Sincerely,



Lara Weinheimer  
Project Scientist  
RECS  
(575) 441-0431

Attachments:

- Figure 1 – Site Location Map
- Appendix A – Junction Box Disclosure Report
- Appendix B – Quality Procedures

RECEIVED OOD  
2017 MAR 27 P 2:19



# Figures

**RICE Environmental Consulting and Safety (RECS)**  
P.O. Box 5630 Hobbs, NM 88241  
Phone 575.393.4411 Fax 575.393.0293



# Site Location Map



## ***EME H-10***

Legals: UL/H sec. 10  
T-20-S R-36-E  
LEA COUNTY, NM  
NMOCD CASE #: 1R427-02

Figure 1



0 0.275 0.55 1.1  
Miles

Drawing date: 2-27-13  
Drafted by: LS

# Appendix A

## Junction Box Disclosure Report

**RICE Environmental Consulting and Safety (RECS)**

P.O. Box 5630 Hobbs, NM 88241  
Phone 575.393.4411 Fax 575.393.0293

**RICE OPERATING COMPANY  
JUNCTION BOX DISCLOSURE REPORT**

**BOX LOCATION**

SWD SYSTEM	JUNCTION	UNIT	SECTION	TOWNSHIP	RANGE	COUNTY	BOX DIMENSIONS - FEET		
EME	H-10	H	10	20S	36E	Lea	Length	Width	Depth
							No Box		

LAND TYPE: BLM \_\_\_\_\_ STATE \_\_\_\_\_ FEE LANDOWNER George & Harry Klein OTHER \_\_\_\_\_

Depth to Groundwater 31 feet NMOC SITE ASSESSMENT RANKING SCORE: 20

Date Started 1/29/2003 Date Completed 2/27/2003 OCD Witness No

Soil Excavated 156 cubic yards Excavation Length 24 Width 11 Depth 16 feet

Soil Disposed 0 cubic yards Offsite Facility n/a Location n/a

**FINAL ANALYTICAL RESULTS:** Sample Date 2/10/2003 Sample Depth 16'

Procure 5-point composite sample of bottom and 4-point composite sample of sidewalls. TPH, BTEX and Chloride laboratory test results completed by using an approved lab and testing procedures pursuant to NMOC guidelines.

Sample Location	Benzene mg/kg	Toluene mg/kg	Ethyl Benzene mg/kg	Total Xylenes mg/kg	GRO mg/kg	DRO mg/kg	Chlorides mg/kg
SIDEWALLS	<0.025	<0.025	<0.025	<0.025	<10.0	<10.0	88.6
BOTTOM	<0.025	<0.025	<0.025	<0.025	<10.0	<10.0	67.7
REMEDIED	<0.025	<0.025	<0.025	<0.025	<10.0	65.7	106

**General Description of Remedial Action:** A 24' x 11' area was excavated to 16' bgs

with a slope on the north side. TPH concentrations met OCD guidelines at 16', however,

chloride impact only declined somewhat with depth. Sidewalls were clean with respect to TPH

and chloride impact so a 1' compacted clay barrier was installed at the bottom to slow vertical

chloride migration. The excavation was backfilled with the excavated soil that was remediated

on-site and contoured to the surrounding area. This site is no longer a junction so a box is

not required. Remaining TPH is expected to naturally attenuate. This site will be re-seeded

with native vegetation and will be monitored for growth.

cc: photos, lab results, diagrams.

**CHLORIDE FIELD TESTS**

LOCATION	DEPTH (ft)	ppm
Vertical	4	1223
	8	399
	12	552
12' S	12	458
6'W	12	432
5'E	12	577
8'N	12	690
Wall Comp.	10'	170
Bottom Comp.	16'	800

**I HEREBY CERTIFY THAT THE INFORMATION ABOVE IS TRUE AND COMPLETE TO THE BEST OF MY KNOWLEDGE AND BELIEF.**

DATE 3/10/2003

PRINTED NAME Kristin Farris


SIGNATURE Kristin Farris


TITLE Projects Scientist




EME jct. H-10  
Impact Excavation



 = area to be re-seeded



steel  
flow  
lines



SLOPE  
TO  
SURFACE


new 2"  
poly line  
at 4' bgs

center of  
old box

16' BGS


R  
O  
A  
D

VEGETATION



**EME jct. H-10**  
**Impact Excavation**  
**Cross-Section**

1" = 2 FT



## EME jct H-10



Impact Excavation



Clay Barrier @ 16' bgs



Remediated & Backfilled (looking west)

# CHLORIDE CONCENTRATION CURVE


RICE Operating Company

EME jct. H-10

T20S, R36E

Depth bgs (ft)	[Cl-] ppm
4	1223
6	241
8	299
10	402
12	552

Groundwater = 31 ft



## ANALYTICAL REPORT

**Prepared for:**

Kristin Farris  
Rice Operating  
122 W. Taylor  
Hobbs, NM 88240

*Remediated*

Project: Jct. H-10  
PO#: 749  
Order#: G0305836  
Report Date: 03/05/2003

**Certificates:**

US EPA Laboratory Code TX00158

---

## ENVIRONMENTAL LAB OF TEXAS

### SAMPLE WORK LIST

Rice Operating  
122 W. Taylor  
Hobbs, NM 88240  
505-397-1471

Order#: G0305836  
Project:  
Project Name: Jct. H-10  
Location: EME

The samples listed below were submitted to Environmental Lab of Texas and were received under chain of custody. Environmental Lab of Texas makes no representation or certification as to the method of sample collection, sample identification, or transportation/handling procedures used prior to the receipt of samples by Environmental Lab of Texas, unless otherwise noted.

<u>Lab ID:</u>	<u>Sample :</u>	<u>Matrix:</u>	<u>Date / Time</u> <u>Collected</u>	<u>Date / Time</u> <u>Received</u>	<u>Container</u>	<u>Preservative</u>
0305836-01	Remed. Comp.	SOIL	2/26/03	2/27/03 19:36	4 oz glass	Ice
<u>Lab Testing:</u>		Rejected: No	Temp: -2°C			
8015M						
8021B/5030 BTEX						
Chloride:						

---



# ENVIRONMENTAL LAB OF TEXAS

## ANALYTICAL REPORT

Kristin Farris  
Rice Operating  
122 W. Taylor  
Hobbs, NM 88240

Order#: G0305836  
Project:  
Project Name: Jct. H-10  
Location: EME

Lab ID: 0305836-01  
Sample ID: Remed. Comp.

**8015M**

Method	Date	Date	Sample	Dilution	Analyst	Method
Blank	Prepared	Analyzed	Amount	Factor		
		2/28/03	1	1	CK	8015M

Parameter	Result mg/kg	RL
GRO, C6-C12	<10.0	10.0
DRO, >C12-C35	65.7	10.0
TOTAL, C6-C35	65.7	10.0

Surrogates	% Recovered	QC Limits (%)	
1-Chlorooctane	106%	70	130
1-Chlorooctadecane	98%	70	130

**8021B/5030 BTEX**

Method	Date	Date	Sample	Dilution	Analyst	Method
Blank	Prepared	Analyzed	Amount	Factor		
0004839-02		3/4/03 12:00	1	25	CK	8021B

Parameter	Result mg/kg	RL
Benzene	<0.025	0.025
Toluene	<0.025	0.025
Ethylbenzene	<0.025	0.025
p/m-Xylene	<0.025	0.025
o-Xylene	<0.025	0.025

Surrogates	% Recovered	QC Limits (%)	
aaa-Toluene	90%	80	120
Bromofluorobenzene	95%	80	120

Approval:

Roland K. Tuttle, Lab Director, QA Officer  
Celey D. Keene, Org. Tech. Director  
Jeanne McMurrey, Inorg. Tech. Director  
Sandra Biezugbe, Lab Tech.  
Sara Molina, Lab Tech.

Date

DL = Diluted out N/A = Not Applicable RL = Reporting Limit

Page 1 of 1

# ENVIRONMENTAL LAB OF TEXAS

## ANALYTICAL REPORT

Kristin Farris  
Rice Operating  
122 W. Taylor  
Hobbs, NM 88240

Order#: G0305836  
Project:  
Project Name: Jct. H-10  
Location: EME

Lab ID: 0305836-01  
Sample ID: Remed. Comp.

### Test Parameters

Parameter	Result	Units	Dilution Factor	RL	Method	Date Analyzed	Analyst
Chloride	106	mg/kg	1	20	9253	3/3/03	SB

Approval:

*Coley D. Keene* 3/5/03  
Raland K. Tuttle, Lab Director, QA Officer  
Coley D. Keene, Org. Tech. Director  
Jeanne McMurrey, Inorg. Tech. Director  
Sandra Biezugbe, Lab Tech.  
Sara Molina, Lab Tech.

Date

RL = Reporting Limit N/A = Not Applicable

Page 1 of 1

ENVIRONMENTAL LAB OF TEXAS, LTD. 12600 West I-20 East, Odessa, TX 79765 Ph: 915-563-1800

# ENVIRONMENTAL LAB OF TEXAS

## QUALITY CONTROL REPORT

8015M

Order#: G0305836

<b>BLANK</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
TOTAL, C6-C35-mg/kg		0004808-02			<10.0		
<b>MS</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
TOTAL, C6-C35-mg/kg		0305835-01	0	952	875	91.9%	
<b>MSD</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
TOTAL, C6-C35-mg/kg		0305835-01	0	952	809	85%	7.8%
<b>SRM</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
TOTAL, C6-C35-mg/kg		0004808-05		1000	822	82.2%	

# ENVIRONMENTAL LAB OF TEXAS

## QUALITY CONTROL REPORT

8021B/5030 BTEX

Order#: G0305836

<b>BLANK</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Benzene-mg/kg		0004839-02			<0.025		
Toluene-mg/kg		0004839-02			<0.025		
Ethylbenzene-mg/kg		0004839-02			<0.025		
p/m-Xylene-mg/kg		0004839-02			<0.025		
o-Xylene-mg/kg		0004839-02			<0.025		
<b>MS</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Benzene-mg/kg		0305835-02	0	0.1	0.097	97.0%	
Toluene-mg/kg		0305835-02	0	0.1	0.100	100.0%	
Ethylbenzene-mg/kg		0305835-02	0	0.1	0.102	102.0%	
p/m-Xylene-mg/kg		0305835-02	0	0.2	0.210	105.0%	
o-Xylene-mg/kg		0305835-02	0	0.1	0.103	103.0%	
<b>MSD</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Benzene-mg/kg		0305835-02	0	0.1	0.098	98.0%	1.0%
Toluene-mg/kg		0305835-02	0	0.1	0.100	100.0%	0.0%
Ethylbenzene-mg/kg		0305835-02	0	0.1	0.101	101.0%	1.0%
p/m-Xylene-mg/kg		0305835-02	0	0.2	0.208	104.0%	1.0%
o-Xylene-mg/kg		0305835-02	0	0.1	0.102	102.0%	1.0%
<b>SRM</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Benzene-mg/kg		0004839-05		0.1	0.098	98.0%	
Toluene-mg/kg		0004839-05		0.1	0.102	102.0%	
Ethylbenzene-mg/kg		0004839-05		0.1	0.102	102.0%	
p/m-Xylene-mg/kg		0004839-05		0.2	0.211	105.5%	
o-Xylene-mg/kg		0004839-05		0.1	0.105	105.0%	

# ENVIRONMENTAL LAB OF TEXAS

## QUALITY CONTROL REPORT

### Test Parameters

Order#: G0305836

<i>BLANK</i>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Chloride-mg/kg		0004828-01			<20.0		
<i>MS</i>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Chloride-mg/kg		0305835-01	100	1000	1100	99.4%	
<i>MSD</i>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Chloride-mg/kg		0305835-01	100	1000	1100	99.4%	0.0%
<i>SRM</i>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Chloride-mg/kg		0004828-04		5000	4960	99.2%	

CHAIN OF CUSTODY RECORD AND ANALYSIS REQUEST

Project #:

PO # 749

Fax No: (505) 397-1471

Enter Sample #:		Analyze For:	
TCLP:			
TOTAL:			
TPH/CL 1500/100			
TPH 418.1			
TPH TX 1005/1005			
TPH 60 13M 50/DRO			
		Metals: As Ag Ba Cd Cr Pb Hg Se	
		Volatiles	
		Semivolatiles	
		BTEX 4021 B/G030	

Sample Container Info:	V	I
Temperature Upon Receipt:		
Laboratory Comments:		

Time

[illegible]

Date	Time
------	------

2-27-93



# ANALYTICAL REPORT

## Prepared for:

Kristin Farris  
Rice Operating  
122 W. Taylor  
Hobbs, NM 88240

Project: Jct. H-10  
PO#: 749  
Order#: G0305703  
Report Date: 02/14/2003

BTM. Comp. @ 16'

## Certificates

US EPA Laboratory Code TX00158

# ENVIRONMENTAL LAB OF TEXAS

## SAMPLE WORK LIST

Rice Operating  
122 W. Taylor  
Hobbs, NM 88240  
505-397-1471

Order#: G0305703  
Project: None Given  
Project Name: Jct. H-10  
Location: EME

The samples listed below were submitted to Environmental Lab of Texas and were received under chain of custody. Environmental Lab of Texas makes no representation or certification as to the method of sample collection, sample identification, or transportation/handling procedures used prior to the receipt of samples by Environmental Lab of Texas, unless otherwise noted.

<u>Lab ID:</u>	<u>Sample :</u>	<u>Matrix:</u>	<u>Date / Time</u> <u>Collected</u>	<u>Date / Time</u> <u>Received</u>	<u>Container:</u>	<u>Preservative:</u>
0305703-01	Bottom Comp. @16'	SOIL	2/10/03	2/12/03 19:50	4 oz Glass	Ice:
	<u>Lab Testing:</u>	Rejected: No		Temp: 1.0 C		
	8015M					
	8021B/5030 BTEX					
	Chloride					

# ENVIRONMENTAL LAB OF TEXAS

## ANALYTICAL REPORT

Kristin Farris  
Rice Operating  
122 W. Taylor  
Hobbs, NM 88240

Order#: G0305703  
Project: None Given  
Project Name: Jet. H-10  
Location: EME

Lab ID: 0305703-01  
Sample ID: Bottom Comp. @16'

**8015M**

Method Blank	Date Prepared	Date Analyzed	Sample Amount	Dilution Factor	Analyst	Method
		2/13/03	1	1	CK	8015M

Parameter	Result mg/kg	RL
GRO, C6-C12	<10.0	10.0
DRO, >C12-C35	<10.0	10.0
TOTAL, C6-C35	<10.0	10.0

Surrogates	% Recovered	QC Limits (%)	
1-Chlorooctane	97%	70	130
1-Chlorooctadecane	100%	70	130

**8021B/5030 BTEX**

Method Blank	Date Prepared	Date Analyzed	Sample Amount	Dilution Factor	Analyst	Method
0004632-02		2/14/03 1:01	1	25	CK	8021B

Parameter	Result mg/kg	RL
Benzene	<0.025	0.025
Toluene	<0.025	0.025
Ethylbenzene	<0.025	0.025
p/m-Xylene	<0.025	0.025
o-Xylene	<0.025	0.025

Surrogates	% Recovered	QC Limits (%)	
aaa-Toluene	94%	80	120
Bromofluorobenzene	102%	80	120

Approval:

*Raland K. Tuttle*  
Raland K. Tuttle, Lab Director, QA Officer  
Coley D. Keene, Org. Tech. Director  
Jeanne McMurrey, Inorg. Tech. Director  
Sandra Biezugbe, Lab Tech.  
Sara Molina, Lab Tech.

Date

*2-16-03*

DL = Diluted out N/A = Not Applicable RL = Reporting Limit

Page 1 of 1

# ENVIRONMENTAL LAB OF TEXAS

## ANALYTICAL REPORT

Kristin Farris  
Rice Operating  
122 W. Taylor  
Hobbs, NM 88240

Order#: G0305703  
Project: None Given  
Project Name: Jct. H-10  
Location: EME

Lab ID: 0305703-01  
Sample ID: Bottom Comp. @16'

### Test Parameters

Parameter	Result	Units	Dilution Factor	RL	Method	Date Analyzed	Analyst
Chloride	677	mg/kg	1	20.0	9253	2/14/03	CK

Approval:

*Roland K. Tuttle*  
Roland K. Tuttle, Lab Director, QA Officer  
Celey D. Keene, Org. Tech. Director  
Jeanne McMurrey, Inorg. Tech. Director  
Sandra Biezugbe, Lab Tech.  
Sara Molina, Lab Tech.

2-17-03

Date

RL = Reporting Limit N/A = Not Applicable

Page 1 of 1

ENVIRONMENTAL LAB OF TEXAS, LTD.

12600 West I-20 East, Odessa, TX 79765 Ph: 915-563-1800

# ENVIRONMENTAL LAB OF TEXAS

## QUALITY CONTROL REPORT

**8015M**

Order#: G0305703

<b>BLANK</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
TOTAL, C6-C35-mg/kg		0004634-02			<10.0		
<b>MS</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
TOTAL, C6-C35-mg/kg		0305702-01	49.2	952	849	84.9%	
<b>MSD</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
TOTAL, C6-C35-mg/kg		0305702-01	49.2	952	845	83.6%	0.5%
<b>SRM</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
TOTAL, C6-C35-mg/kg		0004634-05		1000	903	90.3%	

# ENVIRONMENTAL LAB OF TEXAS

## QUALITY CONTROL REPORT

8021B/5030 BTEX

Order#: G0305703

<b>BLANK</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Benzene-mg/kg		0004632-02			<0.025		
Toluene-mg/kg		0004632-02			<0.025		
Ethylbenzene-mg/kg		0004632-02			<0.025		
p/m-Xylene-mg/kg		0004632-02			<0.025		
o-Xylene-mg/kg		0004632-02			<0.025		
<b>MS</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Benzene-mg/kg		0305706-04	0	2.5	2.14	85.6%	
Toluene-mg/kg		0305706-04	0.037	2.5	2.21	86.9%	
Ethylbenzene-mg/kg		0305706-04	0	2.5	2.25	90.4%	
p/m-Xylene-mg/kg		0305706-04	0.058	5	4.90	96.8%	
o-Xylene-mg/kg		0305706-04	0	2.5	2.31	92.4%	
<b>MSD</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Benzene-mg/kg		0305706-04	0	2.5	2.21	88.4%	3.2%
Toluene-mg/kg		0305706-04	0.037	2.5	2.24	88.1%	1.3%
Ethylbenzene-mg/kg		0305706-04	0	2.5	2.26	90.4%	0.4%
p/m-Xylene-mg/kg		0305706-04	0.058	5	4.91	97.7%	0.2%
o-Xylene-mg/kg		0305706-04	0	2.5	2.34	93.6%	1.3%
<b>SRM</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Benzene-mg/kg		0004632-05		0.1	0.087	87.0%	
Toluene-mg/kg		0004632-05		0.1	0.088	88.0%	
Ethylbenzene-mg/kg		0004632-05		0.1	0.088	88.0%	
p/m-Xylene-mg/kg		0004632-05		0.2	0.192	96.0%	
o-Xylene-mg/kg		0004632-05		0.1	0.092	92.0%	



# ENVIRONMENTAL LAB OF TEXAS

## QUALITY CONTROL REPORT

### Test Parameters

Order#: G0305703

<b>BLANK</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Chloride-mg/kg		0004640-01			<20.0		
<b>MS</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Chloride-mg/kg		0305697-01	3540	5000	8510	99.4%	
<b>MSD</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Chloride-mg/kg		0305697-01	3540	5000	8600	101.2%	1.1%
<b>SRM</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Chloride-mg/kg		0004640-04		5000	5230	104.6%	

# Environmental Lab of Texas, Inc.

12600 West I-20 East  
Odessa Texas 79763

Phone: 915-563-1800  
Fax: 915-563-1713

## CHAIN OF CUSTODY RECORD AND ANALYSIS REQUEST

Project Manager: Kristin Farris  
Company Name: RICE Operating  
Company Address: 122 W. Taylor  
City/State/Zip: Flabbs, NM 88240  
Telephone No: (505) 393-9174  
Fax No: (505) 397-1471  
Sampler Signature: Kristin Farris

Project Name: Jet H-10  
Project #: \_\_\_\_\_  
Project Loc: EME  
PO #: 749

				Analyze For:																					
				TCLP:						TOTAL:															
				TPH TX 1005/1006						TPH 8015M GRO/DRO															
				Metals: As Ag Ba Cd Cr Pb Hg Se						Volatiles															
				Semivolatiles						BTX 8021B/5030															
				RUSH TAT (Pre-Schedule)						Standard TAT															
021003 LAB # Lab Use Only	FIELD CODE:	Date Sampled	Time Sampled	No. of Containers	Ice	HNO <sub>3</sub>	HCl	NaOH	H <sub>2</sub> SO <sub>4</sub>	Nitric	Other (Specify)	Water	Sludge	Soil	Other (Specify)	TPH CL / 5000	TPH 1015	TPH TX 1005/1006	TPH 8015M GRO/DRO	Metals: As Ag Ba Cd Cr Pb Hg Se	Volatiles	Semivolatiles	BTX 8021B/5030		
	01	Bottom Comp @ 16'	02/10/03	—	1	X									X		X		X						

Special Instructions: See Res 111702

Relinquished by: Kristin Farris Date: 02/12/03 Time: 1630

Received by: Rel. d K 1-0 Date: 2-12-03 Time: 1950

Relinquished by: CP Hargus Date: 2-12-03 Time: 1950

Received by: Rel. d K 1-0 Date: 2-12-03 Time: 1950

Sample Containers Intact? Y 11

Temperature Upon Receipt: Rec 1.0°C

Laboratory Comments:

# ANALYTICAL REPORT

## Prepared for:

Kristin Farris  
Rice Operating  
122 W. Taylor  
Hobbs, NM 88240

Project: Jct. H-10  
PO#: 749  
Order#: G0305670  
Report Date: 02/14/2003

Wall Comp @ 10'

## Certificates

US EPA Laboratory Code TX00158

# ENVIRONMENTAL LAB OF TEXAS

## SAMPLE WORK LIST

Rice Operating  
122 W. Taylor  
Hobbs, NM 88240  
505-397-1471

Order#: G0305670  
Project: None Given  
Project Name: Jct. H-10  
Location: EME

The samples listed below were submitted to Environmental Lab of Texas and were received under chain of custody. Environmental Lab of Texas makes no representation or certification as to the method of sample collection, sample identification, or transportation/handling procedures used prior to the receipt of samples by Environmental Lab of Texas, unless otherwise noted.

<u>Lab ID:</u>	<u>Sample :</u>	<u>Matrix:</u>	<u>Date / Time</u> <u>Collected</u>	<u>Date / Time</u> <u>Received</u>	<u>Container</u>	<u>Preservative</u>
0305670-01	Wall Comp. @10'	SOIL	2/4/03 15:39	2/7/03 19:30	4 oz Glass	Ice
	<u>Lab Testing:</u>	Rejected: No	Temp:	0.5 C		
	8015M					
	8021B/5030 BTEX					
	Chloride					

# ENVIRONMENTAL LAB OF TEXAS

## ANALYTICAL REPORT

Kristin Farris  
Rice Operating  
122 W. Taylor  
Hobbs, NM 88240

Order#: G0305670  
Project: None Given  
Project Name: Jct. 11-10  
Location: EME

Lab ID: 0305670-01  
Sample ID: Wall Comp. @10'

8015M

Method Blank	Date Prepared	Date Analyzed	Sample Amount	Dilution Factor	Analyst	Method
		2/10/03	1	1	CDH	8015M

Parameter	Result mg/kg	RL
GRO, C6-C12	<10.0	10.0
DRO, >C12-C35	<10.0	10.0
TOTAL, C6-C35	<10.0	10.0

Surrogates	% Recovered	QC Limits (%)	
1-Chlorooctane	95%	70	130
1-Chlorooctadecane	102%	70	130

8021B/5030 BTEX

Method Blank	Date Prepared	Date Analyzed	Sample Amount	Dilution Factor	Analyst	Method
0004627-02		2/13/03 14:39	1	25	CK	8021B

Parameter	Result mg/kg	RL
Benzene	<0.025	0.025
Toluene	<0.025	0.025
Ethylbenzene	<0.025	0.025
p/m-Xylene	<0.025	0.025
o-Xylene	<0.025	0.025

Surrogates	% Recovered	QC Limits (%)	
aaa-Toluene	85%	80	120
Bromofluorobenzene	89%	80	120

Approval:

Raland K. Tuttle, Lab Director, QA Officer  
Coley D. Keene, Org. Tech. Director  
Jeanne McMurrey, Inorg. Tech. Director  
Sandra Biezugbe, Lab Tech.  
Sara Molina, Lab Tech.

Date

DL = Diluted out, N/A = Not Applicable, RL = Reporting Limit

Page 1 of 1

ENVIRONMENTAL LAB OF TEXAS LTD.

12600 West I-20 East, Odessa, TX 79765 Ph: 915-563-1800

# ENVIRONMENTAL LAB OF TEXAS

## ANALYTICAL REPORT

Kristin Farris  
Rice Operating  
122 W. Taylor  
Hobbs, NM 88240

Order#: G0305670  
Project: None Given  
Project Name: Jct. H-10  
Location: EME

Lab ID: 0305670-01  
Sample ID: Wall Comp. @10'

### Test Parameters

Parameter	Result	Units	Dilution Factor	RL	Method	Date Analyzed	Analyst
Chloride	88.6	mg/kg	1	20.0	9253	2/10/03	CK

Approval: Ral. K. Tuttle 2-14-03  
Raland K. Tuttle, Lab Director, QA Officer  
Celey D. Keene, Org. Tech. Director  
Jeanné McMurrey, Inorg. Tech. Director  
Sandra Biezugbe, Lab Tech.  
Sara Molina, Lab Tech.



# ENVIRONMENTAL LAB OF TEXAS

## QUALITY CONTROL REPORT

**8015M**

Order#: G0305670

<b>BLANK</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
TOTAL, C6-C35-mg/kg		0004583-02			<10.0		
<b>MS</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
TOTAL, C6-C35-mg/kg		0305670-01	0	952	935	98.2%	
<b>MSD</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
TOTAL, C6-C35-mg/kg		0305670-01	0	952	949	99.7%	1.5%
<b>SRM</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
TOTAL, C6-C35-mg/kg		0004583-05		1000	909	90.9%	

# ENVIRONMENTAL LAB OF TEXAS

## QUALITY CONTROL REPORT

8021B/5030 BTEX

Order#: G0305670

<b>BLANK</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Benzene-mg/kg		0004627-02			<0.025		
Toluene-mg/kg		0004627-02			<0.025		
Ethylbenzene-mg/kg		0004627-02			<0.025		
p/m-Xylene-mg/kg		0004627-02			<0.025		
o-Xylene-mg/kg		0004627-02			<0.025		
<b>MS</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Benzene-mg/kg		0305650-01	0	0.1	0.088	88%	
Toluene-mg/kg		0305650-01	0	0.1	0.088	88%	
Ethylbenzene-mg/kg		0305650-01	0	0.1	0.087	87%	
p/m-Xylene-mg/kg		0305650-01	0	0.2	0.188	94%	
o-Xylene-mg/kg		0305650-01	0	0.1	0.088	88%	
<b>MSD</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Benzene-mg/kg		0305650-01	0	0.1	0.085	85%	3.5%
Toluene-mg/kg		0305650-01	0	0.1	0.085	85%	3.5%
Ethylbenzene-mg/kg		0305650-01	0	0.1	0.083	83%	4.7%
p/m-Xylene-mg/kg		0305650-01	0	0.2	0.175	87.5%	7.2%
o-Xylene-mg/kg		0305650-01	0	0.1	0.083	83%	5.8%
<b>SRM</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Benzene-mg/kg		0004627-05		0.1	0.089	89%	
Toluene-mg/kg		0004627-05		0.1	0.091	91%	
Ethylbenzene-mg/kg		0004627-05		0.1	0.090	90%	
p/m-Xylene-mg/kg		0004627-05		0.2	0.196	98%	
o-Xylene-mg/kg		0004627-05		0.1	0.092	92%	

# ENVIRONMENTAL LAB OF TEXAS

## QUALITY CONTROL REPORT

### Test Parameters

Order#: G0305670

<b>BLANK</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Chloride-mg/kg		0004580-01			< 20.0		
<b>MS</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Chloride-mg/kg		0305665-02	2350	834	3280	111.5%	
<b>MSD</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Chloride-mg/kg		0305665-02	2350	834	3190	100.7%	2.8%
<b>SRM</b>	SOIL	LAB-ID #	Sample Concentr.	Spike Concentr.	QC Test Result	Pct (%) Recovery	RPD
Chloride-mg/kg		0004580-04		5000	5140	102.8%	

12600 West I-20 East  
Odessa, Texas 79763

Phone: 915-563-1800  
Fax: 915-563-1713

Project Manager: Kristin Ferris

Project Name: jet. H-10

Company Name: RICE Operating

Project #:

Company Address: 122 W. Taylor

Project Loc: EME

City/State/Zip: Flomms, NM 88240

PO #: 749

Telephone No. (505) 393-9174

Fax No: (505) 397-1471

Sampler Signature: Kevin James

[illegible]



# Appendix B

## Quality Procedures

**RICE Environmental Consulting and Safety (RECS)**  
P.O. Box 5630 Hobbs, NM 88241  
Phone 575.393.4411 Fax 575.393.0293

# Rice Environmental Consulting and Safety

## Quality Procedures

### Table of Contents

- QP-1 Soil Samples for Transportation to a Laboratory
- QP-2 Chloride Titration Using 0.282 Normal Silver Nitrate Solution
- QP-3 Development of Cased Water-Monitoring Wells
- QP-4 Sampling of Cased Water-Monitoring Well
- QP- 5 Composite Sampling of Excavation Sidewalls and Bottoms for TPH and Chloride Analysis
- QP-6 Sampling and Testing Protocol for VOC in soil
- QP-7 Composite Sampling of Excavation Sidewalls and Bottoms for BTEX
- QP-8 Procedure for Plugging and Abandonment of Cased Water-Monitoring wells

## **Rice Environmental Consulting and Safety**

---

### **Quality Procedure Soil Samples for Transportation to a Laboratory**

---

#### **1.0 Purpose**

This procedure outlines the methods to be employed when obtaining soil samples to be taken to a laboratory for analysis.

#### **2.0 Scope**

This procedure is to be used when collecting soil samples intended for ultimate transfer to a testing laboratory.

#### **3.0 Preliminary**

- 3.1 Obtain sterile sampling containers from the testing laboratory designated to conduct analyses of the soil.
- 3.2 If collecting TPH, BTEX, RCRA 8 metals, cation /anions or O&G, the sample jar may be a clear 4 oz. container with Teflon lid. If collecting PAH's, use an amber 4 oz. container.

#### **4.0 Chain of Custody**

- 4.1 Prepare a Sample Plan. The plan will list the number, location and designation of each planned sample and the individual tests to be performed on the sample. The sampler will check the list against the available inventory of appropriate sample collection bottles to insure against shortage.
- 4.2 Transfer the data to the Laboratory Chain of Custody Form. Complete all sections of the form except those that relate to the time of delivery of the samples to the laboratory.
- 4.3 Pre-label the sample collection jars. Include all requested information except time of collection. (Use a fine point Sharpie to insure that the ink remains on the label.) Affix the labels to the jars.

#### **5.0 Sampling Procedure**

- 5.1 Do not touch the soil with your bare hands. Use new nitrile gloves to help minimize any contamination.
- 5.2 Go to the sampling point with the sample container. If not analyzing for ions or metals, use a trowel to obtain the soil.

5.3 Pack the soil tightly into the container leaving the top slightly domed. Screw the lid down tightly. Enter the time of collection onto the sample collection jar label.

5.4 Place the sample directly on ice for transport to the laboratory if required.

5.5 Complete the Chain of Custody form to include the collection times for each sample. Deliver all samples to the laboratory.

## **6.0 Documentation**

6.1 The testing laboratory shall provide the following minimum information:

- a. Project and sample name.
- b. Signed copy of the original Chain of Custody Form including the time the sample was received by the lab.
- c. Results of the requested analyses
- d. Test Methods employed
- e. Quality Control methods and results



## **Rice Environmental Consulting and Safety**

---

### **QUALITY PROCEDURE Chloride Titration Using 0.282 Normal Silver Nitrate Solution**

---

#### **1.0 Purpose**

This procedure is to be used to determine the concentration of chloride in soil.

#### **2.0 Scope**

This procedure is to be used as the standard field measurement for soil chloride concentrations.

#### **3.0 Sample Collection and Preparation**

- 3.1 Collect at least 80 grams of soil from the sample collection point. Take care to insure that the sample is representative of the general background to include visible concentrations of hydrocarbons and soil types. If necessary, prepare a composite sample for soils obtained at several points in the sample area. Take care to insure that no loose vegetation, rocks or liquids are included in the sample(s).
- 3.2 The soil sample(s) shall be immediately inserted into a one-quart or larger polyethylene freezer bag. Care should be taken to insure that no cross-contamination occurs between the soil sample and the collection tools or sample processing equipment.
- 3.3 The sealed sample bag should be massaged to break up any clods.

#### **4.0 Sample Preparation**

- 4.1 Tare a clean glass vial having a minimum 40 ml capacity. Add at least 10 grams of the soil sample and record the weight.
- 4.2 Add at least 20 grams of reverse osmosis water to the soil sample and shake well.
- 4.3 Allow the sample to set for a period of 5 minutes or until the separation of soil and water.

#### **5.0 Titration Procedure**

- 5.1 Using a graduated pipette, remove 10 ml extract and dispense into a clean plastic cup.
- 5.2 Add 2-3 drops potassium chromate ( $K_2CrO_4$ ) to mixture if necessary.

5.3 Using a 1 ml pipette, carefully add .282 normal silver nitrate (one drop at a time) to the sample while constantly agitating it. Stop adding silver nitrate when the solution begins to change from yellow to red. Be consistent with endpoint recognition.

5.4 Record the ml of silver nitrate used.

## 6.0 Calculation

To obtain the chloride concentration, insert measured data into the following formula:

$$\frac{.282 \times 35,450 \times \text{ml AgNO}_3}{\text{ml water extract}} \times \frac{\text{grams of water in mixture}}{\text{grams of soil in mixture}}$$

Using Step 5.0, determine the chloride concentration of the RO water used to mix with the soil sample. Record this concentration and subtract it from the formula results to find the net chloride in the soil sample.

Record all results on the delineation form.

---

**Rice Environmental Consulting and Safety**

---

**Quality Procedure**  
**Development of Cased Water-Monitoring Wells**

---

**1.0 Purpose**

This procedure outlines the methods to be employed to develop cased monitoring wells.

**2.0 Scope**

This procedure shall be used for developed, cased water monitoring wells. It is not to be used for standing water samples such as ponds or streams.

**3.0 Sample Collection and Preparation**

- 3.1 Prior to development, the static water level and height of the water column within the well casing will be measured with the use of an electric D.C. probe.
- 3.2 All measurements will be recorded within a field log notebook.
- 3.3 All equipment used to measure the static water level will be decontaminated after each use by means of Liquinox, a phosphate free laboratory detergent, and water to reduce the possibility of cross-contamination. The volume of water in each well casing will be calculated.

**4.0 Purging**

- 4.1 Wells will be purged by using a 2" decontaminated submersible pump or dedicated one liter Teflon bailer. Wells should be purged until the pH and conductivity are stabilized and the turbidity has been reduced to the greatest extent possible.
- 4.2 If a submersible is used the pump will be decontaminated prior to use by scrubbing the outside surface of tubing and wiring with a Liquinox water mixture, pumping a Liquinox-water mixture through the pump, and a final flush with fresh water.

**5.0 Water Disposal**

- 5.1 All purge and decontamination water will be temporarily stored within a portable tank to be later disposed of in an appropriate manner.

**6.0 Records**

- 6.1 Rice Environmental Consulting and Safety will record the amount of water removed from the well during development procedures. The purge volume will be reported to the appropriate regulatory authority when filing the closure report.

## Rice Environmental Consulting and Safety

---

### Quality Procedure Sampling of Cased Water-Monitoring Well

---

#### 1.0 Purpose

This procedure outlines the methods to be employed in obtaining water samples from cased monitoring wells.

#### 2.0 Scope

This procedure shall be used for developed, cased water monitoring wells. It is not to be used for standing water samples such as ponds or streams.

#### 3.0 Preliminary

3.1 Obtain sterile sampling containers from the testing laboratory designated to conduct analyses of the water.

3.2 The following table shall be used to select the appropriate sampling container, preservative method and holding times for the various elements and compounds to be analyzed.

Compound to be Analyzed	Sample Container Size	Sample Container Description	Cap Requirements	Preservative	Maximum Hold Time
BTEX	40 ml	VOA Container	Teflon Lined	HCL	14 days
TPH (8015 Extended)	40 ounces	(2) 40ml VOA vials	Teflon Lined	HCL and Ice	14 days
PAH	1 liter	amber glass	Teflon Lined	Ice	7 days
Cation/Anion	1 liter	HD polyethylene	Any Plastic	None	48 Hrs
Metals	1 liter	HD polyethylene	Any Plastic	Ice/HNO <sub>3</sub>	28 Days
TDS	300 ml	clear glass or 250 ml HD polyethylene	Any Plastic	Ice	7 Days
Cl-	500 ml	HD polyethylene	Any Plastic	None	28 Days

#### **4.0 Chain of Custody**

- 4.1 Prepare a Sample Plan. The plan will list the well identification and the individual tests to be performed at that location. The sampler will check the list against the available inventory of appropriate sample collection bottles to insure against shortage.
- 4.2 Transfer the data to the Laboratory Chain of Custody Form. Complete all sections of the form except those that relate to the time of delivery of the samples to the laboratory.
- 4.3 Pre-label the sample collection jars. Include all requested information except time of collection. (Use a fine point Sharpie to insure that the ink remains on the label). Affix the labels to the jars.

#### **5.0 Bailing Procedure**

- 5.1 Identify the well from the sites schematics. Place pre-labeled jar(s) next to the well. Remove the plastic cap from the well bore by first lifting the metal lever and then unscrewing the entire assembly.
- 5.2 Using a dedicated one liter Teflon bailer or submersible pump, purge a minimum of three well volumes. Place the water in storage container for transport to a ROC disposal facility.
- 5.3 If using a bailer, take care to insure that the bailing device and string does not become cross-contaminated. A clean pair of nitrile gloves should be used when handling either the retrieval string or bailer. The retrieval string should not be allowed to come into contact with the ground.

#### **6.0 Sampling Procedure**

- 6.1 Once the well has been bailed in accordance with 5.2 of this procedure, a sample may be decanted into the appropriate sample collection jar directly from the bailer or submersible pump.
- 6.2 Note the time of collection on the sample jar with a fine Sharpie.
- 6.3 Place the sample directly on ice for transport to the laboratory. The preceding table shows the maximum hold times between collection and testing for the various analyses.

6.4 Complete the Chain of Custody form to include the collection times for each sample. Deliver all samples to the laboratory.

## 7.0 Documentation

7.1 The testing laboratory shall provide the following minimum information:

- A. Project and sample name.
- B. Signed copy of the original Chain of Custody Form including the time the sample was received by the lab.
- C. Results of the requested analyses
- D. Test Methods employed
- E. Quality Control methods and results

### Calculation for Determining the Minimum Bailing Volume for Monitor Wells

$$\text{Formula } V = (\pi r^2 h)$$

2" well  $[V/2.31 = \text{gal}] \times 3 = \text{Purge Volume}$

V=Volume

$\pi = \text{pi}$

r=inside radius of the well bore

h=maximum height of well bore in water table

Example:

$\pi$	$r^2$	h(in)	V(cu.in)	V(gal)	X 3 Volumes	Actual
3.1416	1	180	565.488	2.448	7.34 gal	>10 gal

---

## Rice Environmental Consulting and Safety

---

### Quality Procedure Composite Sampling of Excavation Sidewalls and Bottoms For TPH and Chloride Analysis

---

#### 1.0 Purpose

This procedure outlines the methods to be employed when obtaining final composite soil samples for TPH and Chloride analysis.

#### 2.0 Scope

This procedure is to be used in conjunction with *Quality Procedure – 02: Soil Samples for Transportation to a Laboratory* and will be inserted at subparagraph 5.2 of Section 5.0: Sampling Procedure.


#### 3.0 Sampling Procedure

Follow *Quality Procedure – 02: Soil Samples for Transportation to a Laboratory* for all Sections and subparagraphs until subparagraph 5.2 of Section 5.0: Sampling Procedure. Instead of 5.2 instructions, perform the composite sample collection procedure as follows:

3.1 Go to the excavation with a new plastic baggie. If not analyzing for ions or metals, use a trowel to obtain the soil. If the excavation is deeper than 6' BGS, do not enter the pit, but use a backhoe to assist in procurement of the sample. (If a backhoe is used, the backhoe will obtain an amount of soil from each composite point; bring the purchase to the surface staging area where a sample-portion of soil will be extracted from the backhoe purchase. The remainder of the backhoe purchase will be staged on the surface with other staged soils.)

#### 3.2 Sidewall samples

3.2.1 On each sidewall, procure a 5oz sample from each of five distinct points on the sidewall with distinct points resembling the "W" pattern:



- 3.2.2 Thoroughly blend these five samples in a labeled baggie.
- 3.2.3 Repeat steps 3.2.1 through 3.2.4 for each remaining sidewall.
- 3.2.4 From each labeled baggie, procure a 5 oz portion and pour into a baggie labeled "Sidewall Composite". Blend this soil mixture completely.
- 3.2.5 Obtain proper laboratory sample container for "Sidewall Composite" and continue with subparagraph 5.3 of QP – 01.

### 3.3 Bottom Sample

- 3.3.1 From bottom of excavation, procure a 5oz sample from each of five distinct points with distinct points resembling the "W" pattern as illustrated above.
- 3.3.2 Thoroughly blend these five samples in a clean baggie.
- 3.3.3 Obtain proper laboratory sample container for "Bottom Composite" and continue with subparagraph 5.3 of QP – 01.



## **Rice Environmental Consulting and Safety**

---

### **QUALITY PROCEDURE**

#### **Sampling and Testing Protocol for VOC in Soil**

---

#### **1.0 Purpose**

This procedure is to be used to determine the concentrations of Volatile Organic Compounds in soils.

#### **2.0 Scope**

This procedure is to be used as the standard field measurement for soil VOC concentrations. It is not to be used as a substitute for full spectrographic speciation of organic compounds.

#### **3.0 Procedure**

##### **3.1 Sample Collection and Preparation**

3.1.1 Collect at least 500 g. of soil from the sample collection point. Take care to insure that the sample is representative of the general background to include visible concentrations of hydrocarbons and soil types. If necessary, prepare a composite sample of soils obtained at several points in the sample area. Take care to insure that no loose vegetation, rocks or liquids are included in the sample(s).

3.1.2 The soil sample(s) shall be immediately inserted into a one-quart or larger polyethylene freezer bag and sealed. When sealed, the bag should contain a nearly equal space between the soil sample and trapped air. Record the sample name and the time that the sample was collected on the Field Analytical Report Form.

3.1.3 The sealed samples shall be allowed to set for a minimum of five minutes at a temperature of between 10-15 Celsius, (59-77<sup>0</sup> F). The sample temperatures may be adjusted by cooling the sample in ice, or by heating the sample within a generally controlled environment such as the inside of a vehicle. The samples should not be placed directly on heated surfaces or placed in direct heat sources such as lamps or heater vents.

3.1.4 The sealed sample bag should be massaged to break up any clods, and to provide the soil sample with as much exposed surface area as practically possible.

### 3.2 Sampling Procedure

- 3.2.1 The instrument to be used in conducting VOC concentration testing shall be a RAE Systems Photoionization device. (Device will be identified on VOC Field Test Report Form.) Prior to use, the instrument shall be zeroed-out in accordance with the appropriate maintenance and calibration procedure outlined in the instrument operation manual. The PID device will be calibrated each day it's used.
- 3.2.2 Carefully open one end of the collection bag and insert the probe tip into the bag taking care that the probe tip not touch the soil sample or the sidewalls of the bag.
- 3.2.3 Set the instrument to retain the highest result reading value. Record the reading onto the Field Test Report Form.
- 3.2.4 **If the instrument provides a reading exceeding 100 ppm, proceed to QP-7. If the reading is 100 ppm or less, NMOCD BTEX guideline has been met and no further testing for BTEX is necessary. File the Field Test Report Form in the project file.**

### 4.0 Clean-up

After testing, the soil samples shall be returned to the sampling location, and the bags collected for off-site disposal. **IN NO CASE SHALL THE SAME BAG BE USED TWICE. EACH SAMPLE CONTAINER MUST BE DISCARDED AFTER EACH USE.**

---

## **Rice Environmental Consulting and Safety**

---

### **Quality Procedure Composite Sampling of Excavation Sidewalls and Bottoms For BTEX**

---

#### **1.0 Purpose**

This procedure outlines the methods to be employed when obtaining final composite soil samples for BTEX analysis.

#### **2.0 Scope**

This procedure is to be used when collecting soil samples intended for ultimate transfer to a testing laboratory for BTEX analysis. This procedure is to be used only when the PID field-test results for OVM exceeds 100 ppm.

#### **3.0 Preliminary**

- 3.1 Obtain sterile, clear, 2 oz. glass containers with Teflon lid from a laboratory supply company or the testing laboratory designated to conduct analyses of the soil.

#### **4.0 Chain of Custody**

- 4.1 Prepare a Sample Plan. The plan will list the number, location and designation of each planned sample and the individual tests to be performed on the sample. The sampler will check the list against the available inventory of appropriate sample collection bottles to insure against shortage.
- 4.2 Transfer the data to the Laboratory Chain of Custody Form. Complete all sections of the form except those that relate to the time of delivery of the samples to the laboratory.
- 4.3 Pre-label the sample collection jars. Include all requested information except time of collection. (Use a fine point Sharpie to insure that the ink remains on the label.) Affix the labels to the jars.


#### **5.0 Sampling Procedure**

- 5.1. Do not touch the soil with your bare hands. Use new nitrile gloves to help minimize any cross-contamination.
- 5.2. If safe and within OSHA regulations, go to the sampling point with the sample container. If not analyzing for ions or metals, use a trowel to

obtain the soil. If the excavation is deeper than 6' BGS, do not enter the pit, but use a backhoe to assist in procurement of the sample. (If a backhoe is used, the backhoe will obtain an amount of soil from each composite point; bring the purchase to the surface staging area where a sample-portion of soil will be extracted from the backhoe purchase. The remainder of the backhoe purchase will be staged on the surface with other staged soils.)

### 5.3.Sidewall Samples

5.3.1.On each sidewall, procure a 2oz sample from each of five distinct points on the sidewall with distinct points resembling the "W" pattern:



5.4.Pack the soil tightly into the container leaving the top slightly domed. Screw the lid down tightly. Enter the time of collection onto the sample collection jar label. Repeat for each sampling point.

5.5.Place the samples directly on ice for transport to the laboratory if required.

5.6.Complete the Chain of Custody form to include the collection times for each sample. Deliver all samples to the laboratory.

## 6.0 Documentation

6.1 The testing laboratory shall provide the following minimum information:

- a. Project and sample name.
- b. Signed copy of the original Chain of Custody Form including the time the sample was received by the lab.
- c. Results of the requested analyses
- d. Test Methods employed
- e. Quality Control methods and results

## **Rice Environmental Consulting and Safety**

---

### **Procedure for Plugging & Abandonment of Cased Water Monitoring Wells**

---

#### **1.0 Purpose**

This procedure outlines the methods to be employed to plug and abandon cased monitoring wells.

#### **2.0 Scope**

This procedure shall be used for developed, cased water monitoring wells located in the State of New Mexico

#### **3.0 Preliminary**

**3.1** No well may be drilled, modified or plugged without NMOCD approval. Additional approvals may be required if the well is situated in a sensitive area, within municipal jurisdictions or on federal or tribal lands.

#### **4.0 Plugging**

**4.1** Each bore will be filled with a 1% - 3% bentonite/concrete slurry to three feet bgs. The remaining three feet will be capped with concrete only.

**4.2** All wellheads will be removed to below ground surface.

#### **5.0 Records**

**5.1** The company plugging the well shall prepare a report on their company letter head listing the site name and describing general well construction including total depth of the well, the diameter of casing, material used to plug the well (e.g. bentonite/cement slurry), and date of the plugging operation.

**5.2** It is recommended but not required that photographs of the final surface restoration be taken and included within the records.

**5.3** Copies of the plugging report shall be submitted to all appropriate agencies and retained by the well operator for a minimum period of ten years.