

Well Welch "A" #1
Unit B Section 4 Township 19 Range 31
API # 30-015-05726

T. Salt 852
B. Salt 2200
Yates 2480
Glorieta _____
Delaware _____
Bone Sp. _____
Abo _____
Wolfcamp _____
Morrow _____
Devonian _____
Fusselman _____
Other _____

← Perf. $8\frac{1}{2}" \times 5\frac{1}{2}"$ CSQ @ 60' - Place
60' of cmt 0-60' inside & outside
Both strings

← Place 100' of cmt inside & outside CSQ
198'-298' - Tag

← Perf CSQ @ 298'

← Place 100' of cmt 750'-850' inside & outside
CSQ - Tag

← Perf CSQ @ 850'

← Place 100' of cmt 2300'-2400' inside & outside
CSQ - Tag

← Perf CSQ @ 2400'

248'
255'
calc

51 - TOC - calc @ 50%

← 25 SX plug @ 3325' - Tag

← Perfs

2 -
380'
" 4499
2755'

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

BEFORE EXAMINER CATANACH
OIL CONSERVATION DIVISION

OCD EXHIBIT NO. 27

CASE NO. 12965