

Brooks, David K

From: Williams, Chris
Sent: Tuesday, January 29, 2002 2:17 PM
To: Brooks, David K
Subject: RE: Cecil Lee's Company; M&G Oil

Looks OK to me! Chris

-----Original Message-----

From: Brooks, David K
Sent: Tuesday, January 29, 2002 1:48 PM
To: Prichard, Billy; Williams, Chris
Subject: Cecil Lee's Company; M&G Oil

Billy and Chris

Attached are plugging applications that I have prepared to file re above operators.

Today is day for filing for 2/21 hearing if you give me go ahead.

I already have approval on Leigh Operating.

DB

<< File: Application.doc >> << File: Case No.doc >> << File: Application.doc >> << File: Exhibit A.doc >>

**Cecil Lee's Company
Landreth State # 1
API # 30-025-25595
UL M, Sec 15, T10S, R36E
Plugging Procedure**

**12 3/4" casing set at 398 feet, Cement Circulated
8 5/8" casing set at 4216 feet, Cement Circulated
5 1/2" casing set at 12235 feet, Cement with 1700 sacks, Calculated TOC 657 feet
Open Hole 12235-12239**

All fluids will be circulated to plastic lined pit or steel tank

- 1. Move in rig up plugging rig**
- 2. Nipple up BOP**
- 3. Pull production equipment**
- 4. Run gauge ring and junk basket to 12200 feet**
- 5. Run and set CIBP at 12200 feet**
- 6. Cap CIBP with 35 feet of cement by dump bailer**
- 7. Run tubing**
- 8. Tag cement plug at 12165 feet**
- 9. Displace well with gelled brine**
- 10. Pull tubing to 9715 feet**
- 11. Spot 25 sack cement plug**
- 12. Pull tubing to 7828 feet**
- 13. Spot 25 sack cement plug**
- 14. Pull tubing to 5690 feet**
- 15. Spot 25 sack cement plug**
- 16. Pull tubing to 4266 feet**
- 17. Spot 25 sack cement plug**
- 18. Pull tubing and WOC**
- 19. Run tubing and tag cement plug, Maximum depth 4166 feet**
- 20. Pull tubing to 2275 feet**
- 21. Spot 25 sack cement plug**
- 22. Pull tubing**
- 23. Weld on pull nipple and stretch casing**
- 24. Cut and pull 5 1/2" casing from 398 feet if free**
- 25. Run tubing to 448 feet**
- 26. Spot 40 sack cement plug**
- 27. Pull tubing and WOC**
- 28. Run tubing and tag cement plug, Maximum depth 348 feet**
- 29. Pull tubing to 60 feet**
- 30. Circulate cement to surface**
- 31. Pull tubing**
- 32. Cut off wellhead and install PA marker**
- 33. Rig down move out service unit**
- 34. Cut off service unit anchors and clean location**