

NORTH BLINEBRY WATERFLOOD EXPANSION PROJECT

Typical Producer to Waterflood Injector Conversion

Procedure

1. MIRU. Install BOPE.
2. POOH and lay down production equipment.
3. Pick up and RIH w/bit, scraper and workstring and clean out to TD.
4. Add additional Blinebry and/or Tubb perforation as required.
5. Acid breakdown perforations.
6. Sand frac or acid frac new perforations as required.
Note: Blinebry and Tubb zones will be isolated and stimulated separately.
7. Swab back load.
8. Pick up and RIH with plastic coated injection tubing with Guiberson injection regulator/packers to isolate Tubb and Blinebry injection.
9. Flange up injection wellhead.
10. RDMO pulling unit.

EXHIBIT 17

BEFORE EXAMINER STOGNER OIL CONSERVATION DIVISION
EXHIBIT NO. <u>17</u>
CASE NO. <u>10220</u>
Submitted by <u>Conoco Inc.</u>
Hearing Date <u>1-24-91</u>