Submit I Copy To Appropriate District Office	State of	f New Mex	tico	EMNRD-OCE		Form C-10	
<u>District I</u> – (575) 393-6161	Energy, Mineral	s and Natur	al Resources	REC'D: 6/11/2   WELL AI		Revised July 18, 201	
1625 N. French Dr., Hobbs, NM 88240 <u>District II</u> – (575) 748-1283	OIL CONSER	WELLA	30-0	015-27072	-		
811 S. First St., Artesia, NM 88210 <u>District III</u> – (505) 334-6178	1220 Sout		te Type of Leas				
1000 Rio Brazos Rd., Aztec, NM 87410 District IV – (505) 476-3460	Santa F		ATE ■ Dil & Gas Lease	FEE L	$\dashv$		
1220 S. St. Francis Dr., Santa Fe, NM 87505					30327		
	TICES AND REPORTS C	ON WELLS		7. Lease		Agreement Name	$\dashv$
(DO NOT USE THIS FORM FOR PROP DIFFERENT RESERVOIR. USE "APP				PIN	INACLE	STATE	
PROPOSALS.)  1. Type of Well: Oil Well	8. Well N	Jumber	003	$\dashv$			
2. Name of Operator	9. OGRII	D Number	246289				
3. Address of Operator <sub>3500 ONE</sub> TULSA, Oh		name or Wilder		ST			
4 Well Location		SOLIT	·⊔			_	
Unit Letter K	: 1980 feet from the		fine and		feet from the _		
Section 36	Township  11. Elevation (Show w	22S Ran			EDDY Coun	ty	
	11. Elevation (Snow h	3,102' G		cic.)			
10 (1 1	A	12 . 37	CNI	·	0.1 D		
12. Check	Appropriate Box to I	ndicate Na	ture of Noti	ice, Report or	Other Data		
	INTENTION TO:			SUBSEQUEN			7
PERFORM REMEDIAL WORK [ TEMPORARILY ABANDON [		N 🔳	REMEDIAL V COMMENCE	VORK EDRILLING OPN			_
PULL OR ALTER CASING	MULTIPLE COMPL		CASING/CEN				•
DOWNHOLE COMMINGLE CLOSED-LOOP SYSTEM				Notify OCD 24	hrs. prior to a	<mark>ny work</mark>	
OTHER:			OTHER:	done			]_
13. Describe proposed or con	npleted operations. (Clear work). SEE RULE 19.15.′						ate
proposed completion or r		7.14 TVIVIZ (C.	Tor Watapic	completions.	rttaen wenoon	c diagram of	
WPX ENERGY PERMIAN,			•				ise
see the below for the proce			ached fro th	he current ar	nd proposed	d WBDs.	
Set 5 1/2" CIBP @ 5930' w/ I. Set 5 ½" CIBP @ 3300'.			ire test csi	a Snot 25 sy	v cmt @330	n-3100' <mark>wo</mark> ɗ	<u> </u>
2. S <del>po</del> t 25 sx cmt @ 2600-2						0-0100. <b>VVO</b>	
3. Perf & Sqz 130 sx cmt @	• • • • • • • • • • • • • • • • • • • •	,		·			
<ol> <li>Cut off well head, verify of</li> </ol>	mt to surface, weld	on Dry H	ole Marker				ent Name ATE 3 6289  ARE, EAST ST line  ASING   ck  stimated date am of ell. Please Ds.  00'. WOC & 1
Spud Date: 08/22/	1992 Rig	Release Dat	e: <b>1</b>	0/13/199	92		
****SEE ATTACHED COA		MU	JST BE PL	UGGED BY 6	3/18/2021		
I hereby certify that the information							—
1-1	641	_			•	2/4/4/2020	
SIGNATURE (MIX	U (P TIT	<sub>rle</sub> Regu	ılatory Te	ech III	DATE_0	6/11/2020	
Type or print name Caitlin O	'Hair <sub>F-r</sub>	nail address:	caitlin.ohair	@wpxenergy.c	om PHONE:	539-573-352	7
For State Use Only	E-11						_
APPROVED BY:	TIT	LE	Staff Mar	иааох	DATE 6	/18/2020	
Conditions of Approval (if any):	111	<b>ப</b> ப	July Iria	inger	DAID		—



## **CURRENT WELLBORE DIAGRAM**


MD (KB)

TVD (KB)

MD (KB)

13

-104.0436480



T/Salt- 555 B/Salt- 2540 Del - 2805 B/S - 6342 32.3474426



## PROPOSED WELLBORE DIAGRAM

WELL: PINNACLE STATE 3 SPUD DATE: 8/22/1992 COUNTY: **EDDY** 6411 TD: MD (KB) STATE: NM EU NUMBER: 62429033 TVD (KB) TVD: 6411 API: 30-015-27072 PBTD: 6312 MD (KB) LOCATION: 36-22S-28E KB ELEVATION: 3115 13 FIELD / AREA: RUSTLER BREAKS GL ELEVATION: 3102 FORMATION: DELAWARE MTN GROUP SURFACE LAT/LONG: 32.3473290 -104.0436480

CASING RECORD									
RFACE CASING									
O.D.	WT./FT.	GRADE	THĐ	TOP	ВТМ				
8.625"	24.000"	J-55		0.000"	555				

GRADE

J-55

THD

TOP

0

BTM

6411

3. Perf & Sqz 130 sx cmt @ 605' to surface. (T/Salt & Shoe)

WT./FT.

15 1/2

8.625 @ 555' (MD)

2. Spot 25 sx cmt @ 2600-2400'. WOC & Tag (B/Salt)

O.D.

5 1/2

1. Set 5  $\frac{1}{2}$ " CIBP @ 3300'. Circulate hole w/ MLF. Pressure test csg. Spot 25 sx cmt @ 3300-3100'.

Perfs @ 3351-6200'

DVT @ 4205'

5.5 @ 6,411' (MD)

## CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E)Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - I) Glorieta
  - J) Yates.
  - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

## **DRY HOLE MARKER REQUIRMENTS**

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)