

Submit 1 Copy To Appropriate District Office
 District I - (575) 393-6161
 1625 N. French Dr., Hobbs, NM 88240
 District II - (575) 748-1283
 811 S. First St., Artesia, NM 88210
 District III - (505) 334-6178
 1000 Rio Brazos Rd., Aztec, NM 87410
 District IV - (505) 476-3460
 1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
 Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
 1220 South St. Francis Dr.
 Santa Fe, NM 87505

WELL API NO. 30-015-26457
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name SST
8. Well Number #3
9. OGRID Number 228937
10. Pool name or Wildcat PALMILLO;BONE SPRING, EAST

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>	
2. Name of Operator MATADOR PRODUCTION COMPANY	
3. Address of Operator 5400 LBJ FREEWAY, STE 1500, DALLAS, TX 75240	
4. Well Location Unit Letter <u>C</u> : <u>660</u> feet from the <u>N</u> line and <u>1747</u> feet from the <u>W</u> line Section <u>06</u> Township <u>19S</u> Range <u>29E</u> NMPM County <u>EDDY</u>	
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3389 GL	

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input checked="" type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> MULTIPLE COMPL <input type="checkbox"/> DOWNHOLE COMMINGLE <input type="checkbox"/> CLOSED-LOOP SYSTEM <input type="checkbox"/> OTHER: <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> P AND A <input type="checkbox"/> CASING/CEMENT JOB <input type="checkbox"/> OTHER: <input type="checkbox"/>

Notify OCD 24 hrs. prior to any work done

13. Describe proposed or completed operations. (Clearly state all pertinent details of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Matador is requesting to plug and abandon the SST #3, per the NMOCD's COA, following the procedure below:

- Notify NMOCD 24 hrs before MIRU.
- Safety mtg, MIRU, Kill well, ND wellhead, NU BOPs & POOH w/ tbg.
- RU WL and set CIBP @ 7,410'. Dump bail 35' of CI C cmt on top of CIBP. WOC.
- TIH w/ tbg and tag TOC. Circ and displace hole w/ MLF. Pull up and spot 25 sx CI C cmt at 6,400'. WOC & Tag.
- 3480' • Perf @ 3,400' & Sqz 35 sx CI C cmt. WOC and Tag @ all perforations
- Perf @ 2,635' & Sqz 35 sx CI C cmt.
- Perf @ 1,765' & Sqz 35 sx CI C cmt.
- 1150' • Perf @ 1,250' & Sqz 35 sx CI C cmt. Perf @ 950' & sqz 35 sx cmt WOC and Tag - T Yates
- Perf @ 350' & Sqz CI C cmt to surface.
- Cut off wellhead and ensure cmt to surface on all csg strings.
- Install above ground marker per NMOCD specifications.
- *Current and proposed wellbore diagrams attached
- **Mud laden fluid (MLF) mixed at 25sx/100 bbls water will be spotted between each plug.

Spud Date:

09/10/1990

Rig Release Date:

****SEE ATTACHED COA's****


MUST BE PLUGGED BY 10/23/2021

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Ava Monroe TITLE Sr Regulatory Analyst DATE 09/14/20
 Type or print name Ava Monroe Technical information: Kyle Christy, Production Engineer
 E-mail address: KChristy@matadorresources.com PHONE: 303-929-9000
 For State Use Only

APPROVED BY: [Signature] TITLE Staff Manager DATE 10/23/2020
 Conditions of Approval (if any):

MATADOR PRODUCTION COMPANY
SST #3
C-6-19S-29E; 660' FNL & 1747' FWL
Eddy County, NM
API: 30-015-26457
CURRENT WELLBORE SCHEMATIC
Spudded: 9/10/90




Casing Information						
	Hole Size	Casing Size	Type	Weight lb/ft	Joints	Depth Set
Surface	17 1/2	13 3/8	J-55 ST&C	54.5	7	335
Intermediate	12 1/4	8 5/8	J-55 ST&C	32	27	1200
Production	7 7/8	5 1/2	J-55 LTC	17	187	7845
Marker Jt.		7098				

Cementing Record						
Surface	350 sx, circ'd 68 sx back to surface					
Intermediate	800 sx, circ'd 150 sx back to surface					
Production	1st Stg: 600 sx CI H; 2nd Stg: 750 sx filler + 100 sx CI C neat; Circ 125 sx to surface					
Tubing		Rods		Geologic Markers		
Joints	233	Total		Yates		900'
Diam.	2 3/8	7/8"		Seven Rivers		1,218'
Grade	J-55	3/4"		Queen		1,768'
Weight		7/8"		Grayburg		2,113'
Fill	7,686'	1"		San Andres		2,638'
PBTD	7,797'	Pony		Bone Spring		3,430'
BP	7685	Pump		2nd BS Sand		7,470'
SN	7,661'					
TAC	7,290'			TD		7,845'

(10-17-90) Perf 2nd Bone Spring Sand 7489 - 7620 w/1SPF, 8 shots
 acdz w/3000 gal 10% NEFE & Frac w/ 67k gals WF40 + 118,500# 16/20 Carbolite

MATADOR PRODUCTION COMPANY
SST #3
C-6-19S-29E; 660' FNL & 1747' FWL
Eddy County, NM
API: 30-015-26457
CURRENT WELLBORE SCHEMATIC
Spudded: 9/10/90



350': Perf & Sqz Cl C cmt to surface

1,250': Perf & Sqz 35sx Cl C cmt

1,765': Perf & Sqz 35 sx Cl C cmt (Queen)

2,635': Perf & Sqz 35 sx Cl C cmt (San Andres)

3,400': Perf & Sqz 35 sx Cl C cmt (Bone Spring)

6,400': Spot 25 sx Cl C cmt

7,410': CIBP w/ 35' of Cl C cmt

(10-17-90) Perf Second Bone Spring Sand 7489 - 7620 w/1SPF, 8 shots
 acdz w/3000 gal 10% NEFE & Frac w/ 67k gals WF40 + 118,500# 16/20 Carbolite

Casing Information						
	Hole Size	Casing Size	Type	Weight lb/ft	Joints	Depth Set
Surface	17 1/2	13 3/8	J-55 ST&C	54.5	7	335
Intermediate	12 1/4	8 5/8	J-55 ST&C	32	27	1200
Production	7 7/8	5 1/2	J-55 LTC	17	187	7845
Marker Jt.		7098				

Cementing Record	
Surface	350 sx, circ'd 68 sx back to surface
Intermediate	800 sx, circ'd 150 sx back to surface
Production	1st Stg: 600 sx Cl H; 2nd Stg: 750 sx filler + 100 sx Cl C neat; Circ 125 sx to surface

Geologic Markers	
Yates	900'
Seven Rivers	1,218'
Queen	1,768'
Grayburg	2,113'
San Andres	2,638'
Bone Spring	3,430'
2nd BS Sand	7,470'
TD	7,845'

CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
8. Produced water **will not** be used during any part of the plugging operation.
9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
11. Class 'C' cement will be used above 7500 feet.
12. Class 'H' cement will be used below 7500 feet.
13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) **Potash---** (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIREMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3. API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION