

Submit 1 Copy To Appropriate District Office

District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico.
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

REC'D NMOCD

12/03/2020

Form C-103
Revised July 18, 2013

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-005-61891
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
2. Name of Operator Harvard Petroleum, Inc.		6. State Oil & Gas Lease No. LG-978
3. Address of Operator PO Box 936, Roswell, NM 88202		7. Lease Name or Unit Agreement Name Ard
4. Well Location Unit Letter I : 1980 feet from the S line and 660 feet from the E line Section 4 8S Township 27E Range NMPM County Chaves		8. Well Number 1
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3931 GL		9. OGRID Number 10155
		10. Pool name or Wildcat Udes. Foor Ranch: Pre Permian, NE

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	P AND A <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPL <input type="checkbox"/>	CASING/CEMENT JOB <input type="checkbox"/>	
DOWNHOLE COMMINGLE <input type="checkbox"/>			
CLOSED-LOOP SYSTEM <input type="checkbox"/>			
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

Notify OCD 24 hrs. prior to any work done

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Harvard Petroleum, Inc. proposes to P&A this well as follows:

Use closed loop system - no fluids on ground

MIRU Pulling Unit and POH w/ tubing

RIH w/ CIBP and set at 1898'

RIH and circulate hole from 1898' to surface with NMOCD approved plugging mud

Pump 35 sx class C cement plug at 1898' to cover 1798 to 1898' WOC & Tag

Pump 35 sx class C cement plug @ 1420 to cover 1320 to 1420' WOC and Tag to cover top of San Andres

Perforate 863' and 90'

RIH and pump 50 sx class C @ 863 and squeeze in and out of 5 1/2" casing to cover 763 to 863' WOC and Tag to cover 8 5/8" shoe

Establish circulation through perfs at 90' and circulate hole with adequate volume (est 35sx) class c to cover surface to 90'

After plugging the casing will be cut off 3' below ground leve and a plate and dry hole marker will be installed. The location will be cleared of junk and remediated to NMOCD standards. See attached well bore diagram.

Spud Date:

12/31/82

Rig Release Date:

1/31/83

****SEE ATTACHED COA's****

MUST BE PLUGGED BY 12/8/2021

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

TITLE

Consultant

DATE

12/2/2020

Type or print name

Phelps White

E-mail address:

pwiv@zianet.com

PHONE:

575-626-7660

For State Use Only

APPROVED BY:

TITLE

Staff Manager

DATE

12/8/2020

Conditions of Approval (if any):

HARVARD PETROLEUM COMPANY

WELL BORE DIAGRAM

Proposed Plugs

Current Wellbore

Ard State #1
30-005-61891

35 sx @ 90'
Surface to 90'
Squeeze Perfs @ 90'

50 sx Class C @ 863
763-863'
Squeeze Perfs @ 863'

35 sx Class C @ 1420'
1320-1420

35 sx Class C @ 2100'
1798' to 1898'
CIBP @ 1898'

13 3/8" 54.5# @ 813', 1/3/83
540 sx cement Circulated

TOC Est 1065'

LOG TOPS	Depth
San Andres	1370
Glorieta	2575
Abo	4758
Wolfcamp	5428
Cisco	6016

Not to Scale

Perfs: 1948-58', 2/8/07
CIBP @ 2100
Perfs: 2152-68, 2173-76, 1/28/07
CIBP +35' cmt @ 2300', 2/4/07
Perfs: 2342-52, 56-60, 1-25-07

Cement Retainer @ 2399,
Squeeze 178 sx

Hole in Casing @ 2300-2500'
CIBP +35' cmt @ 2575' 1/11/07
Original TOC @ 2600'


DV Tool 3990'
2nd Stage 960 sx Class C

CIBP + 35' cmt @ 4758', 1/11/07

CIBP + 35' cmt @ 5320, 11/24/06
Perfs @ 5459-5463
CIBP +35' cmt @ 5780, 11/20/06
Perfs: 5810-5814
CIBP +35' cmt @ 6050, 11/17/06
Perfs: 6268-6275
CIBP +35' cmt @ 6360
Perfs: 6394-6400, 6424-6434
CIBP +35' cmt @ 6590
Perfs: 6646-6654

5 1/2" 15.5# @ 6883', 1/31/83
1st stage 465 sx

TD 6890'



CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
8. Produced water **will not** be used during any part of the plugging operation.
9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
11. Class 'C' cement will be used above 7500 feet.
12. Class 'H' cement will be used below 7500 feet.
13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) **Potash---** (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIREMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3. API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION