

NEW MEXICO OIL CONSERVATION COMMISSION

MAR 20 1982

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	✓
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State Fee
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator McClellan Oil Corporation 3. Address of Operator P.O. Drawer 730, Roswell, New Mexico 88202 4. Location of Well UNIT LETTER <u>G</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>22</u> TOWNSHIP <u>11N</u> RANGE <u>21E</u> NMPM.	7. Unit Agreement Name 8. Farm or Lease Name Driggers Fee 9. Well No. 1 10. Field and Pool, or Wildcat Wildcat 12. County Guadalupe
15. Elevation (Show whether DF, RT, GR, etc.) 5091' DF	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Re-entry of this well has been infeasible due to large amounts of junk encountered in the hole.

- We propose to plug and abandon this well in the following manner:
1. Set a 30 sack Class "C" cement plug at 2061' (Depth well was cleaned out to).
 2. Set a 30 sack plug at 1760' inside and out of the 9-5/8" stub.
 3. Set a 30 sack plug at 270" inside and out of the 13-3/8" casing.
 4. Set a 15 sack plug at surface and install a dry hole marker.

All plugs will have heavy salt mud between plugs.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Paul Rigdale TITLE Operations Manager DATE 3/19/82
 APPROVED BY Carl [Signature] TITLE REGIST DATE 3-23-82
 CONDITIONS OF APPROVAL, IF ANY: