

Submit 3 Copies To Appropriate District Office
 District I
 1625 N. French Dr., Hobbs, NM 88240
 District II
 1301 W. Grand Ave., Artesia, NM 88210
 District III
 1000 Rio Brazos Rd., Aztec, NM 87410
 District IV
 1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
 Energy, Minerals and Natural Resources

Form C-103
 May 27, 2004

OIL CONSERVATION DIVISION
 1220 South St. Francis Dr.
 Santa Fe, NM 87505

WELL API NO.
 30-005-21095

5. Indicate Type of Lease
 STATE FEE

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
 (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well Gas Well Other

2. Name of Operator
 Pure Resources, LP

3. Address of Operator
 500 W Illinois Ave, Midland Texas 79707

4. Well Location
 Unit Letter N : 660 feet from the South line and 1980 feet from the West line
 Section 29 Township 13S Range 31E NMPM Chaves County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
 4051 (GR)

Pit or Below-grade Tank Application or Closure Will use above ground tanks

Pit type _____ Depth to Groundwater _____ Distance from nearest fresh water well _____ Distance from nearest surface water _____

Pit Liner Thickness: _____ mil Below-Grade Tank: Volume _____ bbls; Construction Material _____

7. Lease Name or Unit Agreement Name
 Oxy Federal Com

8. Well Number 2

9. OGRID Number
 150661

10. Pool name or Wildcat
 Chaves Queen Gas Area SE

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK PLUG AND ABANDON
 TEMPORARILY ABANDON CHANGE PLANS
 PULL OR ALTER CASING MULTIPLE COMPL

SUBSEQUENT REPORT OF:

REMEDIAL WORK ALTERING CASING
 COMMENCE DRILLING OPNS. P AND A
 CASING/CEMENT JOB

OTHER: Add additional pay in Queen OTHER:

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Workover Procedure-Add additional Queen perforations

Open perforations from 2581'-2594' (26 holes)
 PBTB at 2719'.

J-Lock packer w/ on-off tool set at 2528'. 2-3/8" tubing w/ 1.81" profile nipple.

1. Rig up wireline mast truck. Perforate from 2702'-2715' w/ 2 spf. Tie into Schlumberger CNL/LDT log dated 12/17/1990 and Black Warrior Gamma Ray/CCL dated 1/3/91.
2. Acidize w/ 750 gals 7-1/2% NeFe w/ 10% methanol. Drop 40 ball sealers at the start of the acid job.
3. Attempt to flow back well for cleanup. Rig up swabbing unit if needed.
4. Return well to production.

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines , a general permit or an (attached) alternative OCD-approved plan .

SIGNATURE Patricia Culpepper TITLE Agent DATE 3/28/05

Type or print name Patricia Culpepper E-mail address: pmculpe@aol.com Telephone No. 432/520-4184

APPROVED BY: Hayward Wink OCFIELD REPRESENTATIVE II/STAFF MANAGER DATE MAR 31 2005
 Conditions of Approval (if any):

