State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 5-27-2004

FILE IN TRIPLICATE	MUDDO YYYY A	CONSERVATION DIVISION	
DISTRICT 1 1625 N. French Dr. , Hobbs, NM 88240	FICES OCD	CONSERVATION DIVISION 1220 South St. Francis Dr. Santa Fe, NM 87505	WELL API NO. 30-025-28951
DISTRICT II	JAN 31 2014	Sama 1 c, 14141 07303	5. Indicate Type of Lease
1301 W. Grand Ave, Artesia, NM 88210	2011		STATE X FEE
DISTRICT III			6. State Oil & Gas Lease No.
1000 Rio Brazos Rd, Aztec, NM 87410	RECEIVED		
SUNDRY N	OTICES AND REPO	ORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR	PROPOSALS TO DRILL	OR TO DEEPEN OR PLUG BACK TO A	North Hobbs (G/SA) Unit Section 33
DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT" (Form C-101) for such proposals.)			
1. Type of Well:		1 ou	8. Well No. 323
Oil Well x 2. Name of Operator	Gas Well	Other	9. OGRID No. 157984
Occidental Permian Ltd.			3. GSMD No. 157704
3. Address of Operator			10. Pool name or Wildcat Hobbs (G/SA)
_2611 State Hwy 214 Denv	er City, TX 79323		
4. Well Location	,		
Unit Letter G : 2525'	Feet From The	North Line 1453	Feet From The <u>East</u> Line
Section 33	Township		B-E NMPM Lea County
		w whether DF, RKB, RT GR, etc.)	
	3642' KB		
Pit or Below-grade Tank Application	or Closure		
Pit Type Depth of Ground Water Distance from nearest fresh water well Distance from nearest surface water			
Pit Liner Thickness mil Below-Grade Tank: Volume bbls; Construction Material			
		0010, 0010, 00100	
12. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:			
PERFORM REMEDIAL WORK PLUG AND ABANDON X REMEDIAL WORK ALTERING CASING			
PERFORM REMEDIAL WORK	PLUG AND ABANI	DON x REMEDIAL WORK	ALTERING CASING
· =			
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRILLING	PPNS: PLUG & ABANDONMENT
TEMPORARILY ABANDON DULL OR ALTER CASING		commence drilling of casing test and cem	PPNS: PLUG & ABANDONMENT
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRILLING	PPNS: PLUG & ABANDONMENT
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Compressed work) SEE RULE 110	CHANGE PLANS Multiple Completion Departions (Clearly stat 3. For Multiple Comple	COMMENCE DRILLING C CASING TEST AND CEM OTHER:	PPNS. PLUG & ABANDONMENT ENT JOB Es, including estimated date of starting any
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Comproposed work) SEE RULE 110 1. RUPU. POOH w/ESP and p	CHANGE PLANS Multiple Completion Departions (Clearly stat 3. For Multiple Completions)	COMMENCE DRILLING C CASING TEST AND CEM OTHER: e all pertinent details, and give pertinent da	PPNS. PLUG & ABANDONMENT ENT JOB Es, including estimated date of starting any
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Compressed work) SEE RULE 110	CHANGE PLANS Multiple Completion Departions (Clearly stat 3. For Multiple Completions)	COMMENCE DRILLING C CASING TEST AND CEM OTHER: The all pertinent details, and give pertinent date to the compose of the compo	DPNS. PLUG & ABANDONMENT ENT JOB tes, including estimated date of starting any d completion or recompletion.
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed (proposed work) SEE RULE 110 1. RUPU. POOH w/ESP and p 2. Set CIBP at 4050'. Cap w/ 3. Circulate 10# MLF. 4. Perf and Sqz 30 sx of cmt	CHANGE PLANS Multiple Completion Departions (Clearly stat 3. For Multiple Completion rod equipment 20 sx of cmt 25 from 2655', WOC. Tag	COMMENCE DRILLING COMMENCE DRI	DPNS. PLUG & ABANDONMENT ENT JOB tes, including estimated date of starting any d completion or recompletion. During this procedure we plan to use
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed C proposed work) SEE RULE 110 1. RUPU. POOH w/ESP and p 2. Set CIBP at 4050'. Cap w/ 3. Circulate 10# MLF.	CHANGE PLANS Multiple Completion Departions (Clearly stat 3. For Multiple Completion rod equipment 20 sx of cmt 25 from 2655', WOC. Tag	COMMENCE DRILLING COMMENCE DRI	DPNS. PLUG & ABANDONMENT ENT JOB tes, including estimated date of starting any d completion or recompletion. During this procedure we plan to use the closed-loop system with a steel
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Comproposed work) SEE RULE 110 1. RUPU. POOH w/ESP and p 2. Set CIBP at 4050'. Cap w/ 3. Circulate 10# MLF. 4. Perf and Sqz 30 sx of cmt 5. Perf and sqz 50 sx of cmt	Operations (Clearly stat 3. For Multiple Completion or od equipment 20 sx of cmt from 2655', WOC. Tag from 2670', WOC. Tag	COMMENCE DRILLING COMMENCE DRI	DPNS. PLUG & ABANDONMENT ENT JOB tes, including estimated date of starting any d completion or recompletion. During this procedure we plan to use the closed-loop system with a steel ank and haul contents to the required
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Comproposed work) SEE RULE 110 1. RUPU. POOH w/ESP and p 2. Set CIBP at 4050'. Cap w/ 3. Circulate 10# MLF. 4. Perf and Sqz 30 sx of cmt 5. Perf and sqz 50 sx of cmt	CHANGE PLANS Multiple Completion Departions (Clearly stat 3. For Multiple Completion rod equipment 20 sx of cmt from 2655', WOC. Tag I and circulate to surfat	COMMENCE DRILLING COMMENCE DRI	DPNS. PLUG & ABANDONMENT ENT JOB tes, including estimated date of starting any d completion or recompletion. During this procedure we plan to use the closed-loop system with a steel
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed C proposed work) SEE RULE 110 1. RUPU. POOH w/ESP and p 2. Set CIBP at 4050'. Cap w/ 3. Circulate 10# MLF. 4. Perf and Sqz 30 sx of cmt f 5. Perf and sqz 50 sx of cmt f 6. Perforate at 400'. Sqz well	CHANGE PLANS Multiple Completion Departions (Clearly stat 3. For Multiple Completion of equipment 20 sx of cmt from 2655', WOC. Tag from 2655', WOC. Tag and circulate to surfa	COMMENCE DRILLING COMMENCE DRI	DPNS. PLUG & ABANDONMENT ENT JOB tes, including estimated date of starting any d completion or recompletion. During this procedure we plan to use the closed-loop system with a steel ank and haul contents to the required
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Comproposed work) SEE RULE 110 1. RUPU. POOH w/ESP and pool 2. Set CIBP at 4050'. Cap w/good 3. Circulate 10# MLF. 4. Perf and Sqz 30 sx of cmt for second 5. Perf and sqz 50 sx of cmt for second 6. Perforate at 400'. Sqz well 7. Cut off wellhead and instated	CHANGE PLANS Multiple Completion Departions (Clearly stat 3. For Multiple Completion of equipment 20 sx of cmt from 2655', WOC. Tag from 2655', WOC. Tag and circulate to surfa	COMMENCE DRILLING COMMENCE DRI	DPNS. PLUG & ABANDONMENT ENT JOB tes, including estimated date of starting any d completion or recompletion. During this procedure we plan to use the closed-loop system with a steel ank and haul contents to the required
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Comproposed work) SEE RULE 110 1. RUPU. POOH w/ESP and pool 2. Set CIBP at 4050'. Cap w/good 3. Circulate 10# MLF. 4. Perf and Sqz 30 sx of cmt for second 5. Perf and sqz 50 sx of cmt for second 6. Perforate at 400'. Sqz well 7. Cut off wellhead and instated	CHANGE PLANS Multiple Completion Departions (Clearly stat 3. For Multiple Completion of equipment 20 sx of cmt from 2655', WOC. Tag from 2655', WOC. Tag and circulate to surfa	COMMENCE DRILLING COMMENCE DRI	DPNS. PLUG & ABANDONMENT ENT JOB tes, including estimated date of starting any d completion or recompletion. During this procedure we plan to use the closed-loop system with a steel ank and haul contents to the required
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Of proposed work) SEE RULE 110 1. RUPU. POOH w/ESP and p 2. Set CIBP at 4050'. Cap w/ 3. Circulate 10# MLF. 4. Perf and Sqz 30 sx of cmt f 5. Perf and sqz 50 sx of cmt f 6. Perforate at 400'. Sqz well 7. Cut off wellhead and install 8. Clean up location, remove	CHANGE PLANS Multiple Completion Departions (Clearly stat 3. For Multiple Completion of equipment 20 sx of cmt from 2655'. WOC. Tag from 2670'. WOC. Tag and circulate to surfa all dry hole marker with e anchors.	COMMENCE DRILLING OF CASING TEST AND CEME OTHER: The all pertinent details, and give pertinent date of the details. Attach wellbore diagram of propose of the details. The act of the details of the details of the details. The details of the deta	DPNS. PLUG & ABANDONMENT ENT JOB tes, including estimated date of starting any d completion or recompletion. During this procedure we plan to use the closed-loop system with a steel ank and haul contents to the required
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Comproposed work) SEE RULE 110 1. RUPU. POOH w/ESP and pose to complete to	CHANGE PLANS Multiple Completion Deparations (Clearly stat 3. For Multiple Completion or equipment 20 sx of cmt from 2655'. WOC. Tag from 2670'. WOC. Tag and circulate to surfa all dry hole marker with e anchors.	COMMENCE DRILLING OF CASING TEST AND CEME OTHER: The all pertinent details, and give pertinent date of the details. Attach wellbore diagram of propose of the details. The details of the	DPNS. PLUG & ABANDONMENT ENT JOB Les, including estimated date of starting any d completion or recompletion. During this procedure we plan to use the closed-loop system with a steel ank and haul contents to the required isposal per ODC Rule 19.15.17 Lify that any pit or below-grade tank has been/will be
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed C proposed work) SEE RULE 110 1. RUPU. POOH w/ESP and p 2. Set CIBP at 4050'. Cap w/ 3. Circulate 10# MLF. 4. Perf and Sqz 30 sx of cmt 5. Perf and sqz 50 sx of cmt f 6. Perforate at 400'. Sqz well 7. Cut off wellhead and insta 8. Clean up location, remove	CHANGE PLANS Multiple Completion Deparations (Clearly stat 3. For Multiple Completion or equipment 20 sx of cmt from 2655'. WOC. Tag from 2670'. WOC. Tag and circulate to surfa all dry hole marker with e anchors.	COMMENCE DRILLING OF CASING TEST AND CEME OTHER: The all pertinent details, and give pertinent date etions: Attach wellbore diagram of propose of the case. Top well-off as necessary. The labeling.	DPNS. PLUG & ABANDONMENT ENT JOB tes, including estimated date of starting any d completion or recompletion. During this procedure we plan to use the closed-loop system with a steel ank and haul contents to the required isposal per ODC Rule 19.15.17 Ify that any pit or below-grade tank has been/will be tive OCD-approved
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oproposed work) SEE RULE 110 1. RUPU. POOH w/ESP and p 2. Set CIBP at 4050'. Cap w/ 3. Circulate 10# MLF. 4. Perf and Sqz 30 sx of cmt f 6. Perforate at 400'. Sqz well 7. Cut off wellhead and insta 8. Clean up location, remove I hereby certify that the information above constructed or closed according to NMOCD guideline	CHANGE PLANS Multiple Completion Operations (Clearly stat 3. For Multiple Completion of equipment 20 sx of cmt from 2655', WOC. Tag from 2655', WOC. Tag and circulate to surfat all dry hole marker wit anchors. is true and complete to the es , a general	COMMENCE DRILLING OF CASING TEST AND CEM OTHER: The all pertinent details, and give pertinent date etions: Attach wellbore diagram of propose of the composition of	DPNS: PLUG & ABANDONMENT ENT JOB tes, including estimated date of starting any d completion or recompletion. During this procedure we plan to use he closed-loop system with a steel ank and haul contents to the required isposal per ODC Rule 19.15.17 Ify that any pit or below-grade tank has been/will be tive OCD-approved DATE 1/30/2014
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oproposed work) SEE RULE 110 1. RUPU. POOH w/ESP and p 2. Set CIBP at 4050'. Cap w/ 3. Circulate 10# MLF. 4. Perf and Sqz 30 sx of cmt 5. Perf and sqz 50 sx of cmt of the complete	CHANGE PLANS Multiple Completion Operations (Clearly stat 3. For Multiple Completion of equipment 20 sx of cmt from 2655', WOC. Tag from 2655', WOC. Tag and circulate to surfat all dry hole marker wit anchors. is true and complete to the es , a general	COMMENCE DRILLING OF CASING TEST AND CEMPOTHER: The all pertinent details, and give pertinent date etions: Attach wellbore diagram of propose of the composition of	DPNS: PLUG & ABANDONMENT ENT JOB tes, including estimated date of starting any d completion or recompletion. During this procedure we plan to use he closed-loop system with a steel ank and haul contents to the required isposal per ODC Rule 19.15.17 Ify that any pit or below-grade tank has been/will be tive OCD-approved DATE 1/30/2014
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oproposed work) SEE RULE 110 1. RUPU. POOH w/ESP and p 2. Set CIBP at 4050'. Cap w/ 3. Circulate 10# MLF. 4. Perf and Sqz 30 sx of cmt 5. Perf and sqz 50 sx of cmt 6. Perforate at 400'. Sqz well 7. Cut off wellhead and insta 8. Clean up location, remove I hereby certify that the information above constructed or closed according to NMOCD guideline SIGNATURE TYPE OR PRINT NAME Steve Sr	CHANGE PLANS Multiple Completion Operations (Clearly stat 3. For Multiple Completion of equipment 20 sx of cmt from 2655', WOC. Tag from 2655', WOC. Tag and circulate to surfat all dry hole marker wit anchors. is true and complete to the es , a general	COMMENCE DRILLING OF CASING TEST AND CEM OTHER: The all pertinent details, and give pertinent date etions: Attach wellbore diagram of propose of the composition of	DPNS: PLUG & ABANDONMENT ENT JOB tes, including estimated date of starting any d completion or recompletion. During this procedure we plan to use he closed-loop system with a steel ank and haul contents to the required isposal per ODC Rule 19.15.17 Ify that any pit or below-grade tank has been/will be tive OCD-approved DATE 1/30/2014
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe Proposed or Completed Oproposed work) SEE RULE 110 1. RUPU. POOH w/ESP and p 2. Set CIBP at 4050'. Cap w/ 3. Circulate 10# MLF. 4. Perf and Sqz 30 sx of cmt 5. Perf and sqz 50 sx of cmt 6. Perforate at 400'. Sqz well 7. Cut off wellhead and insta 8. Clean up location, remove I hereby certify that the information above constructed or closed according to NMOCD guideline SIGNATURE TYPE OR PRINT NAME Steve Sr	CHANGE PLANS Multiple Completion Operations (Clearly stat 3. For Multiple Completion of equipment 20 sx of cmt from 2655', WOC. Tag from 2655', WOC. Tag and circulate to surfat all dry hole marker wit anchors. is true and complete to the es , a general	COMMENCE DRILLING OF CASING TEST AND CEM OTHER: The all pertinent details, and give pertinent date etions: Attach wellbore diagram of propose of the composition of	DPNS: PLUG & ABANDONMENT ENT JOB tes, including estimated date of starting any d completion or recompletion. During this procedure we plan to use he closed-loop system with a steel ank and haul contents to the required isposal per ODC Rule 19.15.17 Ify that any pit or below-grade tank has been/will be tive OCD-approved DATE 1/30/2014

Occidental Permian Ltd. NHSAU #323 30-025-28951 Surface: 2525' FNL and 1453' FEL Unit Letter 'G' Section 33 T18S, R38E Lea County, New Mexico 13 3/8" 70# @ 40' with cmt to surface Perf at 400', Sqz 9 5/8", 36#, K-55 at 1517 Cmt w/ 650 sx Perf at 1655, Sqz w/50sx Circulate. Perf at 2635', Sqz w/50sx CIBP at 3953' Cap w/20 sx cmt San Andres Open Perforations 4003-4221' (gross) 7" 20#, K-55 @ 4370 - PBTD at 4320 (cmt) cmt w/925 sx TOC 3012' (CBL)

Returns seen at surface