Submit 1 Copy To Appropriate District	State of New Mexico		Form C-103
Office <u>District I</u> – (575) 393-6161	Energy, Minerals and Natural Resources		Revised July 18, 2013
1625 N. French Dr., Hobbs, NM 88240 <u>District II</u> – (575) 748-1283			WELL API NO. 30-025-42086
811 S. First St., Artesia, NM 88210 District III – (505) 334-6178	OIL CONSERVATION DIVISION		5. Indicate Type of Lease
1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Francis Dr. Santa Fe, NM 87505		STATE FEE
<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM	Santa Pe, 1444 07303		6. State Oil & Gas Lease No.
87505 SUNDRY NOT	ICES AND REPORTS ON WELLS		7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPO	SALS TO DRILL OR TO DEEPEN OR PLU		Hearns 27 State Com
PROPOSALS.)	CATION FOR PERMIT" (FORM C-101) FO)BBS OCD	
1. Type of Well: Oil Well	Gas Well Other	OCO OCD	8. Well Number 301H
2. Name of Operator EOG Resources, Inc.	DEC 0 5 2014		9. OGRID Number 7377
3. Address of Operator			10. Pool name or Wildcat
P.O. Box 2267 Midla	· · · · · ·	FORMS ACTION	Triste Draw; Bone Spring, East
4. Well Location Unit Letter M 210 South South line and line and line line			
Section 27		inic and nge 33E	NMPM County Lea
11. Elevation (Show whether DR, RKB, RT, GR, etc.)			
3480' GR			
12 Cheek Ammonnista Pay to Indicate Nuture of Notice Papert or Other Date			
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK □ PLUG AND ABANDON □ REMEDIAL WORK □ ALTERING CASING			
PERFORM REMEDIAL WORK ☐ TEMPORARILY ABANDON ☐	PLUG AND ABANDON ☐ CHANGE PLANS ☒	<u> </u>	
PULL OR ALTER CASING			
DOWNHOLE COMMINGLE			
CLOSED-LOOP SYSTEM		OTUED.	E
OTHER: OTHER:			
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of			
proposed completion or recompletion.			
EOG Resources requests an amendment to our approved APD for this well to reflect an addition to our production cement job:			
1. Pump 5 mCi (millicurie) of Scandium 46 radioactive tracer in the last 20 bbls of a 160 bbl gelled fresh water spacer			
system.			
 a. Scandium RA Tracer (Sc-46, 40/70 mesh ceramic proppant bead, Halflife - 83.8 days) 2. Pump 5 mCi (millicurie) of Iridium 192 radioactive tracer in the last 20 bbls of a 50 bbl surfactant spacer system. 			
a. Iridium RA Tracer (Ir-192, 40/70 mesh ceramic proppant bead, Halflife - 74 days.			
Pump lead cement Pump middle cement			
5. Pump tail cement			
Displace with fresh water.Cement is designed to tie back to intermediate casing string. Radioactive tracer is designed to remain below ground surface.			
The top of radioactive to	acers will be verified with a spectral of	amma ray log.	1
6 15	2: 21 2		
Spud Date:	Rig Release Dat	e:	
I hereby certify that the information above is true and complete to the best of my knowledge and belief.			
De mulatoria Ameliata			
SIGNATURE TITLE Regulatory Analysis		DATE	
Type or print name Stan Wagne	er E-mail address		PHONE: 432-686-3689
For State Use Only			
Potentour Fusioner 11/06/14			
APPROVED BY: TITLE Petroleum Engineer DATE /			