form 31,60-5 (March 2012)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

(25)
TELLO CARGE

FORM APPROVED
OMB No. 1004-0137

Expires: October 31, 2014

5. Lease Serial No. NMNM0127782

6. If Indian, Allottee or Tribe Name

					ch proposals				
	SUBMIT	IN TRIPLIC	ATE - Other	r instructions o	n page 2.	~[]	7. If Unit of CA/A	greement, Nam	e and/or No.
1. Type of Well					n page 2. HOBBS O	سام			
Oil Well	Gas Wo	:11 [Other			2015	8. Well Name and TKL Federal 27	No. /	
Name of Operator Ridgeway Arizona Oil Co	rp /				JUL 22	((),~	9. API Well No. 30-041-10502	7	
3a. Address	<u> </u>			3b. Phone No.	(include àrea coa	e)	10. Field and Pool	or Exploratory	Area
200. N Loraine, STE 1440 Midland, TX 79701				432-242-454	(include area coa	AED	Chaveroo, San A		
4. Location of Well (Footage 660 FNL & 660 FEL Sec.27,07S,33E	ge, Sec., T.,R	.,M., or Surv	ey Description	1)			11. County or Paris Roosevelt Count	•	
	12. CHECI	C THE APPR	OPRIATE BO	OX(ES) TO IND	ICATE NATURE	OF NOTI	CE, REPORT OR O	THER DATA	
TYPE OF SUBMISS	SION				TY	E-P	ERMITTING	<swd< td=""><td>INJECTION></td></swd<>	INJECTION>
Notice of Intent		Acidiz	æ	Deep			NVERSION_		RBDMS
•		Alter (Casing	Fract	ure Treat	RE	TURN TO		ΓΑ
Subsequent Report			g Repair		Construction	CSI	NG	C	HG LOC_
Final Abandonment N	lotice		e Plans - ert to Injection	✓ Plug ☐ Plug	and Abandon	INT	TO PARK	P&A NR_	P&A R
Attach the Bond under following completion of testing has been compledetermined that the site. In response to WO# 14R	of the involve eted. Final A is ready for	d operations. bandonment	If the operat Notices must	ion results in a n	ultiple completion	or recom	pletion in a new inter	rval, a Form 31	60-4 must be filed once
Ridgeway Arizona Oil Coand well bore diagram.	rp (Ridgewa	y) requests	approval to	plug and aband	don TKL Federal	27 #1 ac	cording to the attac	ched proposed	d plugging procedure
Ridgeway or a representa	ative of Ridg	eway will co	ontact BLM 2	hours prior to	beginning pluggi	ng proced	dures.		, r
•							• •		vei".
APPROVI ENDING	ED FOR	<u> </u>	nont	TH PERIOD) -	c	SEE ATT/ CADITICASE	ACHED F OF AFT	FOR PROVAL
14. I hereby certify that the fe	oregoing is tri	ue and correct	Name (Printe	ed/Typed)		· · · · · ·			
Jana True	$\longrightarrow \bigwedge$				Title Production	n/Regula	tory Mgr		
Signature O	a L				Date 04/09/20	14			
0		THI	S SPACE	FOR FEDE	RAL OR ST	TE OF	FICE USE	/	
Approved by	. Son	in .				edlo	gist	Date	/16/2014
Conditions of approval, if any that the applicant holds legal centitle the applicant to conduc	or equitable tit	le to those rig	his notice doe	es not warrant or o	ould Office		MOWELLE	ELD OFFI	od.
Title 18 U.S.C. Section 1001 : fictitious or fraudulent statem						d willfully	to make to any depart		of the United States any false,

(Instructions on page 2)

MAB/OCD 7/21/2015

AFMSS

JUL 27 2015

M



Ridgeway

Arizona Oil Corporation

St. Johns Helium/CO2 Project

Plugging Procedure TKL Federal 27 #1 API-No. 30-041-10502

- Prepare location and test anchors 1.
- 2. MIRU plugging rig
- 3. Notify OCD/BLM 24 hours prior to commencement of P & A procedure.
- 4. NDWH/NU BOP
- RIH w-4 ½ CIBP on 2 3/8 WS @ 4100' (+/-) within 100' of top perf 4050'(+/-) within 100' of top perf 4050'(+/-)
 - a. Spot 35' of cement on CIBP
 - b. WOC bump plug @ 4065" (+/-)
- 6. Load well with a minimum of 9 lb. mud and conduct MIT to 500 psi., test for leak off.
 - a. Bleed pressure off after MIT.
- MIRU WL and RIH w/perf gun to 3065' Wifness
 - perforate @ 2 JSPF a.
 - POOH w/WL b.
 - RDWL c.
- TIH w/WS Squeeze 40 SX cement plug @ 3065' to 2965' (+/-) w/fness
 - Wait on cement
 - b. Tag plug @ 2965 or above.
- MIRU WL and RIH w/perf gun to 1875 '
 - a. 8-5/8" csng. Shoe @ 18**50** ...
 - perforate @ 2 JSPF
 - POOH w/WL C.
 - **RDWL** d.
- 10. TIH w/WS Squeeze 40 SX cement plug @ 1875' to 1775'. W. Inc. 19
 - Wait on cement
 - Tag plug @ 1775' or above
- 11. MiRU WL and RIH w/perf gun to 900'
 - perforate @ 2 JSPF a.
 - POOH w/WL b.
 - C. **RDWL**
- 12. TIH w/WS Squeeze 40 SX cement plug @ 900' to 800'
 - Wait on cement
 - Tag plug @ 800' or above
- 13. MIRU WL and RIH w/perf gun to 60'
 - a. perforate @ 2 JSPF
 - POOH w/WL
 - **RDWL**
- 14. TIH w/WS Circulate cement plug from 60' to surface

- Wait on cement
- Cut off well head b.
- 15. RDMO Plugging Rig
 - Install P & A marker plate
 - Cut off dead men b.
 - Remediate Location

Co. Rep	0	
Well Name Field County State Date Date Comp	TKL Federal 27	Well No. 1
Field	Chaveroo	
County	Roosevelt	
State	NM	
Date	1/0/1900	
Date Comp		
KB	0.00	

Description	O.D.	Grade	Weight	Depth	Cmt Sx	тос
Surface Csg	7	0	20	1850	375	0
Inter Csg	0	0	0	0	0	0
Prod Csg	4 1/2	0	9 1/2	4398	350	0
Liner O.D.	0	0	0	0	0	0

Lease TKL Federal 27 Well # 1 Field Chaveroo Well Tect Data BOPPD BWPD McF Well Tect Data BOPPD BWPD McF Well Tect Data BOPPD BWPD McF Well Tect Data Botton McF Well Tect Data Botton Well Tect Well Tect Data Well Tect Well Tect Well Tect Data Well Tect Well Tect Well Tect Data Well Tec	Well Test Data BOPD BWPD MCF Unit Name & Size Perforations 4150-4280 TBG Data Pump Size Strokes Per. Min. Stroke Length Seat Nipple Tension Rods String Taper 1 Taper 2 TAC Rod Grade Taper 3 Taper 4 Predicitive Load Actual Load LIST DATES, REASON FOR FAILURES & MEASURES TAKEN TP PREVENT S	SAID Perf @ 900'
Well Test Data BOPD BWPD MCF INTO NAME & Size Perforations 4150-4280 Perforations 4150-4280 Perforations Flower Perforations At 150-4280 Perforations Perf	Well Test Data BOPD BWPD MCF Unit Name & Size Perforations 4150-4280 TBG Data Pump Size Stroke Per. Min. Stroke Length Seat Nipple Tension Rods String Taper 1 Taper 2 TAC Rod Grade Taper 3 Taper 4 Predicitive Load Actual Load LIST DATES, REASON FOR FAILURES & MEASURES TAKEN TP PREVENT SFAILURES & NON FAILURE PULLS. Possible Packer @ 4141-4146 according to OCD records	SAID Perf @ 900'
Perforations A150-4280 Pump Size	Perforations 4150-4280 TBG Data Pump Size Strokes Per. Min. Stroke Length Seat Nipple Tension Rods String Taper 1 Taper 2 TAC Rod Grade Taper 3 Taper 4 Predicitive Load Actual Load LIST DATES, REASON FOR FAILURES & MEASURES TAKEN TP PREVENT SEALURES & NON FAILURE PULLS.	Perf @ 900'
TIEG Data Strokes Per, Min. Stroke Length Seat Nipple Tension Rods String Taper 1 Taper 2 TAC Rod Grade Taper 3 Taper 4 Predictive Load Lust Dates, RASON FOR FAILURES RASON FOR FAILURES A MEASURES TAKEN TP PREVENT SAID FAILURES & NON FAILURE PULLS. Possible Packer @ 4141-4146 according to OCD records Penf @ 907 Sqr 40 SX LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Penf @ 3045 Sqr 40 SX	TBG Data Pump Size Strokes Per. Min. Strokes Length Seat Nipple Tension Rods String Taper 1 Taper 2 TAC Rod Grade Taper 3 Taper 4 Predicitive Load Actual Load LIST DATES, REASON FOR FAILURES & MEASURES TAKEN TP PREVENT SEALURES & NON FAILURE PULLS.	Perf @ 900'
Strokes Per. Min. Stroke Length Seat Nipple Tension Rodes String Insper 1 Taper 2 Taper 4 Predictive Load Lat Dates, REASON FOR FAILURES & MEASURES TAKEN TP PREVENT SAID FAILURES & NON FAILURE PULLS. Possible Packer @ 4141-4146 according to OCD records Pert @ 950 Str. 40 SX Str.	Strokes Per. Min. Stroke Length Seat Nipple Tension Rods String Taper 1 Taper 2 TAC Rod Grade Taper 3 Taper 4 Predicitive Load Actual Load LIST DATES, REASON FOR FAILURES & MEASURES TAKEN TP PREVENT S FAILURES & NON FAILURE PULLS.	Perf @ 900'
Tensio Rods String Taper 1 Taper 2 TACO Rod Grade Taper 3 Taper 4 TACO Rod Grade Taper 3 Taper 4 Predictitive Load Actual Load LIST DATES, REASON FOR FAILURES & MEASURES TAKEN TP PREVENT SAID FAILURES & NON FAILURES & MEASURES TAKEN TP PREVENT SAID FAILURES & 4141-4146 according to OCD records Pert @ 5007 Sign 40 SX Pert @ 1875 Sign 40 SX LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Pert @ 3005 Sign 40 SX Perforations 4150-4280 35 Cmt Plug GISP @ 4100 400 ACTION ACTION ACTION Sign 40 SX Sign 40 SX	Tension Rods String Taper 1 Taper 2 TAC Rod Grade Taper 3 Taper 4 Predicitive Load Actual Load LIST DATES, REASON FOR FAILURES & MEASURES TAKEN TP PREVENT S FAILURES & NON FAILURE PULLS.	Perf @ 900'
TAC Traper 3 Taper 4 Taper 4 Taper 4 Taper 5 Taper 5 Taper 6 Taper 6 Taper 6 Taper 6 Taper 7 Taper 7 Taper 8 Taper 8 Taper 8 Taper 8 Taper 9 Tap	TAC Rod Grade Taper 3 Taper 4 Predicitive Load Actual Load LIST DATES, REASON FOR FAILURES & MEASURES TAKEN TP PREVENT S FAILURES & NON FAILURE PULLS.	Perf @ 900'
Perdictitive Load LUST DATES, REASON FOR FAILURES & MEASURES TAKEN TP PREVENT SAID FAILURES & NON FAILURE PULLS. Possible Packer @ 4141-4146 according to OCD records Perf @ 5007 Sqz 40 SX Perf @ 5005 Sqz 40 SX LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 5005 Sqz 40 SX	Predicitive Load Actual Load LIST DATES, REASON FOR FAILURES & MEASURES TAKEN TP PREVENT S FAILURES & NON FAILURE PULLS.	Perf @ 900'
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3005 Sqz 40 SX	LIST DATES, REASON FOR FAILURES & MEASURES TAKEN TP PREVENT S FAILURES & NON FAILURE PULLS.	Perf @ 900'
Perforations Perforations 4150-4280 Perforations A 150-4280 Perforation S		
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3065 Sqz 40 SX Perforations 4150-4280 325 Cml Pkg CIPP @ 4107		
Perforations 4150-4280 Perforations ASC MI Pkg CIPP @ 4107		
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3065 Sqz 40 SX Perf @ 307 M Plug CIBP @ 4100		
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3065 Sqz 40 SX Perf @ 307 M Plug CIBP @ 4100		
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3065 Sqz 40 SX Perf @ 307 M Plug CIBP @ 4100		
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3085 Sqz 40 SX Perf @ 3085 CIBP @ 4100 Perforations 4150-4280 CIBP @ 4100		
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3085 Sqz 40 SX Perf @ 3085 CIBP @ 4100 Perforations 4150-4280 CIBP @ 4100		
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3065 Sqz 40 SX Perf @ 307 M Plug CIBP @ 4100		
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3065 Sqz 40 SX Perf @ 307 M Plug CIBP @ 4100		
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3085 Sqz 40 SX Perf @ 3085 CIBP @ 4100 Perforations 4150-4280 CIBP @ 4100		
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3065 Sqz 40 SX Perf @ 307 M Plug CIBP @ 4100		
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3085 Sqz 40 SX Perf @ 3085 CIBP @ 4100 Perforations 4150-4280 CIBP @ 4100		
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3065 Sqz 40 SX Perf @ 307 M Plug CIBP @ 4100		
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3085 Sqz 40 SX Perf @ 3085 CIBP @ 4100 Perforations 4150-4280 CIBP @ 4100		
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3085 Sqz 40 SX Perf @ 3085 CIBP @ 4100 Perforations 4150-4280 CIBP @ 4100		Perf @ 1875
LIST ANY RECOMMENDATIONS TO PREVENT FUTURE FAILURES OR ANY COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURES. Perf @ 3065' Sqz 40 SX Perforations 4150-4280 CIBP @ 4100		
Perforations 4150-4280 Perforations Grade August 150-4280 Perforations 25' Cmt Plug CIBP @ 4100'		
Perforations 4150-4280 Perforations Grade August 150-4280 Perforations 25' Cmt Plug CIBP @ 4100'		
Perforations 4150-4280 Perforations Grade August 150-4280 Perforations 25' Cmt Plug CIBP @ 4100'		
Perforations 4150-4280 Perforations GIBP @ 4100'		
Perforations 4150-4280 Perforations GIBP @ 4100'		
Perforations 4150-4280 Perforations GIBP @ 4100'		
Perforations 4150-4280 Perforations GIBP @ 4100'		
Perforations 4150-4280 Perforations GIBP @ 4100'		<u></u>
Perforations 4150-4280 Perforations GIBP @ 4100'	LICT ANY DECOMMENDATIONS TO DESVENT SUTUDE SAN LIDES OF ANY	
Perf @ 3065' Sqz 40 SX Perforations 4150-4280 35' Cmt Plug C/BP @ 4100'		
Perforations 4150-4280 35' Cmt Plug CIBP @ 4100'	COMMENTS ON WELL CONDITIONS THAT WILL CONTRIBUTE TO FAILURE	
Perforations 4150-4280 35' Cmt Plug CIBP @ 4100		
, 4150-4280 35' Cmt Plug C/BP @ 4100'		942 40 3A W 124 125 125 125 125 125 125 125 125 125 125
, 4150-4280 35' Cmt Plug CIBP @ 4100'		
. 4150-4280 35' Cmt Plug CIBP @ 4100' CIBP @		
. 4150-4280 35' Cmt Plug CIBP @ 4100' CIBP @		
. 4150-4280 35' Cmt Plug CIBP @ 4100' CIBP @		
, 4150-4280 35' Cmt Plug CIBP @ 4100'		
, 4150-4280 35' Cmt Plug C/BP @ 4100'		
, 4150-4280 35' Cmt Plug C/BP @ 4100'		1
, 4150-4280 35' Cmt Plug C/BP @ 4100'	Perforations	
CIBP @ 4100'		35' Cmt Plug
		CIBP @ 4100'

BUREAU OF LAND MANAGEMENT Roswell Field Office 2909 West Second Street Roswell, New Mexico 88201 (575) 627-0272

Permanent Abandonment of Federal Wells Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

- 1. Plugging operations shall commence within ninety (90) days from the approval date of this Notice of Intent to Abandon. If you are unable to plug the well by the 90th day provide the BLM Roswell Field Office (RFO), prior to the 90th day, with the reason for not meeting the deadline and a date when the BLM Roswell Field Office can expect the well to be plugged. Failure to do so will result in enforcement action. Unless the well has been properly plugged, the rig shall not be removed from over the hole without prior approval.
- 2. <u>Notification</u>: Contact the BLM Roswell Field Office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, during office hours or after office hours call (575) 627-0205. Engineer on call during office hours phone (575) 627-0275 or phone (after hours) call (575) 626-5749.
- 3. <u>Blowout Preventers:</u> A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The minimum BOP requirement is a 2M system for a well not deeper than 9090 feet; a 3M system for a well not deeper than 13636 feet; and a 5M system for a well not deeper than 22727 feet.
- 4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at a rate of 25 sacks (50 pounds each) of gel per 100 barrels of water. Minimum nine (9) pounds per gallon.
- 5. <u>Cement Requirement:</u> Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. In lieu of a cement plug in cased hole, a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 50 feet of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either class "C" for up to 7500 feet of depth, mixed at 14.8 lbs./gal with 6.3 gallons of fresh water per sack or class "H" for deeper than 7500 feet plugs, mixed at 16.4 lbs./gal with 4.3 gallons of fresh water per sack.

- 6. Monument: Upon abandonment of the well, all casing shall be cut-off at the base of the cellar or 3-feet below final restored ground level (whichever is deeper). The well bore shall then be covered with a metal plate at least ¼ inch thick and welded in place. The following information shall be permanently inscribed on the dry hole marker: Well name and number, the name of the operator, the lease serial number, the surveyed location (the quarter-quarter section, township and range or other authorized survey designation acceptable to the authorized officer; such as metes and bounds).
- 7. Timing Limitation Lease Stipulation / Condition of Approval For Lesser Prairie-Chicken: Oil and gas activities including 3-D geophysical exploration, and drilling will not be allowed in lesser prairie-chicken habitat during the period from March I through June 15 annually. During that period, other activities that produce noise or involve human activity, such as the maintenance of oil and gas facilities, geophysical exploration other than 3-D seismic operations, and pipeline, road, and well pad construction, will be allowed except between 3:00 am and 9:00 am. The 3:00 am to 9:00 am restriction will not apply to normal, around-the-clock operations, such as venting, flaring, or pumping, which do not require a human presence during this period. Additionally, no new drilling will be allowed within up to 200 meters of leks known at the time of permitting. Normal vehicle use on existing roads will not be restricted. Exhaust noise from pump jack engines must be muffled or otherwise controlled so as not to exceed 75 db measured at 30 feet from the source of the noise.
- 8. <u>Subsequent Plugging Reporting:</u> Within 30 days after plugging work is completed, file one original and five copies of the Subsequent Report of Abandonment, Form 3160-5 to the BLM Roswell Field Office. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. **Show date well was plugged.**

Following the submittal and approval of the Subsequent Report of Abandonment, a Notice of Intent for Final Abandonment with the proposed surface restoration procedure must be submitted for approval.