

District I – (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II – (575) 748-1283
811 S. First St., Artesia, NM 88210
District III – (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV – (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

HOBBS OCD
OCT 03 2016
RECEIVED

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-025-25321
5. Indicate Type of Lease STATE FEE X
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Hodge
8. Well Number 001
9. OGRID Number 12254
10. Pool name or Wildcat Trinity; Wolfcamp

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☒ Gas Well Other

2. Name of Operator
Jimmy P Hodge dba JPH Oil Producers

3. Address of Operator
P.O. Box 565 Lovington, NM 88260

4. Well Location
Unit Letter P : 700 feet from the South line and 810 feet from the East line
Section 28 Township 12S Range 38E NMPM Lea County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐

OTHER: ☐

SUBSEQUENT I

REMEDIAL WORK ☐ INT TO PA Am
COMMENCE DRILLING OPNS. ☐ P&A NR
CASING/CEMENT JOB ☐ P&A R

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

SEE ATTACHED

NOTIFY OCD 24 HOURS PRIOR TO BEGINNING PLUGGING OPERATIONS


I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE Agent DATE 9/29/16
Type or print name Bobby Stearns E-mail address: bobbystearns1@yahoo.com PHONE: 505-760-2482
For State Use Only
APPROVED BY: [Signature] TITLE Petroleum Engr. Specialist DATE 10/6/2016
Conditions of Approval (if any):

JPH Oil Producers
Hodge #1
30-025-25321
Proposed P&A Procedure

1. RIH with wireline and verify cement on top of existing CIBP at 4965' or higher.
2. Load and test casing to 500#.
3. Cut and pull 5 1/2" casing from 4566'.
4. RIH with work string, circulate MLF and spot 50 sx Class C cement from 4616'. WOC and tag at 4466' or higher. (Stub plug and intermediate shoe plug)
5. Spot 35 sx Class C cement at 3065'. (Base salt)
6. Spot 35 sx Class C cement at 2290'. (Top salt)
7. Spot 35 sx Class C cement at 506'. WOC and tag above 406'. (Surface shoe)
8. Spot 20 sx Class C from 60' to surface.
9. Cut off wellhead and verify cement is to surface on all strings of casing. Install regulation dryhole marker.

JPH Oil Producers
Hodge #1
API 30-025-25321
WBD Before P&A



JPH Oil Producers
Hodge #1
API 30-025-25321
WBD After P&A

20 sx cmt 60' to surface.

35 sx cmt @ 506' Surface Shoe
WOC and tag.

35 sx cmt @ 2290' Top Salt

35 sx cmt @ 3065' Base Salt

13 3/8" 48# casing set at
456' w/ 475 sx - Circ.

9 5/8" 40# & 43.5# casing set at
4516' w/ 1500 sx - Circ.

Cut and pull 5 1/2" casing
at 4566'. Spot 50 sx cmt
from 4616'. WOC and tag
at 4466' or higher. Stub plug
and Int. shoe plug.

Existing CIBP @ 5000'
w/ 35' cmt on top

*Well bore conditions below CIBP
are on file with OCD

TOC 9440'

5 1/2" 17# casing set at
12208' w/ 650 sx

