Form 3160-5 (June 2015)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0137 Expires: January 31, 2018

SUNDRY NOTICES AND REPORTS ON WELLS DAD FIELD CONTROL FOR

Do not use this	form for proposals to drill or to ve enteres	-		
Do not use this	torni for proposais to drill or to re-enterial	n Hal	of Indian	Allottee or Tribe Name
abandoned well.	form for proposals to drill or to re-enter at Use form 3160-3 (APD) for such proposals.	UHOL	JUST Malan,	rinotice of Tribe Name
		THE RESERVE TO THE RE	- 10	

SUBMIT IN TRIPLICATE - Other instr	ructions on page 2	0 0017	ement, Name and/or No.		
Type of Well	OCT 2	8. Well Name and No. HAMON FED CO. 9. API Well No. 30-025-43251-0			
Name of Operator LEGACY RESERVES OPERATING LPE-Mail: mdickson@	MATT DICKSON REC	9. API Well No. 30-025-43251-0	00-X1		
3a. Address 303 W WALL SUITE 1600 MIDLAND, TX 79702	3b. Phone No. (include area code) Ph: 432-689-5200	10. Field and Pool or TEAS	Exploratory Area		
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)		11. County or Parish,	11. County or Parish, State		
Sec 18 T20S R34E Lot 1 320FNL 1045FWL		LEA COUNTY,	NM		
12. CHECK THE APPROPRIATE BOX(ES)	TO INDICATE NATURE OF	NOTICE, REPORT, OR OT	HER DATA		
TYPE OF SUBMISSION	TYPE OF	ACTION			
☑ Notice of Intent ☐ Acidize	□ Deepen	☐ Production (Start/Resume)	■ Water Shut-Off		
☐ Alter Casing	☐ Hydraulic Fracturing	☐ Reclamation	■ Well Integrity		
☐ Subsequent Report ☐ Casing Repair	■ New Construction	☐ Recomplete	Other		
☐ Final Abandonment Notice ☐ Change Plans	Plug and Abandon	□ Temporarily Abandon			
☐ Convert to Injection	☐ Plug Back	■ Water Disposal			
Attach the Bond under which the work will be performed or provide to following completion of the involved operations. If the operation rest testing has been completed. Final Abandonment Notices must be file determined that the site is ready for final inspection. Legacy Reserves Operating respectfully request approvintermediate casing cement procedures. This option wor utilizing two DV tools. Both DV tools shall be set a minim shoe and a minimum of 200 feet above the current shoe placement. Please see the following update to the ceme	ults in a multiple completion or record only after all requirements, including all to add an additional option all allow for a three-stage centum of 50 feet below the previous and adjust cement proportion anting details for a three-stage SEE AT CONDITION	npletion in a new interval, a Form 310 agreelamation, have been completed for the nent job ous casing nately based on cement job. TACHED FOR TIONS OF APPRO	50-4 must be filed once and the operator has		
For LEGACY RES Committed to AFMSS for processi		o the Hobbs n 06/30/2017 (17DLM1405SE)			
Name (Printed/Typed) MATT DICKSON	Title DRILLIN	G ENGINEER			
Signature (Electronic Submission)	Date 06/23/20	17			
THIS SPACE FO	R FEDERAL OR STATE O	FFICE USE			
Approved By MUSTAFA HAQUE Conditions of approval, if any, are attached. Approval of this notice does a certify that the applicant holds legal or equitable title to those rights in the which would entitle the applicant to conduct operations thereon.		JM ENGINEER	Date 10/03/2017		

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

Office Hobbs

(Instructions on page 2) ** BLM REVISED ** BLM REVISED ** BLM REVISED ** BLM REVISED ** MURS /OCD 10/23/2017

Hamon #10H

Intermediate Casing

In the event that circulation is lost (> 50%) while drilling the 12-1/4" intermediate hole in the Capitan Reef at +/-4000', we will plan to install a DV tool and external casing packer within 200' of the top depth where lost circulation occurred and will pump a two-stage cement job with the potential to add an additional DV tool for a three-stage cement job. If there is no lost circulation a single stage cementing procedure will be followed. Legacy plans to cement to surface regardless of whether a single stage, 2-stage or 3-stage procedure is implemented.

No DV tool (80% excess on lead & 80% excess on tail to design for cement top at surface)

<u>Lead:</u> 1400 sx (35:65) poz (fly ash) class C cement+ 4% bwoc bentonite II + 5% bwoc MPA-5 + 0.25% bwoc FL- 52 + 5 lbs/sack LCM-1 + 0.125 lbs/sk cello flake+ 0.005 lbs/sk defoamer + 0.005 gps FP-6L + 1.2% bwoc Sodium Metasilicate + 5% bwow Sodium Chloride (12.5 ppg, 2.13 cfps, 8.81 gps wtr)

<u>Tail:</u> 200 sx class C cement (14.80 ppg, 1.33 cfps, 6.35 gps wtr)

With (1) DV Tool (100% excess on lead & 100% excess on tail to design for cement top at surface)

Assuming DV tool set at 3950' but if the setting depth changes, cement volumes will be adjusted proportionately.

Stage 1

<u>Lead:</u> 400 sx (35:65) paz (fly ash) class C cement+ 4% bwoc Bentonite II+ 5% bwoc MPA-5 + 0,25% bwoc FL-52 + 5 lbs/sack LCM-1 + 0.125 lbs/sk cello flake+ 0.005 lbs/sk defoamer + 0.005 gps FP-6L + 1.2% bwoc Sodium Metasilicate + 5% bwow Sodium Chloride (12.5 ppg, 2.13 cfps, 8.81 gps wtr)

<u>Tail:</u> 200 sx class C cement (14.80 ppg, 1.33 cfps, 6.35 gps wtr)

Stage 2

<u>Lead</u>: 1100 sx (35:65) paz (fly ash) class C cement+ 4% bwoc bentonite II + 5% bwoc MPA-5 + 0,25% bwoc FL-52 + 5 lbs/sack LCM-1 + 0.125 lbs/sk Cello Flake+ 0.005 lbs/sk Static Free+ 0.005 gps FP-6L + 1.2% bwoc Sodium Metasilicate + 5% bwow Sodium Chloride (12.5 ppg, 2.13 cfps, 8.81 gps wtr)

Tail: 200 sx class C cement (14.80 ppg, 1.33 cfps, 6.35 gps wtr)

With (2) DV Tools (100% excess on lead & 100% excess on tail to design for cement top at surface)

Assuming one DV tool set at 3950' and one DV tool set at 1800' but if the setting depths change, cement volumes will be adjusted proportionately.

Stage 1

<u>Lead:</u> 400 sx (35:65) paz (fly ash) class C cement+ 4% bwoc Bentonite II+ 5% bwoc MPA-5 + 0,25% bwoc FL-52 + 5 lbs/sack LCM-1 + 0.125 lbs/sk cello flake+ 0.005 lbs/sk defoamer + 0.005 gps FP-6L + 1.2% bwoc Sodium Metasilicate + 5% bwow Sodium Chloride (12.5 ppg, 2.13 cfps, 8.81 gps wtr)

Tail: 200 sx class C cement (14.80 ppg, 1.33 cfps, 6.35 gps wtr)

Stage 2

<u>Lead</u>: 600 sx (35:65) paz (fly ash) class C cement+ 4% bwoc bentonite II + 5% bwoc MPA-5 + 0,25% bwoc FL-52 + 5 lbs/sack LCM-1 + 0.125 lbs/sk Cello Flake+ 0.005 lbs/sk Static Free+ 0.005 gps FP-6L + 1.2% bwoc Sodium Metasilicate + 5% bwow Sodium Chloride (12.5 ppg, 2.13 cfps, 8.81 gps wtr)

<u>Tail:</u> 200 sx class C cement (14.80 ppg, 1.33 cfps, 6.35 gps wtr)

Stage 3

<u>Lead</u>: 600 sx (35:65) paz (fly ash) class C cement+ 4% bwoc bentonite II + 5% bwoc MPA-5 + 0,25% bwoc FL-52 + 5 lbs/sack LCM-1 + 0.125 lbs/sk Cello Flake+ 0.005 lbs/sk Static Free+ 0.005 gps FP-6L + 1.2% bwoc Sodium Metasilicate + 5% bwow Sodium Chloride (12.5 ppg, 2.13 cfps, 8.81 gps wtr)

<u>Tail:</u> 200 sx class C cement (14.80 ppg, 1.33 cfps, 6.35 gps wtr)

Matt Dickson
Drilling Engineer
(432)689-5204
mdickson@legacylp.com

PECOS DISTRICT CONDITIONS OF APPROVAL

OPERATOR'S NAME: Legacy Reserves Operating LP

LEASE NO.: NM13276

WELL NAME & NO.: 10H-Hamon Fed Com A

SURFACE HOLE FOOTAGE: | 320'/N & 1045'/W

BOTTOM HOLE FOOTAGE | 330'/N & 430'/W, sec. 7

LOCATION: Section 18, T. 20 S., R.34 E., NMPM

COUNTY: Lea County, New Mexico

A. CASING

All previous COAs still apply except the following:

1. The minimum required fill of cement behind the 9 5/8 inch intermediate casing, which shall be set at approximately 5600 feet, is:

Option 1:

- a. Cement to surface. If cement does not circulate to the surface, the appropriate BLM office shall be notified and a temperature survey utilizing an electronic type temperature survey with surface log readout will be used or a cement bond log shall be run to verify the top of the cement. Temperature survey will be run a minimum of six hours after pumping cement and ideally between 8-10 hours after completing the cement job.
- b. Wait on cement (WOC) time for a primary cement job is to include the lead cement slurry due to potash.
- c. Wait on cement (WOC) time for a remedial job will be a minimum of 4 hours after bringing cement to surface or 500 pounds compressive strength, whichever is greater.
- d. If cement falls back, remedial cementing will be done prior to drilling out that string.

Option 2:

Operator has proposed DV tool at depth of 3950 feet, but will adjust cement proportionately if moved. DV tool shall be set a minimum of 50 feet below previous shoe and a minimum of 200 feet above current shoe. Operator shall submit sundry if DV tool depth cannot be set in this range.

	a.	First stage to DV tool:
		Cement to circulate. If cement does not circulate, contact the appropriate BLM office before proceeding with second stage cement job. Operator should have plans as to how they will achieve circulation on the next stage.
	b.	Second stage above DV tool:
		Cement to surface. If cement does not circulate see A.1.Option 1.a, c-d above. Wait on cement (WOC) time for a primary cement job is to include the lead cement slurry due to potash.
<u>Op</u>	tion 3:	
pro	portio l a min	has proposed DV tool at depth of 1800 feet and 3950 feet, but will adjust cement nately if moved. DV tool shall be set a minimum of 50 feet below previous shoe amount of 200 feet above current shoe. Operator shall submit sundry if DV tool not be set in this range.
	a.	First stage to DV tool:
		Cement to circulate. If cement does not circulate, contact the appropriate BLM office before proceeding with second stage cement job. Operator should have plans as to how they will achieve circulation on the next stage.
	b.	Second stage above DV tool:
		Cement to circulate. If cement does not circulate, contact the appropriate BLM office before proceeding with third stage cement job. Operator should have plans as to how they will achieve circulation on the next stage.
	c.	Third stage above DV tool:
		Cement to surface. If cement does not circulate see A.1.Option 1.a, c-d above. Wait on cement (WOC) time for a primary cement job is to include the lead cement slurry due to potash.
MI	IH 100	32017