

District I - (575) 393-6161

1625 N. French Dr., Hobbs, NM 88241

District II - (575) 748-1283

811 S. First St., Artesia, NM 88210

District III - (505) 334-6178

1000 Rio Brazos Rd., Aztec, NM 87410

District IV - (505) 476-3460

1220 S. St. Francis Dr., Santa Fe, NM

87505

HOBBBS OCD

JUL 20 2018

RECEIVED

## OIL CONSERVATION DIVISION

1220 South St. Francis Dr.

Santa Fe, NM 87505

WELL API NO.

30-025-06811

5. Indicate Type of Lease

STATE ☐FEE ☒

6. State Oil &amp; Gas Lease No.

FEE

7. Lease Name or Unit Agreement Name

FF HARDISON B

8. Well Number

8

9. OGRID Number

5380

10. Pool name or Wildcat

DRINKARD

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-103) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

XTO ENERGY INC.

3. Address of Operator

6401 HOLIDAY HILL ROAD MIDLAND, TEXAS 79701

4. Well Location

Unit Letter I : 1980 feet from the SOUTH line and 660 feet from the EAST line

Section

27

Township 21S

Range

37E NMPM

County

LEA

11. Elevation (Show whether DR, RKB, RT, GR, etc.)

3391 GR

## 12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

## NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐PLUG AND ABANDON ☒TEMPORARILY ABANDON ☐CHANGE PLANS ☐PULL OR ALTER CASING ☐MULTIPLE COMPL ☐DOWNHOLE COMMINGLE ☐CLOSED-LOOP SYSTEM ☐OTHER: ☐

## SUBSEQUENT I

REMEDIAL WORK ☐COMMENCE DRILLING OPNS. ☐CASING/CEMENT JOB ☐OTHER: ☐

INT TO PA PM

P&amp;A NR

P&amp;A R

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

XTO ENERGY INC. REQUESTS TO PA' THE REFERENCE WELL WITH THE FOLLOWING PROCEDURE:

1. TAG CIBP @5000.

2. PUH SPOT 20SX CLASS C CMT FROM 3319-3819 WOC (MIN OF 4 HRS) TAG

3. PUH SPOT 20 SX CLASS C CMT FROM 287-297 WOC (MIN OF 4 HRS) TAG

4. PERF AND SQZ 150 SX CLASS C CMT FROM 339 SURFACE. WOC

5. ND BOP AND CUT OFF HEAD 5' BELOW SURFACE. VERIFY CMT. SET P&amp;A MARKER.

See Attached  
Conditions of ApprovalNOTIFY OCD 24 HOURS PRIOR TO  
BEGINNING PLUGGING OPERATIONS

Spud Date:

01/01/1954

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

TITLE REGULATORY ANALYST

DATE 07/12/2018

Type or print name

PATRICIA DONALD

E-mail address: patricia.donald@xtoenergy.com

PHONE: 432-571-8220

For State Use Only

APPROVED BY:

TITLE P.E.S.

DATE 07/30/2018

Conditions of Approval (if any):


C103 INTENT TO P&A EXPIRES  
1 YEAR FROM DATE OF APPROVAL

Wellbore Hardison B 8u

Job &lt;no job&gt;

Date &lt;now&gt;

► II M M M M



## FF HARDISON B No. 8

### CONDITIONS OF APPROVAL

- 1) CIBP must be set within 100' of top perforation at 5470'.
- 2) Circulate MLF and pressure test casing. Spot 25 sx of cement on CIBP.
- 3) Spot 25 sx of cement at 3919'.
- 4) Perforate and squeeze 40 sx cement at 2837'. WOC & Tag at 2737' or better.
- 5) Perforate and squeeze 40 sx cement at 2360'. WOC & Tag at 2260' or better.
- 6) Perforate and squeeze 40 sx cement at 1120'. WOC & Tag at 1020' or better.
- 7) Perforate at 339'. Establish circulation out 10 ¾" x 7 5/8" and 7 5/8" x 5 ½" annulus. Circulate cement to surface leaving 5 ½" casing full.
- 8) Cut off wellhead 3' below ground level. Verify cement to surface all strings. Install upright P&A marker.