

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

HOBBS OCD

AUG 30 2019

State of New Mexico
Energy, Minerals and Natural Resources Department
Oil Conservation Division Hobbs District Office

BRADENHEAD TEST REPORT

Operator Name CML Exploration, LLC	API Number 30-025-36942
Property Name Duncan 32 State Com	Well No. 1

Surface Location									
UL - Lot	Section	Township	Range		Feet from	N/S Line	Feet From	E/W Line	County
H	32	17S	34E		2245	N	660	E	Lea

Well Status						DATE
TA'D WELL YES	NO	YES	SHUT-IN NO	INJECTOR NO	PRODUCER GAS	8/20/19

OBSERVED DATA

	(A)Surface	(B)Interm(1)	(C)Interm(2)	(D)Prod Casing	(E)Tubing
Pressure	0	0	N/A	0	0
Flow Characteristics					
Pull	Y/N	Y/N	Y/N	Y/N	CO2 <input type="checkbox"/>
Steady Flow	Y/N	Y/N	Y/N	Y/N	WTR <input type="checkbox"/>
Surges	Y/N	Y/N	Y/N	Y/N	GAS <input type="checkbox"/>
Down to nothing	Y/N	Y/N	Y/N	Y/N	Type of Fluid
Gas or Oil	Y/N	Y/N	Y/N	Y/N	Injected for
Water	Y/N	Y/N	Y/N	Y/N	Waterflood if
					applies

Remarks - Please state for each string (A,B,C,D,E) pertinent information regarding bleed down or continuous build up if applies.

A. Surface casing - No pressure, no blow.

B. Intermediate casing, - no pressure, no blow.

Signature: Brad Ashworth	OIL CONSERVATION DIVISION
Printed name: Brad Ashworth	Entered into RBDMS
Title: Wellsite Supervisor	Re-test
E-mail Address: ashworthb@cmlexp.com	
Date: 8/27/19	
Phone: 325-574-6297	
Witness:	

INSTRUCTIONS ON BACK OF THIS FORM

PERFORMING BRADENHEAD TEST

General Procedure for Bradenhead Test

- Identify: All valves prior to testing.
- Gauges: Install on each casing string to record pressure.
- Assure: That all valves are in good working condition and closed at least 24 hours prior to testing.
- Open: Each valve (Bradenhead, intermediate and casing valves) is to be opened separately.

Check Gauges: Record pressure on each gauge and casing string on BHT form. Open valves to atmosphere and record results on BHT form.

Designate what applies to the result of opening the valves for each string:

- | | |
|------------------------|-----------|
| • Blow or Puff | Yes or No |
| • Bled down to Nothing | Yes or No |
| • Steady Flow | Yes or No |
| • Oil or Gas | Yes or No |
| • Water | Yes or No |

Start: Injection or SWD pump so tubing pressure can be read.

Instructions below apply to the District 1 Hobbs office since this must be reported on a form.

In case of pressure:

1. Record pressure reading on gauge.
2. Bleed and note time elapsed to bleed down.
3. Leave valve open for additional observation.
4. Note any fluids expelled.

In absence of Pressure:

1. Leave valve open for additional observation.
2. Note types of fluids expelled.
3. Note if fluids persist throughout test.

Note: Tubing pressure on injection or SWD wells.

Test will be signed by person performing test with a contact phone number.