

Submit 1 Copy To Appropriate District Office	State of New Mexico Energy, Minerals and Natural Resources	Form C-103 Revised July 18, 2013		
<u>District I</u> - (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240	Energy, witherais and inatural Resources	WELL API NO. 30-025-21114		
<u>District II</u> – (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL CONSERVATION DIVISION	5. Indicate Type of Lease		
<u>District III</u> (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Francis Dr.	STATE FEE		
<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM	Santa Fe, NM 87505	6. State Oil & Gas Lease No.		
87505 SUNDRY NOTICE	ES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name		
(DO NOT USE THIS FORM FOR PROPOSA	LS TO DRILL OR TO DEEPEN OR PLUG BACK TO A	Northeast Pearl Queen Unit		
PROPOSALS.)	TION FOR PERMIT" (FORM C-101) FOR SUCH	0 37/1127		
1. Type of Well: Oil Well G 2. Name of Operator	as Well Other	9: OGRID Number		
3. Address of Operator	Breitburn Operating LP	370080		
1	Suite 1600 Houston, TX 77002	10. 1 ooi name or windcat		
4. Well Location	990 North	990 East		
Unit Letter:	feet from the line and	feet from theline		
Section 23	Township 19S Range 35E 11. Elevation (Show whether DR, RKB, RT, GR, etc.)	NMPM County Lea		
	3754'	,		
10 01 1 1				
12. Check Ap	propriate Box to Indicate Nature of Notice,	Report or Other Data		
NOTICE OF INT	<u> </u>	SEQUENT REPORT OF:		
<u> </u>	PLUG AND ABANDON REMEDIAL WOR CHANGE PLANS COMMENCE DR	<u> </u>		
	MULTIPLE COMPL CASING/CEMEN			
DOWNHOLE COMMINGLE		_		
CLOSED-LOOP SYSTEM	CTUED.	Б		
OTHER: 13. Describe proposed or complet	ed operations. (Clearly state all pertinent details, an	d give pertinent dates, including estimated date		
of starting any proposed work	c). SEE RULE 19.15.7.14 NMAC. For Multiple Co			
proposed completion or recon	npletion.			
Breitburn Operating LP proposes	to P&A the Northeast Pearl Queen Unit #009 in Janu	uary of 2020.		
W (1055 C 4975				
MIRU plugging rig ND wellhead and NU BOP	185 CS9 580 20 C/056 3118	BASE OF Galt		
1. MIRU plugging rig 2. ND wellhead and NU BOP 185 CS9 SPOT 25 3 Class C 3118 Bise of Galt 3. Load hole w/ plugging mud 4. Perforate 4.5 " casing @ 415' 3.5" P+5 50 5x Class C 2160 Top of Salt				
4. Perforate 4.5 " casing @ 415' 3 1 5 Pt 5 50 5 % (L 6 5) C 2 1 60 7 0 7 0 9 5 0 5 5 0 5 5 0 5 5 0 5 5 0 5 5 0 5 5 0 5				
6. Pull up WOC to set and tag for	depth			
7. Perforate 3.5" casing 100'				
S. Circulate cement to surface S. Erect dead well marker				
4"dia 4'T	all Above ground MKR	See Attached		
[Conditions of Approval		
Spud Date: 6-15-1968	Rig Release Date:			
I hereby certify that the information above is true and complete to the best of my knowledge and belief.				
	Regulatory Ar	nalyst 12-23-2019		
SIGNATURE	ITILE	DATE		
Type or print nameCharlotte	e Nash	avresources.com PHONE: 713-632-8730		
For State Use Only	A = A	.0 32 10		
APPROVED BY: You	TITLE CO H	DATE 17-23-19		
Conditions of Approval (if any):		•		



Displacement fluid wt =	0	ppg
Frac Gradient =	0	psi/ft
Tbg Length =	4865	ft
Tbg ID=	1.995	in
Tbg OD=	2.375	in
Liner ID =	3.068	in
Liner OD=	0	in
Csg ID =	4.052	in
Tbg Cap =	0.003866	bbls/ft
Liner Cap =	0.009144	bbls/ft
Liner-Tbg ann =	0.003664	bbls/ft
Csg Cap =	0.01595	bbls/ft
Liner Depth =	0	ft
Csg Depth =	5095	ft
Difference =	5095	ft
Full Tbg Vol =	19	bbls
Full liner Vol =	0	bbls
Full Csg Vol =	81	bbls
Wellbore Vol =	81	bbls



Displacement fluid wt =	0	ppg
Frac Gradient =	0	psi/ft
Tbg Length =	4865	ft
Tbg ID=	1.995	in
Tbg OD=	2.375	in
Liner ID =	3.068	in
Liner OD=	0	in
Csg ID =	4.052	in
Tbg Cap =	0.003866	bbls/ft
Liner Cap =	0.009144	bbls/ft
Liner-Tbg ann =	0.003664	bbls/ft
Csg Cap =	0.01595	bbls/ft
Liner Depth =	0	ft
Csg Depth =	5095	ft
Difference =	5095	ft
Full Tbg Vol =	19	bbls
Full liner Vol =	0	bbls
Full Csg Vol =		bbls
Wellbore Vol =	81	bbls

CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office I (Hobbs) at (575)-399-3221 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbis of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E)Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION