


UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
OMB No. 1004-0135
Expires November 30, 2000

SUNDRY NOTICES AND REPORTS ON WELLS
Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

SUBMIT IN TRIPLICATE - Other Instructions on reverse side



Lease Serial No. _____

6. Indian, Allottee or Tribe Name _____

7. Unit or CA/Agreement Name and/or No. _____

Well Name and No. Amoco Fed #2

9. API Well No. 2

10. Field and Pool, or Exploratory Area _____

11. County or Parish, State Chaves, NM

1. Type of Well
 Oil Well Gas Well Other

2. Name of Operator JR STARN'S

3a. Address PO Box 900 Crossroads, NM 88114

3b. Phone No. (include area code) 505-369-5015


4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
Sec. 23 T-7-S R-31-E
Footages ? 1980 S 1980 W

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
<input type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/Resume)	<input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing	<input type="checkbox"/> Fracture Treat	<input type="checkbox"/> Reclamation	<input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete	<input type="checkbox"/> Other _____
	<input type="checkbox"/> Change Plans	<input checked="" type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Temporarily Abandon	
	<input type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal	

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplate horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

See conditions of approval.
pg 2.



14. I hereby certify that the foregoing is true and correct

Name (Printed/Typed) D.G. Williamson Title Safety Consultant

Signature [Signature] Date 8/14/03

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by [Signature] Title PE Date 8/15/03

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office RFO

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

Amoco Federal #2
Plugging and Abandonment Procedure

Note: No records available on this well. Proceeding under assumption same as Amoco Federal #1.

13. MI and RU Wireline. GIH with gauge ring and tag PBT. GIH with 4-1/2" CIBP and set at ³⁹²⁵3950'. Dump ^{35'}30' cement on top of CIBP. Fill hole with gelled brine. GIH with 4-1/2" CIBP and set at 420'. Dump ^{35'}30' cement on top of CIBP. Set 60' surface plug. Dig out and cut off casing 3' below ground level. Weld seal plate on top of casing. Set dry hole marker. Clean location and remediate. ^{35'}

Additional plugs:

100' plug from 1930' - 2030'

100' plug from 1630' - 1730' - TAG