

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.
30-025-05136 ✓

5. Indicate Type of Lease
STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator
S & J OPERATING COMPANY

3. Address of Operator
P O BOX 2249, WICHITA FALLS, TEXAS 76307-2249

4. Well Location
Unit Letter B : 660 Feet From The NORTH Line and 1980 Feet From The EAST Line
Section 26 (NWNE) Township 14-S Range 37-E NMPM LEA County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
3824 GR

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

SHUT IN PRODUCING WELL. LAST PRODUCED 8-86. ON 10-19-92, SET CIBP AT 9250' AND CIRCULATED WELL WITH SALT WATER TREATED WITH CORROSION INHIBITOR. ON 10-20-92, DUMPED 35' OF CEMENT ON CIBP. ON 4-5-93, TESTED CASING AND LEAKED OFF. WILL PLUG AND ABANDON WELL.

*SEE ATTACHED

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Peyton S. Carnes, Jr. TITLE MANAGER OF OPERATIONS DATE 5-10-93
(817) 723-2166
TELEPHONE NO.

TYPE OR PRINT NAME PEYTON S. CARNES, JR.

(This space for State Use)
ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

MAY 18 1993

Denton North Wolfcamp Unit Well No. 15-2

Plugging Procedure:

- 1) Run tubing to 9215' and load hole with 9.5# drilling mud. Pull tubing.
- 2) Shoot off 7" casing at 6100'. Pull casing.
- 3) Run tubing. Spot plugs as follows:
 - a. 45 sack cement plug from 6150' to 6050' (50' inside and 50' outside of 7" stub). Tag plug after 2 hours.
 - b. 60 sack cement plug from 4775' to 4675' (50' below to 50' inside of 9 5/8" casing). Tag plug after 2 hours.
 - c. 50 sack cement plug from 2200' to 2100'. Tag plug after 2 hours.
 - d. Perforate 9 5/8" casing at 357' and break circulation to surface. Pump 250 sacks of cement and circulate to surface leaving 100' of cement in 9 5/8" casing.
 - e. 15 sack cement plug from 38' to 3'.
- 4) Cut off casing 3' below ground and install permanent marker. Clean up location.