

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-05384
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name B. E. Shipp
8. Well No. 1
9. Pool name or Wildcat Lovington Paddock
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3816' DF

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	2. Name of Operator Texaco Exploration and Production Inc.
3. Address of Operator P.O. Box 730 Hobbs, New Mexico	4. Well Location Unit Letter G : 2173 Feet From The North Line and 2173 Feet From The East Line Section 32 Township 16S Range 37E NMPM Lea County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Notify NMOC 24 hours prior to commencement of work.
2. Using dump bailer cap CIBP @ 5997' w/ 35' cmt. (4 sxs Class H, 1.18 cu ft/sx).
3. RIH w/ tubing and fill hole w/ 9.5 lb/gal mud.
4. Perforate 2 squeeze holes at the following intervals: 3340' and 50'.
5. TIH w/ tubing and 5-1/2" cmt retainer. Set retainer @ 3300. Pump 25 sxs Class H cement (1.18 cu ft/sx). Pull out of retainer and pump 50 sxs Class H cement on top of retainer.
6. Spot 100' cement plug 2075' - 2175'. (30 sxs Class H, 1.18 cu ft/sx) SION.
7. Tag plug @ 2075'.
8. Spot 100' cement plug 243' - 343'. (30 sxs Class H, 1.18 cu ft/sx) SION.
9. Tag plug @ 243'.
10. Establish circulation through squeeze holes at 50'. Pump Class H cement down the 8-5/8" casing until cement is circulated back to the surface. Estimated 35 sxs.
11. Cut off well head. Install marker. Clean location.

100' top of S.A.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE M. C. Duncan TITLE Engineer's Assistant DATE 7-12-91

TYPE OR PRINT NAME M. C. Duncan TELEPHONE NO. 393-7191

(This space for State Use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY: