

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.  
LG 2251

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1.  OIL WELL  GAS WELL  OTHER

2. Name of Operator  
Yates Petroleum Corporation

3. Address of Operator  
207 South 4th St., Artesia, NM 88210

4. Location of Well  
UNIT LETTER C 660 FEET FROM THE North LINE AND 1980 FEET FROM  
THE West LINE, SECTION 32 TOWNSHIP 15S RANGE 33E N.M.P.M.

7. Unit Agreement Name

8. Farm or Lease Name  
Lea VP State

9. Well No.  
1

10. Field and Pool, or wildcat  
South Saunders Permo Perm

11. Elevation (Show whether DF, RT, GR, etc.)  
4203.5' GR

12. County  
Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Plugback and test new zone</u> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plugback and test new zone as follows:  
Set CIBP at approximately 10700' and cap w/35' cement.  
Set retainer at 10273'.  
Squeeze perms 10295-300' w/100 sx C1 H w/.07% FL + 100 sx C1 H Neat.  
When squeeze perssure is attained, pull out of retainer and reverse out excess cement.  
Perforate 10243-56' w/10 .42" holes: 10243, 44, 45, 46, 50, 51, 52, 54, 55 and 56'.  
Spot acid and acidize perms w/1500 gals 15% acid + ball sealers.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Sexton TITLE Production Supervisor DATE 10-11-85

APPROVED BY District Supervisor TITLE \_\_\_\_\_ DATE OCT 17 1985

CONDITIONS OF APPROVAL, IF ANY: