

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-2229	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <u>Water Injection</u>		7. Unit Agreement Name <u>SMGSAU</u>
2. Name of Operator <u>Cities Service Company</u>		8. Farm or Lease Name <u>Tract 5</u>
3. Address of Operator <u>P.O. Box 1919 - Midland, Texas 79702</u>		9. Well No. <u>6</u>
4. Location of Well UNIT LETTER <u>B</u> <u>990</u> FEET FROM THE <u>North</u> LINE AND <u>2310</u> FEET FROM <u>East</u> THE <u>29</u> LINE, SECTION <u>17S</u> TOWNSHIP <u>33E</u> RANGE <u>33E</u> NMPM.		10. Field and Pool, or Wildcat <u>Maljamar (G-SA)</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>4111' GR</u>		12. County <u>Lea</u>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☒
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☐
CHANGE PLANS ☐
OTHER ☐

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

O.T.D. 4498' Lime, OPBTD 4460'. It is proposed squeeze Perfs 4110 - 4440' and temporarily abandon this well in the following manner:

1. MIRU pulling unit and pull tubing and packer.
2. RIH w/tubing and retainer and set retainer @ approx. 3920' and squeeze old Perfs 4110 - 4440' w/100 sacks of Class C w/2% CaCl₂, 0.3% Halad 4 & 3-5# sand/sack cement + 100 sacks of Class C w/2% CaCl₂ & 3-5# sand/sack cement.
3. Release from retainer and POOH to approx. 3700' and dump 150' of cement on top of retainer, leaving casing full of cement below retainer. Reverse out excess cement.
4. ND BOP and NU WH. Circulate hole w/inhibited FW and leave tubing hanging in hole.
5. RD unit and clear location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Elmer Startz TITLE Reg. Opr. Mgr. - Prod. DATE 5-24-82
APPROVED BY _____ TITLE _____ DATE MAY 24 1982
CONDITIONS OF APPROVAL, IF ANY: _____