

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE
(Other instructions
reverse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-063645

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

E-K Queen Unit Tr. 1

9. WELL NO.

7

10. FIELD AND POOL, OR WILDCAT

E-K Yates 7/Rivers Queen

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 14, T-18-S, R-33-E

12. COUNTY OR PARISH 13. STATE

Lea

New Mexico

1. OIL ☐ GAS ☐ OTHER ☒ WIW
WELL WELL

2. NAME OF OPERATOR

Mobil Oil Corporat.on

3. ADDRESS OF OPERATOR

Three Greenway Plaza East, Suite 800, Houston, Texas 77046

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

Unit I, 1980' FSL & 660 FEL, Sec. 14, T-18-S, R-33-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3926 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. MIRU
2. Pull tubing and tension packer out of hole.
3. Run 5½" cement retainer on work string to 4125'± and squeeze Queen perfs (4268'-4312') with 50 sx Class H neat cement.
4. Pull out of retainer and spot 5 sx on top of retainer.
5. Load hole with 9.5#/gal fluid.
6. Pull tubing up to 3000'± and spot 25 sx cement on salt bottom.
7. WOC
8. Check cement top to be no less than 2880'±.
9. Pull tubing up to 1800'± and spot 40 sx cement on setting.
10. WOC
11. Check cement top to be no less than 1545'.
12. Run free point, shoot off, POH and lay down 5½ csg (top of cement 400').
13. Pull tubing up to casing cut and spot 70 sx cement (50' of cement below csg cut off and 50' cement above csg shoe.)
14. Pull tubing up to surface and spot 10 sx cement for surface plug.
15. Erect monument and clear location.

Notify USGS 24 hrs prior to beginning P&A.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Authorized Agent

DATE 1-17-77

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side