

7. Acidize w/500 gal. 15% acid.
8. Frac w/30,000 gal. gelled lease crude w/1# 20-40 sand, 1/40# Adomite per gal and 60# gelling agent per 1,000 gal. in 5 equal stages. Use 75# Unibeads between each stage.
9. Pull 2-7/8" tubing and run 2-3/8" tubing to 4700'. Swab and test upper and lower Delaware zones together.
10. Pull 2-3/8" tubing and run RBP to 4825' w/wireline. Run 2-3/8" tubing to 4700' and test upper Delaware zone.
11. If lower zone proves productive, pull RBP. If not, dump 4' hydromite on plug for permanent plug back.
12. Place on production.