

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
2040 Pacheco St.  
Santa Fe, NM 87505

WELL API NO.	30-025-32990
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	17175
7. Lease Name or Unit Agreement Name	
State No. <del>1-10</del>	
8. Well No.	1-10
9. Pool name or Wildcat	Abo
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	
DF 3728', KB 3729', GL 3715'	

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER Dry	2. Name of Operator Crawley Petroleum Corporation
3. Address of Operator 105 N. Hudson, Suite 800, Oklahoma City, Okla. 73102	4. Well Location Unit Letter K : 1700 Feet From The South Line and 2300 Feet From The West Line Section 10 Township 18S Range 37E NMPM Lea County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) DF 3728', KB 3729', GL 3715'	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon well. Plugging procedures to be as follows: set 4-1/2" CIBP at +/- 4050', dump bail 35' of cement on top of plug, cut 4-1/2" casing at +/- 3500' and pull, place 100' cement plug (50' in & out of casing cut), place 100' cement plug inside 8-5/8" casing from 1900' - 2000' (note: 8-5/8" is cemented to surface), place surface cement plug from 10' - surface, cut casing off below ground level, weld on plate.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Diana L. Thompson TITLE Operations Analyst DATE 10/31/97

TYPE OR PRINT NAME Diana L. Thompson (405) 232-9700 TELEPHONE NO.

(This space for State Use)

ORIGINAL SIGNED BY

APPROVED BY GARY WINK TITLE FIELD REP. II DATE 11/1/97

CONDITIONS OF APPROVAL, IF ANY: