

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-73

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.  
E-1638

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO OPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL  GAS WELL  OTHER   
7. Unit Agreement Name  
West Pearl Queen Unit

2. Name of Operator  
Gulf Oil Corporation  
8. Farm or Lease Name

3. Address of Operator  
P. O. Box 670, Hobbs, NM 88240  
9. Well No.  
133

4. Location of Well  
UNIT LETTER C 660 FEET FROM THE North LINE AND 1980 FEET FROM  
10. Field and Pool, or Wildcat  
Pearl Queen

THE West LINE, SECTION 31 TOWNSHIP 19S RANGE 35E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)  
3729' GL  
12. County  
Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK   
TEMPORARILY ABANDON   
PULL OR ALTER CASING   
OTHER Re-enter PA'd well & re-plug & abandon as directed by OCD

PLUG AND ABANDON   
CHANGE PLANS

SUBSEQUENT REPORT OF:

REMEDIAL WORK   
COMMENCE DRILLING OPNS.   
CASING TEST AND CEMENT JOB   
OTHER

ALTERING CASING   
PLUG AND ABANDONMENT

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Drill up 50' surface plug; drill up the 100' cement plug from 1900'-2000', clean out to 3350'. Perf at 3300' with (4) 1/2" JH with 90° phasing. Establish circulation thru perfs and out 7"-13-3/8" annulus with 10# brine water. Set cement retainer at 3250'; re-establish circulation with 10# brine. Cement 7" hole annulus with 550 sacks Class "C" with 16% gel + 1/2# flo seal/sack followed by 750 sacks Class "C" + 2% CaCl<sub>2</sub> + 5# gilsonite/sack. (If cement does not circulate, run temperature survey for top of cement. Perforate at approx 1900' with (4) 1/2" 90° phased JH. Break down perfs and cement with 750 sacks Class "C" neat. Circulate abandonment mud.) (If cement circulates, pull out of retainer, reverse out excess cement, circulate abandonment mud; spot a 100' cement plug 2000'-1900'.) Set 50' surface cement plug. Place dry hole marker on well. Clear and clean location as required.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED RDPite TITLE Area Engineer DATE 9-5-80

APPROVED BY [Signature] TITLE [Signature] DATE SEP 8 1980

CONDITIONS OF APPROVAL, IF ANY: