

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 12-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State Lease Fee
5. State Oil & Gas Lease No.
E-5841

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO OPERATE OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL GAS WELL OTHER

7. Unit Agreement Name
West Pearl Queen Unit

Name of Operator
Gulf Oil Corporation

8. Term or Lease Term

Address of Operator
P. O. Box 670, Hobbs, NM 88240

9. Well No.
141

Location of Well
UNIT LETTER C 660 FEET FROM THE North LINE AND 1980 FEET FROM
THE West LINE, SECTION 33 TOWNSHIP 19S RANGE 35E NMPM.

10. Field and Pool, or Wildcat
Pearl Queen

15. Elevation (Show whether DF, RT, GR, etc.)
3714' GL

12. County
Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
NULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> Repair Casing Leak	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

11. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

POH with production equipment. Set RBP at 4700', set packer at 4200'; test 500#. Pressure tubing-casing annulus to 500# at 5 min; if pressure does not hold on annulus, unseat packer and set at 500' intervals from 4200' to surface. Apply 500# to annulus and isolate any leaks. POH with packer. GIH with cement retainer. Place 10' sand on RBP at 4700'. Squeeze leak(s) with Class "C" cement with CaCl₂. WOC. Drill out cement retainer and cement. Reverse sand off RBP and retrieve RBP. GIH with 2-3/8" tubing and MA. Run rods and redressed pump. Return well to production.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R. D. Pitre TITLE Area Engineer DATE 3-23-83

APPROVED BY ORIGINAL SIGNED BY JERRY SEXTON TITLE DISTRICT 1 SUPERVISOR DATE MAR 28 1983

CONDITIONS OF APPROVAL, IF ANY: