

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION '67

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State Fee
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Continental Oil Company	8. Farm or Lease Name Reed Sanderson Unit
3. Address of Operator P. O. Box 460, Hobbs, New Mexico 88240	9. Well No. 22
4. Location of Well UNIT LETTER <u>E</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>10</u> TOWNSHIP <u>20S</u> RANGE <u>36E</u> NMPM.	10. Field and Pool, or Wildcat Eumont Pool
15. Elevation (Show whether DF, RT, GR, etc.) 3608 D.F.	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
OTHER <u>Convert to Water Injection</u> <input checked="" type="checkbox"/>	OTHER _____ <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

In connection with the Reed Sanderson Unit Waterflood, it is proposed to convert the subject well to water injection using the following procedure:

1. Tag bottom at 4017' If fill exists clean out to 4017'.
2. Run cement-lined tubing w/packer set at approximately 3700'.
3. Connect up well and commence water injection down the tubing.

NMOCC Order R-3131 was issued on September 28, 1966, authorizing institution of the Reed Sanderson Unit Waterflood.

A subsequent report will be submitted upon completion of this work.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jesse L. Stark TITLE Supervising Engineer DATE 5-5-67

APPROVED BY _____ TITLE _____ DATE _____