

Submit 3 Copies to Appropriate District Office

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO.	3002505804
5. Indicate Type of Lease	STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	
2. Name of Operator AMERADA HESS CORPORATION	
3. Address of Operator DRAWER D, MONUMENT, NEW MEXICO 88265	
4. Well Location Unit Letter <u>E</u> : <u>1980</u> Feet From The <u>NORTH</u> Line and <u>660</u> Feet From The <u>WEST</u> Line Section <u>33</u> Township <u>T19S</u> Range <u>37E</u> NMPM LEA County	

7. Lease Name or Unit Agreement Name W.E. HATCHETT
8. Well No. 2
9. Pool name or Wildcat <i>Exnice Monument 6/5A</i>

10. Elevation (Show whether DF, RKB, RT, GR, etc.)	
--	--

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

<b>NOTICE OF INTENTION TO:</b>		<b>SUBSEQUENT REPORT OF:</b>	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <u>RE-PLUG AND ABANDON.</u> <input checked="" type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Move in and rig up pulling unit. Cut off P & A marker. TIH with tubing, drill collars and bit. Drill out surface plug and clean out to 1,400'. TOH with tubing, drill collars and bit. Rig up Schlumberger. Perforate 1,394'-1,398' with 1 JSPF. Rig down Schlumberger. TIH with packer on tubing and establish rate and pressure. TOH with packer. Rig up cementers. TIH with cement retainer on tubing to 1,294'. Clear retainer. Set retainer. Mix and pump 200 sacks of Class "C" cement. Attempt to circulate cement then obtain squeeze. Pull out of retainer and cap with 100' of cement; TOH with tubing and spot 50 foot plug at surface. Weld on P & A marker. Rig down and move out pulling unit. Clean and clear location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Terry L. Harvey TITLE Senior Staff Assistant DATE 03-08-94

TYPE OR PRINT NAME Terry L. Harvey TELEPHONE NO. 393-2144

(This space for State Use)

APPROVED BY ORIGINAL SIGNED BY DISTRICT SUPERVISOR TITLE \_\_\_\_\_ DATE MAR 28 1994

CONDITIONS OF APPROVAL, IF ANY: \_\_\_\_\_