

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Submit in triplicate
(Other instructions on reverse side)

Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR AMERADA HESS CORPORATION		8. FARM OR LEASE NAME BRITT A	
3. ADDRESS OF OPERATOR DRAWER D, MONUMENT, NEW MEXICO 88265		9. WELL NO. 2	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1980' FSL & 1980' FWL Unit K		10. FIELD AND POOL, OR WILDCAT EUMONT 4-SR-22	
14. PERMIT NO.		11. SEC., T., R., M., OR BLM. AND SURVEY OR AREA SEC. 6, T-20S, R-37E	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3,582' DF		12. COUNTY OR PARISH LEA	
		13. STATE NM	

N.M. OIL CONS. COMMISSION
P.O. BOX 1980
HOBBS, NEW MEXICO 88240

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
(Other) ☐

PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
ABANDON* ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐
(Other) ☐

REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

ABANDONMENT PROCEDURE ATTACHED.

18. I hereby certify that the foregoing is true and correct

SIGNED Dennis Wann

TITLE SR. PET. ENGINEER

DATE 12-29-93

(This space for Federal or State office use)

APPROVED (ORIG. SGD.) JOE G. LARA
CONDITIONS OF APPROVAL, IF ANY:

TITLE PETROLEUM ENGINEER

DATE 1/25/94

tag plug @ 2500'

*See Instructions on Reverse Side

BRITT A #2
PLUGGING PROCEDURE

1. NOTIFY BLM 24 HOURS PRIOR TO RIG UP.
2. MIRU PU.
3. INSTALL BOP.
4. TOH WITH TUBING AND GUIBERSON PACKER.
5. TIH WITH WORKSTRING AND MODEL R PACKER. TEST PB @ 3279. PULL UP HOLE.
6. LOAD AND TEST CASING TO 500#.
7. LOAD AND TEST TUBING TO 2000#.
8. ESTABLISH RATE AND PRESSURE INTO EUMONT PERFORATIONS 3176'-3235'. TOH.
9. TIH WITH CEMENT RETAINER TO \pm 3100'.
10. SQUEEZE PERFORATION WITH \pm 200 SACKS WITH CLASS C NEAT CEMENT.
11. CIRCULATE HOLE CLEAN WITH MUD.
12. SPOT 35' CEMENT ON CEMENT RETAINER.
13. PULL UP HOLE TO \pm 2500' AND SPOT A 100' CEMENT PLUG ACROSS INTERMEDIATE SHOE.
14. PULL UP HOLE TO \pm 300' AND SPOT A 100' CEMENT PLUG ACROSS SURFACE SHOE.
15. PULL UP HOLE AND SPOT A 50' SURFACE PLUG.
16. CUT OFF WELLHEAD, INSTALL DRY HOLE MARKER, AND CLEAN AND CLEAR LOCATION.