

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	5. LEASE DESIGNATION AND SERIAL NO. LC-031621 (a)
2. NAME OF OPERATOR Union Texas Petroleum Corporation	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR 4000 N. Big Spring, Suite 500, Midland, Texas 79705	7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 2310' FSL & 2279 FWL Sec. 6, T-20-S R-37-E, Unit Letter K	8. FARM OR LEASE NAME Britt "A"
14. PERMIT NO.	9. WELL NO. 5
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3575' DF	10. FIELD AND POOL, OR WILDCAT Monument
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 6, T-20-S, R-37-E
	12. COUNTY OR PARISH Lea
	13. STATE New Mexico

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETION ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. MIRUSU. Notify NMOCC AND USGS. .
2. POH with all production equipment and fill well annulus w/10# gal mud laden fluid.
3. RIH w/tubing work string and tag fish expected @ 3230'.
4. If fish in hole, set cement retainer 20' above, if no fish in hole set cement retainer @3350'.
5. Cement squeeze perforations 3403-3543' thru retainer w/200 sx. Cl. "C".
6. Spot 25 sx cement plug 3250-3350'. Tag cement to make sure not below 3250'.
7. Perforate 5 1/2" casing at 640 w/4 holes and squeeze w/50 sx. leaving 15 sx. inside 5 1/2" casing.
8. Spot 10 sx. plug 50' to surface.
9. Cut off casing, weld on plate, set marker and clean up location.

18. I hereby certify that the foregoing is true and correct

SIGNED

William H. Higgins

TITLE Regul Compl. Coord.

DATE 6-18-84

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

12-31-84

RECEIVED

JAN - 2 1985

G.C.D.
HOBBS OFFICE