

NO. COPIES RECEIVED		
DISTRIBUTION		
OFFICE		
FOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT TO DRILL" (FORM C-101) FOR SUCH PROPOSALS.

1. OIL WELL  GAS WELL  OTHER

2. Name of Operator  
**Atlantic Richfield Company**

3. Address of Operator  
**P. O. Box 1710, Hobbs, New Mexico 88240**

4. Location of Well  
UNIT LETTER **I** **2310** FEET FROM THE **South** LINE AND **495** FEET FROM  
THE **East** LINE, SECTION **7** TOWNSHIP **20S** RANGE **37E** NMPM.

7. Unit Agreement Name

8. Farm or Lease Name  
**Bertha J. Barber**

9. Well No.  
**17**

10. Field and Pool, or Wildcat  
**Monument Paddock**

15. Elevation (Show whether DF, RT, GR, etc.)  
**3551' GR**

12. County  
**Lea**

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data


NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>


17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 5674'. PBD 5239'. Well is presently completed in perms 5162-5215' and shut in.  
 13-3/8" OD 48# csg set @ 917' & cmtd w/1000 sx. Cmt circ to surface.  
 9-5/8" OD 36# csg set @ 2863' & cmtd w/1600 sx. Cmt circ to surface.  
 7" OD 23# csg set @ 5673' & cmtd w/350 sx. Temp survey indicated cmt back of 7" csg @ 2700' FS.  
 Recent attempt to recomplete well in the Monument Paddock zone failed, no other zones of interest to test. Propose to P&A in the following manner:

1. Rig up, install BOP, pull completion assy.
2. RIH w/7" cmt retr. Set retr @ approx 5140' on WL.
3. RIH w/tbg, sting into retr & cmt squeeze perms 5162-5215' w/35 sx Cl C. Pull out of retr & displace 10 sx on top of retr. Fill hole w/heavy gelled mud between all plugs above retr.
4. Run free pt & cut 7" csg as determined by free pt. Pull 7" csg from approx 2690'.
5. Spot 75 sk Cl C cmt plug across 9-5/8" OD csg shoe @ 2863' & 5 1/2" OD csg stub.
6. Spot 10 sk cmt plug @ surface, install regulation dry hole marker. Clean & level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED  TITLE Dist. Drlg. Supv. DATE 6/19/75

APPROVED BY  TITLE Geologist DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: