

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMITTED IN CONNECTION WITH  
(Other instructions on reverse side)

Form approved.  
Budget Bureau No. 42-R1424  
8. LEASE DESIGNATION AND SERIAL NO.

RM-04063

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR Greathouse & Pierce	8. FARM OR LEASE NAME Federal //
3. ADDRESS OF OPERATOR 204 V & J Tower, Midland, Texas 79701	9. WELL NO. -10
4. LOCATION OF WELL (Report location clearly and in accordance with State requirements. See also space 17 below.) at surface: 660' FNL & 1980' FNL	10. FIELD AND POOL, OR WILDCAT
14. PERMIT NO.	11. TWP., R., M., OR BLK. AND SURVEY OR AREA Sec. 10-20S-34E
15. ELEVATIONS (Show whether DE FT., CK, etc.) 3630' GRD	12. COUNTY OR PARISH Lea
	13. STATE N. M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	HOLE OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETS <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input checked="" type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measures, and true vertical depths for all markers and zones pertinent to this work.)\*

1. Set cement plug in 4 1/2" csg. w/25 sks. @ 12,500-12,800', and 25 sks. @ 10,000-10,300'.
2. Set cement plug w/25 sk @ 4 1/2" casing stub @ 8606'.
3. Set cement plug w/25 sk @ 8-5/8 casing shoe @ 5650'.
4. Set cement plug w/25 sk at 3300'-3400'.
5. Set cement plug w/25 sk @ 8-5/8 casing stub @ 940'.
6. Set cement plug w/25 sk @ 13-3/8 casing shoe @ 528'.
7. Set cement plug w/10 sk at surface w/ marker.
8. Hole was loaded w/mud-laden fluids.

18. I hereby certify that the foregoing is true and correct:

SIGNED: [Signature] DATE: 2/23/72

(This space for Federal or State use only)

APPROVED BY: \_\_\_\_\_  
COMMISSIONER OF APPLICABLE AGENCY