

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
E-8913	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator Hamon Operating Company		8. Farm or Lease Name State E-8913 Com
3. Address of Operator 611 Petroleum Building, Midland, Texas 79701		9. Well No. 1
4. Location of Well UNIT LETTER <u>D</u> <u>660</u> FEET FROM THE <u>West</u> LINE AND <u>660</u> FEET FROM THE <u>North</u> LINE, SECTION <u>20</u> TOWNSHIP <u>20S</u> RANGE <u>36E</u> NMPM.		10. Field and Pool, or Wildcat Osudo North Morrow
15. Elevation (Show whether DF, RT, GR, etc.) 3644' KB		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOBS ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐  
OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set cement retainer at 11,200' and squeeze with 50 sks of cement. Circulate around with 10# salt gel mud.
- 35 sk cement plug from 10,829' back to 10,560'. (Top of Atoka at 10,829').
- 35 sk cement plug from 10,207' back to 9,938'. (Top of Wolfcamp at 10,207').
- 35 sk cement plug from 7,384' back to 7,115'. (Top of Bone Springs at 7,384').
- Cut and pull 5 1/2" casing at 5300'. (Base of 9 5/8" casing at 5220'). Spot 150 sk cement plug from 50' in 5 1/2" stub back to 5000'. (This will be 200' in base of 9 5/8" csng.). Tag plug.
- 75 sk plug from 3370' back to 3200'. (Base of salt at 3370').
- 75 sk plug from 1960' back to 1800'. (Top of salt at 1960').
- Cut and pull 9 5/8" casing from approx. 750'. Spot 100 sk plug 50' in and 50' above the 9 5/8" casing stub.
- 150 sk plug from 425' back to 260'. (Base of 13 3/8" casing at 372'). Tag plug.
- 10 sks in top of 13 3/8" casing. Install dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Cecil H. Barton</u>	TITLE <u>Production Engineer</u>	DATE <u>12-9-85</u>
ORIGINAL SIGNED BY <u>JERRY SEXTON</u>		
DISTRICT 1 SUPERVISOR		
APPROVED BY _____	TITLE _____	DATE <u>DEC 12 1985</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

DEC 11 1985

O.C.D.  
HOBBS OFFICE