

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instruction on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

NM-0560408

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Aztec Federal "14"

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Lea (Penn)

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREASec. 14, T-20-S,
R-34-E

12. COUNTY OR PARISH 13. STATE

Lea New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

Western States Producing Company

3. ADDRESS OF OPERATOR

900 Building of the Southwest Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980' FSL

1830' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3648' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Spot 35 sack cement plug from 9500' back to 9300'.
2. Lay down tubing and free point 7" casing.
3. Shoot off casing and spot 35 sack cement plug at cut off point.
4. Spot 35 sack cement plug at 5800', top of Glorieta.
5. Spot 50 sack cement plug from 5100' back to 4980'.
6. Free point 9-5/8" casing and shoot off casing (3200').
7. Spot 50 sack plug at cut off.
8. Spot 75 sack plug from 750' back to 630'.
9. Spot 10 sack plug at surface.
10. Cut off head, weld on plate and set marker and clean location.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Operations Manager

DATE August 18, 1972

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED

AUG 22 1972

ARTHUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse Side

RECEIVED

AUG 22 1972

OIL CONSERVATION COMM.
HOBBS, N. M.