

Bass Federal #1

PROCEDURE (PART 1) - LOWER DELAWARE TEST:

1. MIRUSU.
2. ND tree & NU BOP's.
3. Release packer at 11,300' and let well equalize. TOH.
4. RU Wireline and set a 5 1/2" CIBP for 17# casing at 11,350'. Cap CIBP with 35' of cement.
5. RU Wireline and run a CBL/CCL Log from 5500' - 8500' with hole full of water to check cement bonding.
6. RIH with 4" casing guns, loaded 4 SPF 180° or 90° phasing and perforate the Lower Delaware at:

7814 - 24'	(10')
7840 - 55'	(15')
7990 - 8010'	(20')
8030 - 8040'	(10')
Total	55'

Correlate to the Welex Compensated Acoustic Velocity Log dated 12/2/72.

7. TIH with tubing and packer to 7,800'. Hydrotest tubing to 7000 psi.
8. Swab test zone for signs fluid entry and prep to acidize.
9. Acidize with 3500 gallons of 7 1/2% NEFe acid and ball sealers per forthcoming procedure. Test annulus to 2000 psi.

COPIED  
MAY 2 10 16 AM '93

COPIED