

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE  
(Other instructions on reverse side)

Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 13276

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL  GAS WELL  OTHER  plug hole

7. UNIT AGREEMENT NAME

2. NAME OF OPERATOR  
Walter W. Krug DBA Wallen Production Company

8. FARM OR LEASE NAME

Wallen Federal

3. ADDRESS OF OPERATOR

9. WELL NO.

# 8

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\* See also space 17 below.)  
At surface  
2310' FSL 2310' FWL

10. FIELD AND POOL, OR WILDCAT Pool  
Teas, Yates, Seven Rivers

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec 18, T 20 S, R 34 E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3614

12. COUNTY OR PARISH

13. STATE

Lea

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

MULTIPLE COMPLETE

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDIZE

ABANDON\*

SHOOTING OR ACIDIZING

ABANDONMENT\*

REPAIR WELL

CHANGE PLANS

(Other) plug out hole

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Plugged the above hole as follows :::

1. Bottom of salt 3106 feet of tubing, put in 2 bbls of water plus 25 sacks cement.
2. Come up to the top of salt 1600 feet with tubing add 50 bbls of water and 4 sacks of gel plus 25 sacks of cement.
3. Come up to 165 feet, add 47 bbls of water and 4 sacks of gel, plus 25 sacks cement.
4. Filled the cellar up to the top of the ground with cement and placed marker on top of hole.

Plugged & ABD 10-2-75

18. I hereby certify that the foregoing is true and correct

SIGNED

Walter W. Krug

TITLE

Engineer

DATE

10-8-1975

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED  
DEC 24 1975  
RAB