

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIP
(Other Instructions on Reverse Side)Form approved.
Budget Bureau No. 42 R1434

5. LEASE DESIGNATION AND SERIAL NO.

NM 070315

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Walter W. Krug DBA Wallen Production Company

3. ADDRESS OF OPERATOR

Box 1960, Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)

At surface

990 FWL & 330 FSL

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Bass

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT RIVER

Middle Lynch, Yates 7-

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec 21, T. S, R 34

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

GR 3672

12. COUNTY OR PARISH

Lea

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

On 10/6 & 7/78 we will plug back well from 3550 feet to 3421 feet with sand and gravel and seal with 60 # of lead wool and tamp it with 2500# of tools. We will then place 35 sxs (120') of class H neat cement through tubing and let harden overnight. Check plug in morning and if there, fill hole with 120 bbls of water & 24 sxs gel and pull 8 5/8 casing from 1100 feet, with tubing at 1100' place 25 sxs plug of cement (class "H" neat) and fill hole with 120 bbls water & 24 sxs gel. Now pull 10 3/4 casing and run 7 jts of tubing & cement at 215 feet with 30 sxs of class "H" neat with 10 sxs cement.

18. I hereby certify that the foregoing is true and correct

SIGNED

Walter W. Krug

TITLE

Engineer

DATE


10/10/78

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:



RECEIVED

NOV 7 1978

OIL POLLUTION COMM.
ROCKY, N. M.