

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State * Fee

*USA owns royalty in S-1/2 of Sec. 17

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - L" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name COM AGR SW 437
2. Name of Operator Hamon Oil Company	8. Farm or Lease Name Amerada Federal
3. Address of Operator 611 Petroleum Building, Midland, Texas 79701	9. Well No. 2
4. Location of Well UNIT LETTER <u>F</u> 1980 FEET FROM THE <u>North</u> LINE AND 1980 FEET FROM THE <u>West</u> LINE, SECTION <u>17</u> TOWNSHIP <u>20S</u> RANGE <u>36E</u> NMPM.	10. Field and Pool, or Wildcat North Osudo Morrow
15. Elevation (Show whether DF, RT, GR, etc.) 3636.5' K.B.	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Fill drill pipe with water and pump into formation, followed by 50 sacks of Class "H", drop 10 ball sealers, then pump in 225 sacks of cement. Displace cement with 104 barrels of 10# salt gel mud. When balls get to bit should seal off and leave top of cement in drill pipe at 7300'.
2. Cut drill pipe at free point estimated at 6500'. Pick up and spot 50 sack cement plug (150') on bottom. Pull out of hole with drill pipe. Tag plug.
3. Run tubing with 8-5/8" squeeze retainer. Set retainer at approximately 200' above base of 8-5/8" casing shoe at 5625'. Squeeze with 100 sacks of cement by pumping 75 sacks below the retainer and spot 25 sacks above the retainer.
4. Spot 50 sack cement plug (135') in 8-5/8" casing as following:
 - a. Base of salt at 3160'.
 - b. Top of salt at 1880'.
 - c. Base of 12-3/4" surface casing at 350'. Tag plug.
5. 10 sack plug in top 8-5/8" casing.
6. Install dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cecil H. Barton TITLE Production Engineer DATE 5-8-85

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT SUPERVISOR

APPROVED BY _____ TITLE _____ DATE MAY 10 1985

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

MAY 9 1985

HOUSE OF REPRESENTATIVES